


Firmware Upgrade Procedures

1. Save the unzipped firmware file to your PC
2. Go to access point's configuration page (default IP is 192.168.10.100)
3. Navigate to the **Administrator** section and select **Upload Firmware** option



4. Browse and select the unzipped firmware file the click Apply button
5. Wait until the firmware upload completed and the device reboot.
6. The firmware upgrade is completed.