


## Firmware Upgrade Procedures

1. Save the unzipped firmware file to your PC
2. Go to router's configuration page (default IP is 192.168.10.100)
3. Navigate to the **Administrator** section and select **Upload Firmware** option



4. Browse and select the unzipped firmware file (.bin) and click the Apply button to load
5. Wait until the firmware upload completed and the device reboot.
6. The firmware upgrade is completed.