

## **Firmware Upgrade Procedures**

1. Save the downloaded firmware file to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
  - a. Make sure to remember the location where the extracted file will be saved.
3. Log into to the range extender's configuration page (default IP is 192.168.10.100)
4. Navigate to the **Administrator** section and select **Upload Firmware** option



The image shows a web-based dialog box titled "Upload Firmware". It has a light gray background. At the top, there is a dark gray header bar with the title "Upload Firmware" in white. Below the header, there is a section with a light blue background. On the left of this section is the label "Location:" in bold. To the right of the label is a white text input field. To the right of the input field is a button labeled "Browse...". Below the input field and the "Browse..." button, there are two buttons: "Apply" and "Cancel". Both buttons have a blue gradient and white text.

5. Click **Browse** and select firmware file (.bin) in the extracted file and the click **Apply** button to load
6. Wait until the firmware upload completed and the device reboots.
7. The firmware upgrade is completed.