


# TRENDnet Print Server Firmware Upgrade Utility Installation

*Note:* Make sure the PC is connected to the Print server's LAN port with an Ethernet cable and any Antivirus, Proxies, and Firewall software is disabled before upgrading.

1. Download utility from TRENDnet.com and zip file.
2. Click on the upgrade utility



3. Install the utility in the default directory and click on next.



4. Installation will install.



5. Now you are Finished

## Upgrade the firmware


1. Click on Start, All Programs, Utiugil, and Upgrade Utility.




2. In the Upgrade utility, click on the browse button



3. Find the print server from the list




4. Highlight the print server from the device list




(Note: the device name can be found on the bottom of the product label and in the Web users interface).

## 5. Click on files to find the firmware file for upgrading.



## 6. Click on OK to upgrade the firmware.



7. Now, the firmware is completed.