

1-Port USB Print Server Web Configuration User' s Manual

Rev.01 (July, 2002)

Made In Taiwan



RECYCLABLE

TABLE OF CONTENTS

WEB CONFIGURATION	3
CONFIGURING THE PRINT SERVER.....	4
MANAGEMENT.....	5
SYSTEM STATUS.....	5
PRINTER STATUS	6
CONFIGURATION	7
SERVER DEVICE.....	7
TCP/IP PROTOCOL.....	8
NETBEUI PROTOCOL	9
APPLETALK PROTOCOL.....	10
TOOLS	11
RESET	11
FACTORY RESET	12
HELP	13
ABOUT.....	13


Web Configuration

This manual describes the use of the Web Configuration for controlling and configuring print servers.

***Note:** The figures listed in this manual are for your reference; the actual settings showed may be different on your system because of different network environment.*

Configuring the Print Server

Open your web browser and type **http://192.168.0.1** in the address box, and press <Enter>. This set of number is the default IP address of your print server. ***Please note that the PC's IP address must correspond with the print server's IP address in the same segment for the two devices to communicate.***



When you entered the default IP address, the main screen of the print server's configuration will appear as below. In addition to the product information, you can access and control the print server's configuration through four links on the top of this main screen: **Management**, **Configuration**, **Tools**, and **Help**.

Management	Configuration	Tools	Help
Welcome to Web Configuration			
Server Name	PS-1118E1		
Model	USB Print Server		
Hardware Version	A1		
Firmware Version	2.20 (2002-10-31)		
MAC Address	00 03 1B 11 18 E1		
IP Address	192.168.0.167 (Manual)		
Up Time	0 days, 01:34:54		

Management

Click on **Management** link from the tools bar of the main screen to enter the Management Table, and it provides information of the print server's *System Status* and *Printer Status*.

System Status

When you choose and enter the **Management** link, the first screen appears is the *System Status* option. (Otherwise, you can click on the *System Status* link in the left column of the **Management** screen to return here from the other screens.) This option will show you the system information as below, providing general information regarding the print server. Click on the <Refresh> button below to capture the most updated information.

Management	Configuration	Tools	Help
<div>Management</div> <div>System Status</div> <div>Printer Status</div>	<div>System Status</div> <div>Server NamePS-1118E1</div> <div>ModelUSB Print Server</div> <div>Hardware VersionA1</div> <div>Firmware Version2.20 (2002-10-31)</div> <div>MAC Address00 03 1B 11 18 E1</div> <div>IP Address192.168.0.167 (Manual)</div> <div>Up Time0 days, 01:36:08</div> <div>Refresh</div>		

Printer Status

Click on the **Printer Status** link in the left column of the **Management** screen to enter the **Printer Status** option. This option will show you the information regarding the printer's status. Click on the <Refresh> button below to capture the most updated information. Once the print server is connected to a printer, the Printer Status in the table will show [Online].

Management	Configuration	Tools	Help
<div>Management</div> <div>System Status</div> <div>Printer Status</div>	<div>Printer Status</div> <div>USB</div> <div>Printer Name : PS-1118E1-U1</div> <div>Printer Status : Off line</div> <div>Refresh</div>		

Configuration

Click on **Configuration** link from the tools bar of the main screen to enter the Configuration Table, and it provides the configuration options that include *Server Device*, *TCP/IP Protocol*, *NetBEUI Protocol*, and *AppleTalk Protocol*.

Server Device

When you choose and enter the **Configuration** link, the first screen appears is the *Server Device* option. (Otherwise, you can click on the *Server Device* link in the left column of the **Configuration** screen to return here from the other screens.) This option will show you settings required to configure the print server. Click the <Save> button to ensure the settings are updated and saved.

Management	Configuration	Tools	Help
Configuration			
Server Device			
Server Name : <input type="text" value="PS-1118E1"/>			
Location : <input type="text"/>			
Admin Contact : <input type="text"/>			
Password : <input type="text" value="New Password"/> : <input type="text"/>			
Confirm Again : <input type="text"/>			
USB			
Port Name : <input type="text" value="PS-1118E1-U1"/>			
Description : <input type="text"/>			
PJL Printer : <input type="text" value="No"/>			
<input type="button" value="Save"/> <input type="button" value="Cancel"/>			

TCP/IP Protocol

Click on the ***TCP/IP Protocol*** link in the left column of the **Configuration** screen to enter the ***TCP/IP Protocol*** option. This option will show you settings required to configure the print server. Click the <Save> button to ensure the settings are updated and saved.

Management	Configuration	Tools	Help
Configuration			
Server Device			
TCP/IP Protocol			
NetBEUI Protocol			
AppleTalk Protocol			
TCP/IP Protocol			
IP Address		<input type="text" value="192.168.0.167"/>	
Subnet Mask		<input type="text" value="255.255.255.0"/>	
Default Gateway		<input type="text" value="192.168.0.1"/>	
IP Assignment		<div><input checked="" type="radio"/> Manually Assign</div> <div><input type="radio"/> Assign Automatically Using<ul style="list-style-type: none"><input type="checkbox"/> RARP<input type="checkbox"/> BOOTP<input type="checkbox"/> DHCP</div>	
SNMP Community 1		Name : <input type="text" value="public"/> Access Right : <input type="text" value="Read/Write"/>	
Community 2		Name : <input type="text"/> Access Right : <input type="text" value="Read Only"/>	
Community 3		Name : <input type="text"/> Access Right : <input type="text" value="Read Only"/>	
		<input type="button" value="Save"/> <input type="button" value="Cancel"/>	

NetBEUI Protocol

Click on the ***NetBEUI Protocol*** link in the left column of the **Configuration** screen to enter the ***NetBEUI Protocol*** option. This option will show you settings required to configure the print server. Click the <Save> button to ensure the settings are updated and saved.

The screenshot shows a software configuration window with a top navigation bar containing four tabs: **Management**, **Configuration**, **Tools**, and **Help**. The **Configuration** tab is active. On the left side, there is a vertical list of configuration options: **Configuration**, **Server Device**, **TCP/IP Protocol**, **NetBEUI Protocol**, and **AppleTalk Protocol**. The **NetBEUI Protocol** option is selected. The main area of the window is titled **NetBEUI Protocol** and contains the following settings:

- Workgroup**: A text box containing the value **WORKGROUP**.
- Maximum Limitation**: A section containing two settings:
 - Maximum Connected Stations**: A numeric input box with the value **32**.
 - Maximum Number of Sessions**: A numeric input box with the value **32**.
- Buttons**: At the bottom of the main area are two buttons: **Save** and **Cancel**.

AppleTalk Protocol

Click on the *AppleTalk Protocol* link in the left column of the **Configuration** screen to enter the *AppleTalk Protocol* option. This option will show you settings required to configure the print server. Click the <Save> button to ensure the settings are updated and saved.

The screenshot shows a software interface with a top navigation bar containing four tabs: **Management**, **Configuration**, **Tools**, and **Help**. The **Configuration** tab is active. On the left side, there is a vertical list of configuration options: **Configuration**, **Server Device**, **TCP/IP Protocol**, **NetBEUI Protocol**, and **AppleTalk Protocol**. The **AppleTalk Protocol** option is highlighted. The main area of the window is titled **AppleTalk Protocol** and contains a section labeled **AppleTalk Zone** with a text input field containing an asterisk (*). Below this is a section labeled **USB** with the following settings: **Chooser Name** is set to **PS-1118E1-U1**; **Printer Type** is set to **LaserWriter**; **PostScript Level** is set to **Level 2** (indicated by a dropdown arrow); and **Font Group** is set to **Standard 35** (indicated by a dropdown arrow). At the bottom of the main area are two buttons: **Save** and **Cancel**.

Tools

Click on **Tools** link from the tools bar of the main screen to enter the Tools Table, and it provides the control options that include **Reset** and **Factory Reset**.

Reset

When you choose and enter the **Tools** link, the first screen appears is the **Reset** option. (Otherwise, you can click on the **Reset** link in the left column of the **Tools** screen to return here from the other screen.) Click the <Yes> button to activate the reset procedure.

Management	Configuration	Tools	Help				
<table border="1"><thead><tr><th>Tools</th><th>Reset</th></tr></thead><tbody><tr><td>Reset Factory Reset</td><td><div>Do you really want to reset this device?</div><div>YES</div></td></tr></tbody></table>				Tools	Reset	Reset Factory Reset	<div>Do you really want to reset this device?</div> <div>YES</div>
Tools	Reset						
Reset Factory Reset	<div>Do you really want to reset this device?</div> <div>YES</div>						

Factory Reset

Click on the **Factory Reset** link in the left column of the **Tools** screen to enter the **Factory Reset** option. Click the <Yes> button to resume the factory settings.

Management	Configuration	Tools	Help
------------	---------------	-------	------

Tools

[Reset](#)

[Factory Reset](#)

Factory Reset

Do you really want to factory reset this device?

YES

Help

Click on **Help** link from the tools bar of the main screen to enter the Help Table, and it provides general information about the print server.

About

When you choose and enter the **Help** link, the screen appears is the ***About*** option. This option will show you the system information as below, providing general information regarding the print server.

