


Firmware Upgrade Procedures

1. Save the unzipped firmware file to your PC
2. Go to router's configuration page (default IP is 192.168.10.1)
3. Navigate to the **Toolbox** tab and select **Firmware Upgrade** option



The screenshot shows a web browser window titled "Firmware Upgrade". The interface has a dark header bar with the title. Below the header, there is a section labeled "Firmware Filename" which contains a text input field and a "Browse..." button. Underneath this section, it states "Current firmware version is R1.06a3_0203." followed by a warning: "Note! Do not interrupt the process or power off the unit when it is being upgraded. When the process is done successfully, the unit will be restarted automatically." At the bottom of the window, there are two buttons: "Upgrade" and "Cancel".

4. Browse and select the unzipped firmware file the click Apply button to load
5. Wait until the firmware upload completed and the device reboot.
6. The firmware upgrade is completed.