


Firmware Upgrade Procedures

1. Save the downloaded firmware file to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
 - a. Make sure to remember the location where the extracted file is saved will be saved.
3. Log into to the router's configuration page (default IP is 192.168.10.1) username and password is "admin"
4. Navigate to the **Maintenance** section and select **Firmware Upgrade** option



The screenshot shows a web interface for upgrading firmware. At the top, it displays "Current Firmware Version V1.02.B03". Below this, there is a section labeled "Upgrade Firmware" which contains a text input field and a "Browse..." button. At the bottom of the interface, there is an "Apply" button.

5. Click **Browse** and select firmware file (.bin) in the extracted file and the click **Apply** button to load
6. Wait until the firmware upload completed and the device reboot.
7. The firmware upgrade is completed.