Firmware Upgrade Procedure

1. Save the downloaded firmware file (.zip) to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
    a. Make sure to remember the location where the extracted file will be saved.
3. Log into to the router's configuration page
   Default URL/IP address: http://192.168.10.200
   Default User Name: admin Default Password: admin
4. Navigate to the **Management** section and under the **Firmware Upgrade** section, click **Upgrade.**

5. When prompted to enter Loader Mode, click **OK**.

5. Wait for the loader page to appear and click **Browse** or **Choose File.** Navigate to the folder on your computer where the unzipped firmware file (*.bin*) is located and select it. Click **Upgrade**. If prompted, click **Yes** or **OK**. You may also click **Reboot** to cancel the firmware upgrade.

Please note the following:

- Do not interrupt the firmware upgrade process. Do not turn off the device or press the Reset button during the upgrade.
- If you are upgrade the firmware using a laptop computer, ensure that the laptop is connected to a power source or ensure that the battery is fully charged.
- Disable sleep mode on your computer as this may interrupt the firmware upgrade process.
- Do not upgrade the firmware using a wireless connection, only using a wired network connection.
- Any interruptions during the firmware upgrade process may permanently damage your switch.