

## TFM-560U(B1) Microsoft Windows 7 Installation

### Minimum System Requirements


- USB Port: 1.1 or 2.0
- CPU: 1GHz or above
- Memory: 1GB RAM or above
- Hard Driver Space: 4MB or above

### Note:


1. DO NOT install the TFM-560U in the computer until instructed to do so.
2. You will need to uncompress the drivers after you download it.
3. These instructions are only for TFM-560U version B1. A1 version does not support Windows 7.

1. Go to <http://www.trendnet.com/downloads>. From the Select Product dropdown list, scroll down until you see TFM-560U. Then click Go. Select the hardware version B1, click the Windows 7 driver link and save the drivers to your computer.


2. Browse the Windows 7 folder. Go to the x64 folder if you have 64-bit Windows 7. Go to the x86 folder if you have 32-bit Windows 7.



3. Double click on the Setup icon



4. Click OK.



5. Remove the TFM-560U USB cover and then connect the modem to an available USB 2.0 or 1.1 port on the computer.



6. Connect a telephone cable from the modem to a phone jack.



Your installation is now complete.