

TFM-560X(YO) Microsoft Windows 7 Installation

Minimum System Requirements

- RS-232 COM port
- CPU: 1GHz or above
- Memory: 1GB RAM or above
- Hard Driver Space: 4MB or above

Note:

1. DO NOT install the TFM-560X in the computer until instructed to do so.
2. You will need to uncompress the drivers after you download it.
3. These instructions are only for TFM-560X version Y0. EU version does not support Windows 7.

1. Go to <http://www.trendnet.com/downloads>. From the Select Product dropdown list, scroll down until you see TFM-560X. Then click Go. Select the hardware version Y0, click the Windows 7 driver link and save the drivers to your computer.

2. Shutdown your computer.

3. Plug the male end of the RS-232 cable into the TFM-560X. Then plug the female end of the RS-232 cable into your computer's COM port.



4. Connect the AC Power Adapter to the Modem and then to a power outlet




5. Turn on the modem.

6. Turn on the PC.


7. Browse the Windows 7 folder. Go to the **x64** folder if you have 64-bit Windows 7. Go to the x86 folder if you have 32-bit Windows 7.




8. Double click on the **Setup** icon




9. Click **OK**.



10. Select your country and then click **OK**.



11. Click **OK**.



12. Plug one end of a RJ-11 telephone cord into the **Line** port on the Modem, and then connect the other end into the telephone jack.



13. Connect your telephone into the Phone port (optional).

Your installation is now complete.

For detailed information regarding the TFM-560X configuration and advanced settings, please refer to the User's Guide included on the Driver CD-ROM or TRENDnet's website at www.trendnet.com