

Installation

Note:

iOS must be version 5.0 or higher.

1



Tap on the **App Store** icon to download and install TRENDnet CloudView app. Once installed, tap the **TRENDnet CloudView** icon to open up the app.

Remote Camera Setup

1



- Tap the **Manually Add Camera** icon at the upper right corner of the screen.

2



- Tap the **Name** field

3



- Enter a suitable camera name of your own choice. Then tap **Save**.

4



• Tap the **ID** field.

5



• Enter your cloud camera's 8 digit ID. The ID is located on a sticker on your camera. Then tap the **Save** icon.

6




• Tap the **Username** field.

7




• Enter the cloud camera's username and then tap **Save**. This is the username that you configured during the cloud camera setup.

8



• Tap the **Password** field.

9



• Enter your camera's **password** and then tap **Save**. This is the password that you configured during the cloud camera setup.

10



• Tap Save.


11



• After the camera has been added, CloudView will return to the Camera List screen. Repeat steps 1-10 to add more cameras.

View Video

1



- Tap the desired **Camera**.

2



- Video will appear in portrait mode. The function toolbar will be located below the video.

3



- Rotate the iPhone horizontally to view the video in landscape mode.

4




- Pinch the screen to zoom in and zoom out.

5



- In landscape mode, tap the screen to bring up the function toolbar.

6



- Above is the function toolbar. Buttons include: pan and tilt, snapshot, enable/disable microphone, enable/disable speaker, resolution, settings (profile and audio), refresh and information. If the button is greyed out, the IP camera does not support that function.

Local Camera Setup

Note:


- Before proceeding, you must establish a wireless connection to the network where your IP cameras are installed.
- This method will not allow you to see video while away from your local network. Remote camera setup is recommended.

1




• Tap the **Scan Camera** icon at the upper left corner of the screen.

2




• Tap the desired camera and then click the add icon

3



• Enter the camera's Username and Password and then tap **OK**.

4




• After the selected camera has been added, CloudView will return to the Camera List screen. Repeat steps 1-3 to add more cameras.

Wireless Configuration (Optional)**Note:**

- Before proceeding, you must establish a wireless connection to the network where your IP cameras are installed.


1



Camera List

- Tap the **Scan Camera** icon at the upper left corner of the screen.

2




Scan Cameras

Please select the desired cameras for viewing.
(Only cameras on your network can be shown.)

- Tap the wireless icon next to the desired cameras.

3




TV-IP782IC

admin

Cancel OK

- Enter the camera's Username and Password and then tap **OK**.

4



Wireless Setting

Model
TV-IP782IC

SSID
TRENDnet658

Key

AP List

TRENDnet12
TRENDnet658

TRENDnet

- Select the desired SSID from the AP list, enter the Key and then click the **Save** icon.

Technical Support

If you have any questions regarding the product installation, please contact our Technical Support.

Toll free US/Canada: 1-866-845-3673

Regional phone numbers available
at www.trendnet.com/support

Product Warranty Registration

Please take a moment to register your product online. Go to TRENDnet's website at:

<http://www.trendnet.com/register>

TRENDnet

20675 Manhattan Place, Torrance, CA 90501, USA

Copyright © 2013. All Rights Reserved. TRENDnet.