


Upgrade Procedures for TE100-MP1U, TE100-MP2U, TEW-MP2U

1. Unzip the downloaded firmware files and save it on your Desktop
2. Go to Print Server's web configuration page, click on Configurations → Maintenance → Firmware Upgrade



3. Click on **Browse** button and search for the unzipped firmware file then click on **Upload** button
4. Firmware update is completed.

Note: Firmware v2.36 or above requires to work with Utility v2.36. Please remove the previous installed MFP Server Control Center and download/install the new version.