TRENDnet®

Microsoft Windows Vista
Installation Guide

1. Microsoft Windows Vista Installation

Important! DO NOT install the adapter in the computer until instructed to do so.

TEW-621PC

1. Shutdown your computer.

2. Insert PC Card firmly into an available PC Card slot on the notebook PC and then turn **ON** the computer and wait until the Windows desktop appears.

3. Go to **Step 7.**

TEW-623PI

**4. Shutdown** your computer.

5. Open your computer's case.

6. Insert PCI Card firmly into an available PCI Card slot on the desktop PC, attach the included antenna, and then turn **ON** the computer and wait until the Windows desktop appears.

**7.** Insert the Driver CD into the CD-ROM drive.

8. Click **Locate and install driver software (recommended)**.

Found New Hardware

Windows needs to install driver software for your Network Controller

➤ Locate and install driver software (recommended)
  Windows will guide you through the process of installing driver software for your device.

➤ Ask me again later
  Windows will ask again the next time you plug in your device or log on.

➤ Don't show this message again for this device
  Your device will not function until you install driver software.

[Cancel]

9. Click **Don't search online**.

Found New Hardware - Network Controller

Allow Windows to search online for driver software for your Network Controller?

➤ Yes, always search online (recommended)
  Windows will automatically search for the latest drivers and applications for your hardware and download them to your computer.

➤ Yes, search online this time only
  Windows will search for the latest drivers and applications for this device and download them to your computer.

➤ Don't search online
  Your device may not function properly until you get the latest software.

Please read Microsoft's privacy statement

[Cancel]

10. Click **Next**.

Found New Hardware - Network Controller

Insert the disc that came with your Network Controller

If you have the disc that came with your device, insert it now. Windows will automatically search the disc for driver software.

➤ I don't have the disc. Show me other options.

[Next] [Cancel]

**11.** Click **Install this driver software anyway**.

12. Click **Close**.

Your installation is now complete.

For detailed information regarding the TEW-621PC/TEW-623PI configuration and advanced settings, please refer to the User's Guide included on the Utility & Driver CD-ROM or TRENDnet's website at www.trendnet.com

2. Wireless Configuration

Connecting to an Unsecured Wireless Connection

1. On the bottom right-hand corner of the screen, right click the wireless network connection icon and select **Connect to a network**.

2. Select the desired network and then click **Connect**.

**3.** Click **Connect Anyway**.

4. Click **Close**.

Connecting to a Secured Wireless Connection

1. On the bottom right-hand corner of the screen, right click the wireless network connection icon and select **Connect to a network**.

2. Select the desired network and then click **Connect**.

3. Enter the security key and then click **Connect**.

4. Click **Close**.

Wireless configuration is now complete.

For detailed information regarding the TEW-621PC/TEW-623PI configuration and advanced settings, please refer to the User's Guide included on the Utility & Driver CD-ROM or TRENDnet's website at www.trendnet.com

TRENDnet

TRENDnet Technical Support

US · Canada

Toll Free Telephone: 1(866) 845-3673

24/7 Tech Support

Europe (Germany · France · Italy · Spain · Switzerland · UK)

Toll Free Telephone: +00800 60 76 76 67

English/Espanol - 24/7
Francais/Deutsch - 11am-8pm, Monday - Friday MET

Worldwide

Telephone: +(31) (0) 20 504 05 35

English/Espanol - 24/7
Francais/Deutsch - 11am-8pm, Monday - Friday MET

Product Warranty Registration

Please take a moment to register your product online.
Go to TRENDnet's website at http://www.trendnet.com

TRENDnet

20675 Manhattan Place
Torrance, CA 90501
USA