



Quick Installation Guide



TEW-621PC

Table of Contents

Русский	1
1. Что нужно сделать в самом начале	1
2. Порядок установки	2
3. Использование беспроводного адаптера	5
Troubleshooting	6

1. Что нужно сделать в самом начале




Содержимое упаковки

- TEW-621PC
- Руководство по быстрой установке
- CD-ROM-диск с драйвером и утилитой

Системные требования

- Гнездо для 32-разр. карт CardBus Type II
- Дискковод CD-ROM
- ЦП: Intel Pentium 300 МГц или выше
- Память: 64 МБ или более
- Windows XP/2000

Применение



2. Порядок установки

Это важно! Не получив необходимого указания, НЕ устанавливайте в компьютере PC-Карт.

1. Установите **CD-ROM-диск со служебной программой и драйвером** в дисковод CD-ROM компьютера и выберите **Install Driver & Utility**.



2. Следуйте указаниям **Мастера InstallShield**. При появлении указания на перезагрузку выберите **Нет** и щелкните по кнопке **Завершить**.

3. Отключите компьютер.


4. Плотно задвиньте PC-карту в свободное гнездо для PC-карт в ноутбуке и **включите** компьютер. Дождитесь полной загрузки Windows.



Примечание: При работе в Windows 2000 перейдите к шагу 9. При работе в Windows XP перейдите к шагу 5.

Windows XP

5. Появится Мастер установки нового оборудования. Выберите **Нет** и щелкните по кнопке **Далее**.



6. Выберите **Установить программное обеспечение автоматически (Install the software automatically)** и щелкните по кнопке **Далее (Next)**.

7. Щелкните по кнопке **Все равно продолжить (Continue Anyway)**.




8. Щелкните по кнопке **Завершить (Finish)**. Далее перейдите к разделу 3.

Windows 2000

9. Драйверы установятся автоматически.

10. Щелкните по кнопке Да (Yes).




Установка завершена.

Подробнее о конфигурировании устройства TEW-621PC и дополнительных настройках можно узнать в разделе «Поиск и устранение неисправностей» руководства пользователя на CD-ROM-диске или на веб-сайте Trendnet по адресу <http://www.trendnet.com>.

3. Использование беспроводного адаптера


1. Дважды щелкните по значку программы беспроводной связи в системном лотке.



2. Щелкните по **Обзор сайта (Site Survey)**.



3. Выберите сетевой идентификатор (SSID), соответствующий вашей точке доступа, и щелкните по кнопке **Далее (Connect)**.



Настройка беспроводной конфигурации выполнена

Подробнее о конфигурировании устройства TEW-621PC и дополнительных настройках можно узнать в разделе «Поиск и устранение неисправностей» руководства пользователя на CD-ROM-диске или на веб-сайте Trendnet по адресу <http://www.trendnet.com>.

Q1: I inserted the TEW-621PC CD-ROM into my computer's CD-ROM Drive and the installation menu does not appear automatically. What should I do?

A1: If the installation menu does not appear automatically, click Start, click Run, and type D:\Autorun.exe where "D" in "D:\Autorun.exe" is the letter assigned to your computer's CD-ROM Drive. And then click OK to start the installation.

Q2: I completed all the steps in the quick installation guide, but my card is not connecting to my access point. What should I do?

A2: You should first verify that the Network Name (SSID) matches your wireless router or access point's SSID. If they already match, you should check your TCP/IP properties to ensure that Obtain an IP Address Automatically is selected. Refer to your Windows User's Manual if you are unable to locate your TCP/IP properties.

Q3: Windows is unable to recognize my hardware. What should I do?

A3: Make sure your computer meets the minimum requirements as specified in Section 1 of this quick installation guide. Also, you must install the wireless configuration utility BEFORE you physically install your network card. Lastly, you may consider moving the card to a different PC Card Slot.

Q4: I cannot open the wireless configuration utility. What should I do?

A4: Access your device manager to make sure the adapter is installed properly. If you see a networking device with a yellow question mark or exclamation point, you will need to reinstall the device and/or the drivers. To access your device manager, right-click My Computer, click Properties, click the Hardware tab, and then click Device Manager.

If you still encounter problems or have any questions regarding the TEW-621PC, please refer to the User's Guide included on the Utility & Driver CD-ROM or contact Trendnet's Technical Support Department.

Certifications

This equipment has been tested and found to comply with FCC and CE Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received. Including interference that may cause undesired operation.



Waste electrical and electronic products must not be disposed of with household waste. Please recycle where facilities exist. Check with you Local Authority or Retailer for recycling advice.



NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.



TRENDnet[®]

TRENDnet Technical Support

US • Canada

Toll Free Telephone: 1(866) 845-3673

24/7 Tech Support



Europe (Germany • France • Italy • Spain • Switzerland • UK)

Toll Free Telephone: +00800 60 76 76 67

English/Espanol - 24/7

Francais/Deutsch - 11 am-8pm, Monday - Friday MET

Worldwide

Telephone: +[31] [0] 20 504 05 35

English/Espanol - 24/7

Francais/Deutsch - 11 am-8pm, Monday - Friday MET

Product Warranty Registration

Please take a moment to register your product online.

Go to TRENDnet's website at <http://www.trendnet.com>

TRENDnet

3135 Kashiwa Street
Torrance, CA 90505
USA