

MAC OS X SOFTWARE INSTALLATION

This section will lead you to install the driver and utility of the TEW-624UB/TEW-644UB on your Apple computer with Mac OS X 10.3~10.6.


Before insert the TEW-624UB/TEW-644UB/TEW-664UB into USB port of your computer, please install the Utility Program first. Make sure that the TEW-624UB/TEW-644UB/TEW-664UB is NOT inserted into the USB slot.

Installation


1. Click the TEW-624UB/TEW-644UB_MAC_OS_X_20091224.dmg, that is TEW-624UB/TEW-644UB/TEW-664UB driver/utility disk image file for Mac OS 10.3~10.6.



2. Click the TEW-624UB/TEW-644UB_MAC_OS_X_20091224 and select the Mac driver folder which applicable on your Apple computer.



3. Double click on the install.pkg to start the installation of the TEW-624UB/TEW-644UB driver/utility.




4. Click “Continue” button.



5. If prompted to, select a destination volume to install the utility and then click Continue.




6. Click “Install” button.




7. Input your password then click “OK” button.



8. Click “Continue Installation”.



9. Click “Restart” to reboot your computer.



10. Insert the TEW-624UB/TEW-644UB/TEW-664UB on your Mac. The USB Wireless Utility will automatically appear. If the utility does not appear, you will find the “USBWirelessUtility” icon in the Dock menu. Click on the USB WirelessUtility icon to start the TEW-624UB/TEW-644UB/TEW-664UB configuration.

