



Quick Installation Guide



TEW-624UB
TEW-644UB
H/W: V1

Table of Contents

Deutsch	1
1. Bevor Sie anfangen	1
2. Installation	2
3. Verwendung des drahtlosen Adapters	4
Troubleshooting	6

1. Bevor Sie anfangen



Packungsinhalt

- TEW-624UB/TEW-644UB
- Treiber- und Dienstprogramm-CD
- Anleitung zur Schnellinstallation

Systemanforderungen

- USB-Port: 1.1 oder 2.0
- CD-ROM-Laufwerk
- Prozessor: 300 MHz oder schneller (XP/2000) / 800MHz oder schneller (Windows Vista)
- Speicher: 256MB RAM oder mehr (XP/2000) / 512MB RAM oder mehr (Windows Vista)
- Windows 2000/XP/Vista

Anwendung

Workstation with Wireless N USB Adapter (TEW-644UB)



Wireless N Home Router (TEW-652BRP)



300Mbps Wireless N USB Adapter (TEW-624UB)



Wireless N Speed

2. Installation

Wichtig! Verbinden Sie den drahtlosen USB-Adapter NICHT mit dem Computer, bevor Sie dazu aufgefordert werden.

Hinweis: Mac OS X (10.4-10.5) Anweisungen entnehmen Sie bitte dem Benutzerhandbuch. Die Mac-Treiber finden Sie in dem Mac OS X-Ordner auf der Utility- und Treiber-CD-ROM.



Für Benutzer von Windows

1. Legen Sie die **Treiber- und Dienstprogramm-CD** in das CD-ROM-Laufwerk Ihres Computers ein.

2. Klicken Sie auf **Run autorun.exe** (setup.exe ausführen) (nur Windows Vista).

3. Klicken Sie dann auf **Install Drivers & Utility** (Programm installieren/Treibers).


4. Klicken Sie dann auf **Next** (Weiter). Und Folgen Sie den Anweisungen des **Installationsassistenten**.



5. Klicken Sie auf **Yes (Ja)**.
(nur Windows 2000).



6. Klicken Sie auf **Finish (Fertigstellen)**.




7. Verbinden Sie den Funkadapter mit einem verfügbaren USB-Anschluss Ihres Computers.



8. Die Treiber werden automatisch installiert.

9. Klicken Sie auf **Yes** (Ja).
(nur Windows 2000).



Ihre Installation ist beendet!


Weitere Informationen zu den Konfigurations- und erweiterten Einstellungen des **TEW-624UB/TEW-644UB** finden Sie im Abschnitt „Problembehandlung“ der Bedienungsanleitung auf der beiliegenden CD-ROM oder auf der Website von Trendnet unter <http://www.trendnet.com>.

3. Verwendung des drahtlosen Adapters


1. Doppelklicken Sie auf das Symbol **TEW-624UB & TEW-644UB Manager** in der rechten unteren Bildschirmecke.



2. Klicken Sie auf **Site Survey** (Standort-Übersicht), wählen Sie die SSID aus und klicken Sie dann auf **Connect** (Verbinden).



3. Wenn an Ihrem Access Point die Verschlüsselung aktiviert ist, wählen Sie die **Authentifizierungsart** und den **Verschlüsselungsmodus** aus, geben den Verschlüsselungsschlüssel ein und klicken dann auf **Apply** (Übernehmen).



Die drahtlose Verbindung ist jetzt vollständig konfiguriert.

Weitere Informationen zu den Konfigurations- und erweiterten Einstellungen des **TEW-624UB/TEW-644UB** finden Sie im Abschnitt „Problembehandlung“ der Bedienungsanleitung auf der beiliegenden CD-ROM oder auf der Website von Trendnet unter <http://www.trendnet.com>.

Registrieren Sie Ihr Produkt

Nehmen Sie sich bitte einen Moment Zeit und registrieren Sie Ihr Produkt online, so dass Sie unsere umfassenden Support- und Kundendienstleistungen in Anspruch nehmen können: www.trendnet.com/register
Vielen Dank für den Kauf eines TRENDnet-Produkts

Q1: I inserted the Utility & Driver CD-ROM into my computer's CD-ROM Drive and the installation menu does not appear automatically. What should I do?

A1: For Windows 2000/XP, if the installation menu does not appear automatically, click **Start**, click **Run**, and type **D:\autorun.exe** where "D" in "D:\autorun.exe" is the letter assigned to your CD-ROM Drive, and then press the ENTER key on your keyboard. For Windows Vista, if the installation menu does not appear automatically, click **Start**, click the **Start Search** box, and type **D:\autorun.exe** where "D" in "D:\autorun.exe" is the letter assigned to your CD-ROM Drive, and then press the ENTER key on your keyboard.

Q2: How do I install the TEW-624UB/TEW-644UB on my Mac?

A2: First, verify that you have Mac OS X 10.4 or 10.5. The TEW-624UB/TEW-644UB does not support any other version of Mac. Second, refer to the User's Guide for step-by-step instructions. The Mac drivers can be found in the Mac OS X folder on the Utility and Driver CD-ROM drive.

Q3: I completed all the steps in the quick installation guide, but my Wireless USB Adapter is not connecting to my access point. What should I do?

A3: First, verify that the **SSID** matches your wireless router or access point's **SSID**. Second, please check with your network administrator for security key in order to access a secured wireless access point or router. Please refer to the User's Guide for more information regarding wireless network security. Third, check your TCP/IP properties to ensure that Obtain an IP address automatically is selected. Fourth, double-click the TEW-624UB & TEW-644UB Manager icon, click **Site Survey** and then click **Refresh** to check and see if there are any available wireless networks listed.

Q4: Windows is unable to recognize my hardware. What should I do?

A4: First, make sure your computer meets the minimum requirements as specified in Section 1 of this quick installation guide. Second, you must complete the installation of the TEW-624UB & TEW-644UB Manager (as described in Section 2) before connecting the Wireless USB Adapter to your computer. Third, connect the Wireless USB Adapter to a different USB port on your computer.

Q5: I cannot open the TEW-624UB & TEW-644UB Manager. What should I do?

A5: Access your device manager to make sure the adapter is installed properly. If you see a networking device with a yellow question mark or exclamation point, you will need to reinstall the device and/or the drivers. To access the device manager on Windows 2000/XP, right-click **My Computer**, click **Properties**, click the **Hardware** tab, and then click **Device Manager**. To access the device manager on Windows Vista, right-click **Computer**, click **Properties** and then click **Device Manager**.

If you still encounter problems or have any questions regarding the **TEW-624UB/TEW-644UB**, please refer to the User's Guide included on the Utility & Driver CD-ROM or contact TRENDnet's Technical Support Department.

Declaration of Conformity



Company

Name:

TRENDware International, Inc.

Address

20675 Manhattan Place

Torrance, CA 90501

USA

Product:

Product Name:

300Mbps Wireless N USB 2.0 Adapter



Model Number:

TEW-624UB

Brand Name:

TRENDnet

Test Standard:

EN 300 328 V1.7.1: 10-2006

EN 301 489-1 V1.5.1: 11-2004

EN 301 489-17 V1.2.1: 08-2002

EN 50371: 2002

EN 50392: 2004

EN 60950-1: 2001

EN 60950-1/A11: 2004

Declaration:

The objects of declaration described above are compliant and following the provisions of the European R&TTE 1999/5/EC

I hereby declare that the products and devices mentioned above are consistent with the standards and provisions of the guidelines.

Sonny Su

Name (Full Name)

February 1, 2009

Date

Director of Technology

Position / Title

Legal Signature

Declaration of Conformity



Company

Name:

TRENDware International, Inc.

Address

20675 Manhattan Place

Torrance, CA 90501

USA

Product:

Product Name:

Wireless N USB Adapter



Model Number:

TEW-644UB

Brand Name:

TRENDnet

Test Standards:

EN 300 328 V1.7.1: 10-2006

EN 301 489-1 V1.6.1: 09-2005

EN 301 489-17 V1.2.1: 08-2002

EN 50392: 2004

EN 60950-1: 2006

Declaration:

The objects of declaration described above are compliant and following the provisions of the European R&TTE 1999/5/EC

I hereby declare that the products and devices mentioned above are consistent with the standards and provisions of the guidelines.

Sonny Su

Name (Full Name)

February 1, 2009

Date

Director of Technology

Position / Title

Legal Signature

Certifications

This equipment has been tested and found to comply with FCC and CE Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received. Including interference that may cause undesired operation.



Waste electrical and electronic products must not be disposed of with household waste. Please recycle where facilities exist. Check with you Local Authority or Retailer for recycling advice.



NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

ADVERTENCIA

En todos nuestros equipos se mencionan claramente las características del adaptador de alimentación necesario para su funcionamiento. El uso de un adaptador distinto al mencionado puede producir daños físicos y/o daños al equipo conectado. El adaptador de alimentación debe operar con voltaje y frecuencia de la energía eléctrica domiciliar existente en el país o zona de instalación.



TRENDnet[®]

Product Warranty Registration

Please take a moment to register your product online.
Go to TRENDnet's website at <http://www.trendnet.com/register>

TRENDnet[®]

20675 Manhattan Place
Torrance, CA 90501
USA