



Quick Installation Guide



TEW-631BRP

Table of Contents

Français	1
1. Avant de commencer	1
2. Installation du matériel	2
3. Configuration du routeur sans fil	3
Troubleshooting	5

1. Avant de commencer



Contenu de l'emballage

- TEW-631BRP
- Guide de l'utilisateur sur CD-ROM
- Guide d'installation rapide
- 1 Antenne amovible 4dBi
- 1 câble Ethernet RJ-45 (jaune)
- Adaptateur secteur (5V, 2,5A)


Configuration nécessaire

- Un ordinateur avec un adaptateur réseau câblé ou sans fil correctement installé.
- Internet à large bande

Modem DSL ou câble installé

Internet : Internet Explorer (5.0 ou supérieur)


Application



2. Installation du matériel

Remarque : Avant de débiter, réunissez toutes les informations concernant votre connexion Internet. En cas de besoin, contactez votre fournisseur d'accès Internet (FAI).

1. Lorsque vous connectez votre ordinateur directement au modem câble ou DSL, vérifiez que vous avez une connexion Internet.



2. Branchez une extrémité du câble RJ-45 jeune à l'un des ports LAN du TEW-631BRP. Branchez l'autre extrémité au port Ethernet de l'ordinateur. Branchez ensuite l'antenne amovible 4dBi.

3. Connectez l'extrémité d'un câble RJ-45 au port WAN du TEW-631BRP. Branchez l'autre extrémité du câble à votre modem.

4. Branchez l'adaptateur secteur AC au TEW-631BRP et ensuite à une prise de courant.

5. Vérifiez que les voyants lumineux suivants, se trouvant sur l'avant, sont allumés :
Power, LAN, WAN et WLAN.



3. Configuration du routeur sans fil

Remarque : Il est recommandé de configurer le routeur sans fil depuis un ordinateur câblé.

1. Ouvrez votre navigateur Internet, tapez-y l'adresse **http://192.168.1.1** et appuyez sur la touche **Enter** (Entrez).



2. Saisissez le nom d'utilisateur et le mot de passe, ensuite cliquez sur **Log In**.
Nom d'utilisateur: **admin**
Par défaut, il n'y a pas de mot de passe.



3. Cliquez sur **Basic**, sur **Internet**, sur **l'assistant de configuration** et ensuite sur **Lancer l'assistant de connexion Internet**



4. Saisissez le même mot de passé dans les deux champs et cliquez ensuite sur **Next** (Suivant). Par défaut, il n'y a pas de mot de passe.



5. Sélectionnez votre fuseau horaire et cliquez sur **Next** (Suivant).



6. Sélectionnez le type exact de connexion Internet et cliquez sur **Next** (Suivant).



7. Configurez les paramètres en vous basant sur les données reçues de votre FAI. Cliquez sur **Next** (Suivant).

8. Cliquez sur **Reboot the Device** (Relancer le périphérique)



9. Cliquez sur **OK**.



L'installation est maintenant complète.

Si vous désirez des informations détaillées sur la configuration et les paramètres avancés du TEW-631BRP, veuillez consulter la rubrique Dépannage, le guide de l'utilisateur sur CD-ROM ou le site Internet de TRENDnet sur <http://www.trendnet.com>.

Q1: I typed `http://192.168.1.1` in my Internet Browser's Address Bar, but an error message says "The page cannot be displayed." How can I get into the TEW-631BRP's web configuration page?

A1: First, check your hardware settings again by following the instructions in Section 2. Second, make sure the LAN and WLAN lights are lit. Third, make sure your TCP/IP settings are set to **Obtain an IP address automatically** (see the steps below).

1. Go into the **Control Panel** and double-click the **Network Connections** icon, right-click the **Local Area Connection** icon and then click **Properties**.



2. Click **Internet Protocol (TCP/IP)** and then click **Properties**. Then click on **Obtain an IP address automatically**.



Fourth, press on the factory reset button for 15 seconds.

Q2: I am not sure what type of Internet Account Type I have for my Cable/DSL connection. How do I find out?

A2: Contact your Internet Service Provider's (ISP) support service for the correct information.

Q3: I went through the Internet Connection Setup Wizard, but I can not get onto the Internet. What should I do?

A3: First, verify that you can get onto the Internet with a direct connection into your modem. Second, contact your ISP and verify all the information that you have in regards to your Internet connection settings is correct. Third, power cycle your modem and router. Unplug the power to the modem and router. Wait 30 seconds, and then reconnect the power to the modem. Wait for the modem to fully boot up, and then reconnect the power to the router.

Q4: All the settings are correct, but I can not make a wireless connection to the Modem. What should I do?

A4: First, make sure that the WLAN switch on the back of the router is set to on. Second, double check that the WLAN light on the Router is lit. Third, power cycle the TEW-631BRP. Unplug the power to the TEW-631BRP. Wait 15 seconds, then plug the power back in to the TEW-631BRP. Fourth, log into the TEW-631BRP (see Section 3). Click on **Basic** and then **Wireless**. Make sure **Enable Wireless** is checked. Fifth, contact the manufacturer of your wireless network adapter and make sure the wireless network adapter is configured with the proper SSID. The preset SSID of the Access Point is **TRENDnet**.

If you still encounter problems or have any questions regarding the **TEW-631BRP**, please contact TRENDnet's Technical Support Department.

Certifications

This equipment has been tested and found to comply with FCC and CE Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received. Including interference that may cause undesired operation.



Waste electrical and electronic products must not be disposed of with household waste. Please recycle where facilities exist. Check with you Local Authority or Retailer for recycling advice.



NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

ADVERTENCIA

En todos nuestros equipos se mencionan claramente las características del adaptador de alimentación necesario para su funcionamiento. El uso de un adaptador distinto al mencionado puede producir daños físicos y/o daños al equipo conectado. El adaptador de alimentación debe operar con voltaje y frecuencia de la energía eléctrica domiciliar existente en el país o zona de instalación.



TRENDnet Technical Support

US • Canada

Toll Free Telephone: 1(866) 845-3673
24/7 Tech Support



Europe (Germany • France • Italy • Spain • Switzerland • UK)

Toll Free Telephone: +00800 60 76 76 67
English/Espanol - 24/7
Francais/Deutsch - 11am-8pm, Monday - Friday MET

Worldwide

Telephone: +(31) (0) 20 504 05 35
English/Espanol - 24/7
Francais/Deutsch - 11am-8pm, Monday - Friday MET

Product Warranty Registration

Please take a moment to register your product online.
Go to TRENDnet's website at <http://www.trendnet.com>

TRENDnet[®]
20675 Manhattan Place
Torrance, CA 90501
USA