


## Firmware Upgrade Procedures

1. Save the unzipped firmware file to your PC
2. Go to access point's configuration page (default IP is 192.168.10.100)
3. Navigate to the **System Management** section and select **Firmware Upgrade** section



The screenshot shows a web interface titled "Firmware Upgrade". It contains a "Firmware Information" section with the following details:

Firmware Information	
Firmware Version :	Cen-CPE-N5H5R V1.0.15
Firmware Date :	2010-12-16 02:52:11
Update Firmware :	<input type="button" value="Browse..."/>

Below the table, there is a green information icon and a text box stating: "From time to time, the product may release new versions of the system's firmware. You can click Check Firmware button to check and download up-to-date firmware and click Browser button to locate the file from your local harddisk."

At the bottom of the interface is a blue "Upgrade" button.

4. Click **Browse** and select the unzipped firmware file (.dat) then click **Upgrade** button
5. Wait until the firmware upload completed and the device reboot.
6. The firmware upgrade is completed.