

Limited Warranty

TRENDnet warrants its products against defects in material and workmanship, under normal use and service. Specific warranty periods are listed on each of the respective product pages on the TRENDnet website.

Garantie Limitée

TRENDnet garantit ses produits contre les problèmes de matériel ou de fabrication, dans des conditions normales d'utilisation et de service. Les périodes de garanties précises sont mentionnées sur chacun des pages produits du site web de TRENDnet.

Eingeschränkte Garantie

TRENDnet gewährt eine Garantie für seine Produkte im Falle von Material- und Bearbeitungsdefekten, bei normaler Verwendung und Wartung. Spezielle Garantiezeiträume werden auf jeder Produktseite auf der Website von TRENDnet genannt.

Garantía limitada

TRENDnet garantiza que sus productos carecen de defectos en el material y la fabricación, en condiciones de uso y funcionamiento normales. Los periodos específicos de garantía figuran en cada una de las páginas de producto del sitio web de TRENDnet.

Ограниченная гарантия

Компания TRENDnet предоставляет гарантию на свои изделия от дефектов материалов и сборки при нормальном использовании и обслуживании. Конкретные гарантийные сроки указаны на странице каждого продукта на сайте компании TRENDnet.

Garantia Limitada

A TRENDnet garante seus produtos contra defeitos de material e mão de obra sob condições normais de uso e serviço. Os períodos de garantia específicos estão listados em cada uma das páginas dos respectivos produtos no site da TRENDnet.

Piiratud garantii

TRENDneti garantii hõlmab materjali- ja koostamisdefekte, mis ilmnevad toote tavapärasel kasutamisel. Garantiaaja täpne pikkus konkretse toote puhul on leitav TRENDneti kodulehelt vastava toote infolehelt.

Garanzia limitata

TRENDneti garante i propri prodotti da difetti di materiali e manodopera, in condizioni di normale uso ed esercizio. I periodi di garanzia specifici sono elencati sulle rispettive pagine di prodotto sul sito TRENDnet.

Certifications

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received. Including interference that may cause undesired operation.



Waste electrical and electronic products must not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or Retailer for recycling advice.

CAN ICES-3 (B)/NMB-3(B)

IC: ICES/NMB-006

complies with IC: ICES - 006;
en conformité avec IC: NMB - 006

Applies to PoE Products Only: This product is to be connected only to PoE networks without routing to the outside plant.

Note

The Manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Advertencia

En todos nuestros equipos se mencionan claramente las características del adaptador de alimentación necesario para su funcionamiento. El uso de un adaptador distinto al mencionado puede producir daños físicos y/o daños al equipo conectado. El adaptador de alimentación debe operar con voltaje y frecuencia de la energía eléctrica domiciliar existente en el país o zona de instalación.

Technical Support

If you have any questions regarding the product installation, please contact our Technical Support.
Toll free US/Canada: **1-866-845-3673**
Regional phone numbers available at www.trendnet.com/support

Product Warranty Registration

Please take a moment to register your product online.
Go to TRENDnet's website at: www.trendnet.com/register

TRENDnet

20675 Manhattan Place
Torrance, CA 90501
USA

TRENDnet®

Quick Installation Guide

Powerline 1300 AV2 Adapter
TPL-422E


Powerline 1300 AV2 Adapter Kit
TPL-422E2K

Hardware Installation

Requirements:

Must have existing Powerline Network.

- 1 Connect a network cable from your router to the TPL-422E's network port.



- 2 Plug the TPL-422E (included in TPL-422E2K) or other Homeplug AV powerline adapter into the power outlet.

- 3 Plug the TPL-422E into the power outlet.



- 4 Connect a network device to the TPL-422E's LAN Port.

Note: Connecting Additional Adapters:


Push the Sync button for 2 seconds on the adapter connected to the router. Then push the Sync button for 2 seconds on any new adapter to sync them to your existing Powerline network. The POWERLINE LED will turn solid when the adapters are successfully connected.

Encrypted Connection (Recommended)

NOTE: TRENDnet adapters auto-connect out of the box over a pre-encrypted Powerline signal. The following optional steps are recommended to secure your powerline network.


Existing Powerline Adapters

- 1 Press and hold the sync button on any powerline adapter for 10 seconds to generate a new encryption key. All LEDs will turn off and turn on again. Push the sync button for 2 seconds.




TPL-422E

- 2 Push the Sync button on every adapter in the powerline network for 2 seconds. The POWER LEDs will begin to blink.



TPL-422E

- 3 The POWERLINE LEDs will turn solid when both devices have successfully connected.



LED Indicators Table

LED	Color	Definition
Power	Green	Powered On
	Blinking	Synchronizing
Powerline	Green	Best connection
	Amber	Good connection
	Red	Connected
Ethernet	Green	LAN port connected