



Guia de Instalação Rápida



TU3-H4
1.01

Table of Contents

English	1
1. Antes de Iniciar	1
2. Instalação de Hardware	2
3. Verificar Instalação	3
Especificações Técnicas	4
Troubleshooting	5



Conteúdo da Embalagem

- TU3-H4
- Guia de Instalação Rápida Multilínguas
- Cabo USB 3.0 Tipo A para Tipo B (1,80 m/6ft)
- Adaptador de Tensão Externo (5 VDC, 4 A)

Requisitos de Sistema

- Porta USB: 3.0, 2.0 ou 1.1
- Cabo USB 3.0

Compatibilidade com Sistemas Operacionais	CPU	Memória
Windows 7 (32/64-bit)	1GHz ou superior	1GB RAM ou superior
Windows Vista (32/64-bit)	800MHz ou superior	512MB RAM ou superior
Windows XP (32/64-bit)	300MHz ou superior	256MB RAM ou superior

Nota:

Super velocidades USB 3.0 são baseadas em sistemas operacionais compatíveis. USB 3.0 é retroativamente compatível com USB 2.0 e funcionará em todos sistemas operacionais compatíveis.

Nota:

- 1 Para usufruir de Super Velocidade USB 3.0, seu dispositivo tem de ser Super Velocidade USB 3.0.
- 2 .Você tem de conectar o adaptador de tensão ao TU3-H4.

1. Ligue seu computador e aguarde até que a inicialização se complete.



2. Conecte o cabo USB fornecido ao Hub USB, e então à porta USB de seu computador.



3. Conecte o Adaptador de Tensão AC ao TU3-H4 e então a uma tomada elétrica.



4. Conecte um dispositivo USB a uma porta USB disponível.

Sua instalação agora está completa.


Registre Seu Produto

Para informações detalhadas sobre esta e outras configurações avançadas do TU3-S35, favor recorrer ao Guia do Usuário incluído no CD-ROM com Driver ou ao website da TRENDnet em www.trendnet.com


3. Verificar Instalação

Windows 7/ Vista

1. Clique Computer (Computador) com o botão direito e então clique Properties (Propriedades). Clique Device Manager (Gerenciador de Dispositivo).




2. Expanda "Universal Serial Bus controllers" e confirme que Generic USB Hub (Hub USB Genérico) foi instalado.




Windows XP

1. Clique My Computer (Meu Computador) com o botão direito e então clique Properties (Propriedades). Na aba Hardware, clique Device Manager (Gerenciador de Dispositivo).



2. Expanda "Universal Serial Bus controllers" e confirme que Generic USB Hub (Hub USB Genérico) foi instalado.



Hardware	
Padrões	USB 1.1/2.0/3.0
Portas USB	Entrada: 1 tipo B Saída: 4 tipo A
LED Indicadores	Portas 1 - 4 USB
Taxa de Transferência de Dados	Super velocidade: 5 Gbps (USB 3.0) Alta Velocidade : 480Mbps (USB 2.0) Velocidade Plena : 12Mbps (USB 1.1) Baixa Velocidade : 1.5Mbps (USB 1.0)
Fornecimento de Energia	Adaptador de Tensão Externo (5 VDC, 4 A)
Consumo de Energia	0.3w (máx)
Dimensões	60 x 95 x 22mm (2.3 x 3.7 x 0.8in.)
Peso	68g (2.4oz)
Temperatura	Operação: 0~55°C (32-131 °F) Armazenagem: -10~70°C (14-158 °F)
Umidade	Máx 90% (sem-condensação)
Certifications	CE, FCC

1. Eu posso conectar ou desconectar os cabos USB enquanto o computador estiver ligado?

Sim, você pode conectar ou desconectar o cabo USB enquanto o computador estiver ligado, porque a interface USB é Plug-and-Play e hot-pluggable.

2. Eu tenho um cabo USB 1.1/2.0. Ele funciona com dispositivos USB 3.0?

Sim, ele funciona mas pode causar problemas em conectando periféricos externos de alta velocidade USB 3.0. Assim, é recomendável que você utilize cabo USB 3.0 certificado.

3. Após instalar com sucesso o Hub USB 2.0 TU3-H4, eu conectei meu dispositivo USB externo à porta USB, mas ele parece não funcionar. O que devo fazer?

1. Verifique se seu dispositivo externo USB funciona se instalado diretamente a uma porta USB de seu computador.
2. Se seu dispositivo externo USB foi fornecido com um adaptador externo de tensão, conecte-o ao dispositivo e a uma tomada elétrica.
3. Certifique-se de ter instalado o driver correto para seu dispositivo USB em Windows.

4. Após conectar meu dispositivo ao Hub USB 3.0 TU3-H4, não estou obtendo velocidades USB 3.0. O que devo fazer?

1. Certifique-se de estar utilizando um cabo certificado USB 3.0.
2. Para usufruir de Super Velocidade USB 3.0, seu dispositivo tem de ser Super Velocidade USB 3.0.

5. Eu posso cascadear/empilhar dois ou mais TU3-H4 juntos para ganhar mais portas USB 3.0?

Sim, você pode cascadear/empilhar vários TU3-H4. Você pode conectar até 127 periféricos USB por vez.

Se você ainda encontrar dificuldades ou tiver quaisquer perguntas relativas ao TU3-H4 favor contactar o Departamento de Suporte Técnico da TRENDnet.

Limited Warranty

TRENDnet warrants its products against defects in material and workmanship, under normal use and service, for the following lengths of time from the date of purchase.

TU3-H4 - 3 Years Limited Warranty

AC/DC Power Adapter, Cooling Fan and Power Supply carry a 1 year limited warranty

If a product does not operate as warranted during the applicable warranty period, TRENDnet shall reserve the right, at its expense, to repair or replace the defective product or part and deliver an equivalent product or part to the customer. The repair/replacement unit's warranty continues from the original date of purchase. All products that are replaced become the property of TRENDnet. Replacement products may be new or reconditioned. TRENDnet does not issue refunds or credit. Please contact the point-of-purchase for their return policies.

TRENDnet shall not be responsible for any software, firmware, information, or memory data of customer contained in, stored on, or integrated with any products returned to TRENDnet pursuant to any warranty.

There are no user serviceable parts inside the product. Do not remove or attempt to service the product by any unauthorized service center. This warranty is voided if (i) the product has been modified or repaired by any unauthorized service center, (ii) the product was subject to accident, abuse, or improper use (iii) the product was subject to conditions more severe than those specified in the manual.

Warranty service may be obtained by contacting TRENDnet within the applicable warranty period and providing a copy of the dated proof of the purchase. Upon proper submission of required documentation a Return Material Authorization (RMA) number will be issued. An RMA number is required in order to initiate warranty service support for all TRENDnet products. Products that are sent to TRENDnet for RMA service must have the RMA number marked on the outside of return packages and sent to TRENDnet prepaid, insured and packaged appropriately for safe shipment. Customers shipping from outside of the USA and Canada are responsible for return shipping fees. Customers shipping from outside of the USA are responsible for custom charges, including but not limited to, duty, tax, and other fees.

WARRANTIES EXCLUSIVE: IF THE TRENDNET PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, THE CUSTOMER'S SOLE REMEDY SHALL BE, AT TRENDNET'S OPTION, REPAIR OR REPLACE. THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. TRENDNET NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION MAINTENANCE OR USE OF TRENDNET'S PRODUCTS.

TRENDNET SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THAT THE ALLEGED DEFECT IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY CUSTOMER'S OR ANY THIRD PERSON'S MISUSE, NEGLIGENCE, IMPROPER INSTALLATION OR TESTING, UNAUTHORIZED ATTEMPTS TO REPAIR OR MODIFY, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, OR OTHER HAZARD.

LIMITATION OF LIABILITY: TO THE FULL EXTENT ALLOWED BY LAW TRENDNET ALSO EXCLUDES FOR ITSELF AND ITS SUPPLIERS ANY LIABILITY, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF THE POSSIBILITY OF SUCH DAMAGES, AND LIMITS ITS LIABILITY TO REPAIR, REPLACEMENT, OR REFUND OF THE PURCHASE PRICE PAID, AT TRENDNET'S OPTION. THIS DISCLAIMER OF LIABILITY FOR DAMAGES WILL NOT BE AFFECTED IF ANY REMEDY PROVIDED HEREIN SHALL FAIL OF ITS ESSENTIAL PURPOSE.

Governing Law: This Limited Warranty shall be governed by the laws of the state of California.

Some TRENDnet products include software code written by third party developers. These codes are subject to the GNU General Public License ("GPL") or GNU Lesser General Public License ("LGPL").

Go to <http://www.trendnet.com/gpl> or <http://www.trendnet.com> Download section and look for the desired TRENDnet product to access to the GPL Code or LGPL Code. These codes are distributed WITHOUT WARRANTY and are subject to the copyrights of the developers. TRENDnet does not provide technical support for these codes. Please go to <http://www.gnu.org/licenses/gpl.txt> or <http://www.gnu.org/licenses/lgpl.txt> for specific terms of each license.

PWP05202009v2

Certifications

This equipment has been tested and found to comply with FCC and CE Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received. Including interference that may cause undesired operation.



Waste electrical and electronic products must not be disposed of with household waste. Please recycle where facilities exist. Check with you Local Authority or Retailer for recycling advice.



NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

ADVERTENCIA

En todos nuestros equipos se mencionan claramente las características del adaptador de alimentación necesario para su funcionamiento. El uso de un adaptador distinto al mencionado puede producir daños físicos y/o daños al equipo conectado. El adaptador de alimentación debe operar con voltaje y frecuencia de la energía eléctrica domiciliar existente en el país o zona de instalación.



Product Warranty Registration

Please take a moment to register your product online.
Go to TRENDnet's website at <http://www.trendnet.com/register>