


Firmware Upgrade Procedures

1. Save the unzipped firmware file to your PC
2. Go to the router's configuration page
Default setting
IP address: 192.168.10.1
Username and Password: admin
3. Navigate to the **Tools** section and select **Firmware**
4. Click **Browse** and select the unzipped firmware file (.bin)
5. Click the **Upgrade** button.



5. Wait until the firmware upload has process is completed. The device will reboot automatically.
6. The firmware upgrade procedure has completed.