


Firmware Upgrade Procedures

1. Save the downloaded firmware file to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
 - a. Make sure to remember the location where the extracted file will be saved.
3. Log into to the router's configuration page (default IP is 192.168.10.1)
4. Navigate to the **Toolbox** tab and select **Firmware Upgrade** option



The screenshot shows a web interface titled "Firmware Upgrade". At the top, there is a header "Firmware Upgrade". Below the header, there is a section labeled "Firmware Filename" which contains a text input field and a "Browse..." button. Below this, it states "Current firmware version is R1.06a3_0203." There is a warning message: "Note! Do not interrupt the process or power off the unit when it is being upgraded. When the process is done successfully, the unit will be restarted automatically." At the bottom of the interface, there are two buttons: "Upgrade" and "Cancel".

5. Click **Browse** and select firmware file (.bin) in the extracted file and the click **Apply** button to load
6. Wait until the firmware upload completes and the device reboots.
7. The firmware upgrade is completed.