

## Camera Firmware Upgrade Procedures

### Warning:


- Always upgrade firmware with a wired connection.
- Do not interrupt the connection while doing the firmware upgrading
- Save your configuration before firmware upgrade

### Note:


- 1) TV-IP762IC is used for procedures below.
- 2) It is necessary to perform a factory reset after the firmware upgrade. If you would like to keep your original setting, please back up your configuration first prior to upgrade the firmware as instructed at the last page.

## Firmware Upgrade


1. Download and unzip the firmware file from [http://www.trendnet.com/support/supportdetail.asp?prod=230\\_TV-IP762IC](http://www.trendnet.com/support/supportdetail.asp?prod=230_TV-IP762IC) . Save the firmware on your computer. The firmware file name ends with \*.bin.
2. Open a browser and go to your camera's IP address: to find the camera IP, using the **Install Camera Wizard** or **Setup Wizard** on the CD-ROM (default is 192.168.10.30, without a DHCP server.)




3. Enter the username & password (By default, the username & password is admin/admin, or enter the password setup by you.)




4. Under **Setup**, go to **Tools** page, then **Firmware Upgrade** option, and click **Browse** to select the new firmware file then click **Upload**. If you would like to keep your original setting, please back up your configuration prior to upgrade the firmware as instructed at the last page.




5. After Firmware upgrade completed, the camera will automatic reboot. Wait for up to 2 minutes till it completed.



6. Go to **Tool/System**, click **Reset** the reset camera to factory default.



7. After reset, click **Tool/Firmware Upgrade** tab again to verify the new firmware version. Also after reset, the user name and password would become the default admin, admin.



8. Your firmware upgrade is now completed. To find the camera IP, please use the **Install Camera Wizard** or **Setup Wizard** (can be found on the CD-ROM) to search and configure your camera again.

## 9. **Back up**

To keep your original settings prior to the firmware upgrade, please **back up** the settings.db file and save the file to your chosen folder before the firmware upgrade starts.

## **Restore**

After the firmware upgrade and factory reset completed, then **Restore** the settings.db file and your original settings will be restored.

