



## **TEW-PCIA** **PCMCIA Card Reader for PCI Bus**

TRENDnet's TEW-PCIA PCMCIA Card Reader bridges between PCMCIA card and PCI bus in the Desktop PC. With Windows 98/ME/NT4.0/2000/XP driver support, installation of this card reader is a snap. It plugs right into your PC's PCI bus slot and allows your Desktop PC to accept 8/16-bit PCMCIA Card, including SRAM Card, Modem Card, Ethernet Card, and Wireless LAN Card.



### **FEATURES**

- > Allows Desktop PC to accept PCMCIA PC Card
- > PCI Local Bus Specification Revision 2.2 Compliant
- > PCI Bus Power Management Interface Specification 1.0 Compliant
- > ACPI 1.0 Compliant
- > Card-16 Standard Specification
- > PCMCIA Type II compliant
- > 95/97 PC Card Standard Compliant
- > Driver supports Windows 98/ME/NT4.0/2000/XP
- > 5V operation
- > 5 Year Warranty



# TEW-PCIA

## PCMCIA Card Reader for PCI Bus

### SPECIFICATIONS

**Standard:**

- PCI Local Bus 2.2 compliant
- PCMCIA PC Card 95/97 PC
- Card-16 Specification

**PCI to PCMCIA Host Bridge:**

- R5C475 II

**Supporting OS:**

- Windows 98/ME/NT4.0/2000/XP

**Power Requirements:**

- 5V (PCI bus)

**Dimensions:**

- 104 x 98mm (4.1 x 3.86 inches)

**Weight:**

- Appro. 99 g. (3.5 Oz.)

**Temperature:**

- Operating: 0° ~ 70° C (32° ~ 158° F)
- Storage: -40° ~ 125° C (-40° ~ 257° F)

**Humidity:**

- 95% (no-condensing)

**Certifications:**

- FCC, CE



### PRODUCT INFORMATION

**... TEW-AP100plus**

Wireless Access Point with Built in External Dipole Antenna

**... TEW-AP100**

Wireless Access Point

**... TEW-PC16**

11Mbps Wireless LAN PCMCIA Card

**... TEW-PS3**

3-port Wireless Ethernet Print Server

**... TEW-USB**

11Mbps Wireless USB Adapter

### ORDERING INFORMATION

**TRENDware International, Inc.**

3135 Kashiwa Street

Torrance, CA. 90505. USA

Tel: 310-891-1100

Fax: 310-891-1111

Web: [www.TRENDNET.com](http://www.TRENDNET.com)

Email: [sales@trendware.com](mailto:sales@trendware.com)

**To Order Please Call:**  
**1-888-326-6061**