



# TRENDNET®



## Instrukcja Szybkiej Instalacji

**TE100-S55Eplus**  
**TE100-S88Eplus**  
**TE100-S16Eplus**

Polski .....	1
1. Przed rozpoczęciem .....	1
2. Instalacja sprzętu .....	2
Wymagania techniczne .....	3
Rozwiązywanie problemów .....	5

# 1. Przed rozpoczęciem




## Zawartość opakowania

- TE100-S55Eplus/TE100-S88Eplus/TE100-S16Eplus
- Instrukcja Szybkiej Instalacji
- Zasilacz sieciowy

## Wymagania instalacji

- Komputer z zainstalowaną kartą sieciową
- Powierzchnia powinna być w stanie unieść przynajmniej 1,5 kg wagi Switcha
- Gniazdko elektryczne powinno znajdować się w odległości 1,82 metra (6 stóp) od Switcha
- Obejrzyj wtyczkę typu jack DC, aby upewnić się, iż została ona prawidłowo podłączona do zasilacza
- Upewnij się, że odpowiednia wentylacja wokół Switcha umożliwiała prawidłowe rozproszenie ciepła
- Nie kładź ciężkich przedmiotów na Switchu

## Aplikacja



## 2. Instalacja sprzętu

1. Podłącz **Załącznik sieciowy** do urządzenia TE100- S55Eplus/ TE100-S88Eplus/ TE100-S16Eplus a następnie do gniazdka elektrycznego.



2. Połącz komputer kablem sieciowym typu CAT-5 RJ-45 z wolnym portem Ethernet urządzenia TE100-S55Eplus/TE100-S88Eplus/ TE100-S16Eplus.



Ogólne	
<b>Standardy</b>	IEEE 802.3 10BASE-T Ethernet IEEE 802.3u 100BASE-TX Fast Ethernet ANSI/IEEE 802.3 NWay Auto-negotiation IEEE 802.3x Full-Duplex Flow Control
<b>Protokół</b>	CSMA/CD
<b>Predkość Przepływu Danych</b>	Ethernet: 10Mbps (Half-Duplex), 20Mbps (Full-Duplex) Fast Ethernet: 100Mbps (Half-Duplex), 200Mbps (Full-Duplex)
<b>Topologia</b>	Star-siec typu gwiazda
<b>Kable Sieciowe</b>	Ethernet: UTP/STP CAT-3, 4, 5 Fast Ethernet: UTP/STP CAT5, 5e, 6
<b>Liżba Portów</b>	5, 8 or 16 x 10/100Mbps Auto-negotiation, Auto-MDIX ports

Wydajność	
<b>Metoda transmisji</b>	Store-and-forward
<b>Uczenie się adresów MAC</b>	TE100-S55Eplus: 1K wpisów na urządzenie TE100-S88Eplus: 1K wpisów na urządzenie TE100-S16Eplus: 8K wpisów na urządzenie
<b>Tablica Adresów MAC</b>	Aktualizacja automatyczna

## Fizyczne oraz Środowiskowe

<b>Rodzaje zasilania</b>	DC 7.5V 1A
<b>Zużycie energii</b>	TE100-S55Eplus: 2.5W (Max) TE100-S88Eplus: 2.8W (Max) TE100-S16Eplus: 6W (Max)
<b>Temperatura</b>	Działanie: 0° ~ 40° C Przechowywanie: -10° ~ 70° C
<b>Wilgotność</b>	Działanie: 10% ~ 90% Przechowywanie: 5% ~ 90%
<b>Wymiary (Dł. X Szer. X Wys.)</b>	TE100-S55Eplus: 116 x 69 x 24 mm TE100-S88Eplus: 136 x 70 x 25 mm TE100-S16Eplus: 184 x 124 x 44 mm
<b>Ciezar</b>	TE100-S55Eplus: 220g TE100-S88Eplus: 260g TE100-S16Eplus: 780g
<b>Homologacja</b>	FCC, CE

**P1: Po podłączeniu Switcha do gniazdka elektrycznego nie zapalają się diody.**

**O1:** Sprawdź połączenie zasilacza z urządzeniem TE100- S55Eplus/ TE100-S88Eplus/ TE100-S16Eplus oraz z gniazdkiem elektrycznym. Sprawdź także czy w gniazdku jest napięcie.

**P2: Kiedy podłączam komputer do portu Switcha zapala się dioda LINK/ACT, ale dioda 100Mbps nie świeci się.**

**O2:** Jeżeli dioda 100Mbps nie zapala się, oznacza to, że prędkość połączenia komputera wynosi 10Mbps.

**P3: Kiedy podłączam swój komputer PC do Switcha, nie mogę udostępnić plików.**

**O3:** Po pierwsze, sprawdź diody Switcha. Upewnij się, że pali się dioda LINK/ACT. Po drugie, sprawdź kabel sieciowy. Długość kabla powinna wynosić co najmniej 1,5 metra i nie powinna ona przekraczać 100 metrów. Po trzecie, wyłącz wszelkie programy typu software firewall. Po czwarte, upewnij się, że włączony jest program umożliwiający udostępnienie plików i drukarki. Aby uzyskać więcej informacji, prosimy o skontaktowanie się z działem pomocy firmy Microsoft.

**P4: Po podłączeniu komputerów do Switcha mogą łączyć się z Internetem tylko z jednego komputera.**

**O4:** Switch nie został zaprojektowany do udostępniania połączenia internetowego wielu komputerom. Potrzebny jest router internetowy.

Jeżeli nadal napotykaś problemy, lub masz pytania dotyczące TE100- S55Eplus/ TE100-S88Eplus/ TE100-S16Eplus, skontaktuj się z Oddziałem Pomocy Technicznej firmy TRENDnet.

## Limited Warranty

TRENDnet warrants its products against defects in material and workmanship, under normal use and service, for the following lengths of time from the date of purchase.

### **TE100-S55Epluś/TE100-S88Epluś/TE100-S16Epluś - 5-Year Warranty**

If a product does not operate as warranted above during the applicable warranty period, TRENDnet shall, at its option and expense, repair the defective product or deliver to customer an equivalent product to replace the defective item. All products that are replaced will become the property of TRENDnet. Replacement products may be new or reconditioned.

TRENDnet shall not be responsible for any software, firmware, information, or memory data of customer contained in, stored on, or integrated with any products returned to TRENDnet pursuant to any warranty.

There are no user serviceable parts inside the product. Do not remove or attempt to service the product through any unauthorized service center. This warranty is voided if (i) the product has been modified or repaired by any unauthorized service center, (ii) the product was subject to accident, abuse, or improper use (iii) the product was subject to conditions more severe than those specified in the manual.

Warranty service may be obtained by contacting TRENDnet office within the applicable warranty period for a Return Material Authorization (RMA) number, accompanied by a copy of the dated proof of the purchase. Products returned to TRENDnet must be pre-authorized by TRENDnet with RMA number marked on the outside of the package, and sent prepaid, insured and packaged appropriately for safe shipment.



WARRANTIES EXCLUSIVE: IF THE TRENDNET PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, THE CUSTOMER'S SOLE REMEDY SHALL BE, AT TRENDNET'S OPTION, REPAIR OR REPLACEMENT. THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. TRENDNET NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE OR USE OF TRENDNET'S PRODUCTS.

TRENDNET SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THAT THE ALLEGED DEFECT IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY CUSTOMER'S OR ANY THIRD PERSON'S MISUSE, NEGLIGENCE, IMPROPER INSTALLATION OR TESTING, UNAUTHORIZED ATTEMPTS TO REPAIR OR MODIFY, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, OR OTHER HAZARD.

LIMITATION OF LIABILITY: TO THE FULL EXTENT ALLOWED BY LAW TRENDNET ALSO EXCLUDES FOR ITSELF AND ITS SUPPLIERS ANY LIABILITY, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF THE POSSIBILITY OF SUCH DAMAGES, AND LIMITS ITS LIABILITY TO REPAIR, REPLACEMENT, OR REFUND OF THE PURCHASE PRICE PAID, AT TRENDNET'S OPTION. THIS DISCLAIMER OF LIABILITY FOR DAMAGES WILL NOT BE AFFECTED IF ANY REMEDY PROVIDED HEREIN SHALL FAIL OF ITS ESSENTIAL PURPOSE.

Governing Law: This Limited Warranty shall be governed by the laws of the state of California.

Note: AC/DC Power Adapter, Cooling Fan, Cables and Power Supply carry 1-Year Warranty

## Certificación

This equipment has been tested and found to comply with FCC and CE Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received. Including interference that may cause undesired operation.



Waste electrical and electronic products must not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or Retailer for recycling advice.



**NOTE:** THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

### ADVERTENCIA

En todos nuestros equipos se mencionan claramente las características del adaptador de alimentación necesario para su funcionamiento. El uso de un adaptador distinto al mencionado puede producir daños físicos y/o daños al equipo conectado. El adaptador de alimentación debe operar con voltaje y frecuencia de la energía eléctrica domiciliar existente en el país o zona de instalación.



# TRENDnet<sup>®</sup>

## TRENDnet Technical Support

### US • Canada

**Toll Free Telephone:** 1(866) 845-3673

24/7 Tech Support



### Europe (Germany • France • Italy • Spain • Switzerland • UK)

**Toll Free Telephone:** +00800 60 76 76 67

English/Espanol - 24/7

Francais/Deutsch - 11am-8pm, Monday - Friday MET

### Worldwide

**Telephone:** +(31) (0) 20 504 05 35

English/Espanol - 24/7

Francais/Deutsch - 11am-8pm, Monday - Friday MET

## Product Warranty Registration

Please take a moment to register your product online.

Go to TRENDnet's website at <http://www.trendnet.com>

## TRENDnet<sup>®</sup>

20675 Manhattan Place

Torrance, CA 90501

USA