




Lühike paigaldusjuhend 

TE 100-S5  
TE 100-S8  
V1

Eesti	1
1. Enne alustamist	1
2. Riistvara paigaldus	2
3. LED-tuled	3
Tehniline kirjeldus	4
Tõrkeotsing	5




## Pakendi sisu

- TE100-S5/TE100-S8
- Mitmekeelne lühike paigaldusjuhend
- Toiteplokk (5V DC, 800mA välistoiteplokk)

## Minimaalsed nõuded süsteemile

- Võrgukaardiga arvuti.
- Cat.5 või Cat.6 võrgukaabel.
- Pistikupesa peab olema kuni 1,82 m kaugusel switchist.
- Kontrollige visuaalselt alalisvoolu toitepistikut, et see on turvaliselt toiteploki ühendatud.
- Veenduge, et switchi ümber on sobiv soojuste hajutamine ja piisav ventilatsioon.
- Ärge paigutage switchi peale raskeid esemeid.

1. Ühendage AC toiteplokk TEG- S50g / TEG-S80g'iga ning seejärel pistikupessa.



2. Ühendage Cat.5e või Cat.5 RJ-45 network võrgukaabel arvutist TE100-S5/TE100-S8' i vabasse Etherneti porti.



Power

Roheline: Toide on sees

Ei põle: Toide on väljas



Link/ACT

Roheline (Pidev):

Ühendus pordis on 100 (Full/Half) (half/full) või 10/20(half/full)

Roheline (Vilkuv):

Ühenduses ilmneb mingi tegevus

Ei põle:

Pordis ei toimu tegevust.

	TE100-S5	TE100-S8
Standardid	IEEE 802.3 10Base-T IEEE 802.3u 100Base-TX IEEE 802.3x Flow Control	
Network Media	Ethernet: Cat. 5 up to 100m Fast Ethernet: Cat. 5, 5e, 6 up to 100m	
Andmesidekiirus	Ethernet: 10Mbps/20Mbps (Half/Full-Duplex) Fast Ethernet: 100Mbps/200Mbps (Half/Full-Duplex)	
Switch Fabric	1.0Gbps edastusmaht	1.6Gbps edastusmaht
Topoloogia	CSMA/CD / tähtvõrk	
Kasutajaliides	5 x 10/100 Auto-MDIX RJ-45 pordid	8 x 10/100 Auto-MDIX RJ-45 pordid
Filteerimise tabel	2K entries per device	
Buffer Memory	384Kbits per device	512Kbits per device
Energia tarbimine	2.8 W (max)	4.5 W (max)
Diagnostilised LED-tuled	Power, Link/ACT	
Toiteplokk	5V DC 800mA välis-toiteplokk	
Mõõtmed	100 x 78 x 31mm (3.9 x 3 x 1.2 inches)	154 x 110 x 33mm (6 x 4.3 x 1.3 inches)
Kaal	128g (4.5oz.)	225g (8oz.)
Temperatuur	0° ~ 50° C (32° ~ 122° F)	
Niiskus	Max. 90% (non-condensing)	
Sertifikaadid	CE, FCC	

1. Pärast Switchi lülitamist pistikupesasse ei hakka LED-tuled põlema.
  1. Kontrollige ühendust TE100-S5 / TE100-S8 ja vooluallikaga.
  2. Kontrollige, et seinapesas oleks voolu.
2. Kui ma olen ühendanud oma PC switchiga, ei saa ma jagada oma faile.
  1. Vaadake switchil LEDe. Veenduge, et Link / ACT LED põlevad.
  2. Kontrollige võrgu kaablit. Minimaalne kaabli pikkus on 1,5 meetrit ja pikim kaabel on 100 meetrit.
  3. Kolmandaks blokeeri tarkvara tule müüri programm.
  4. Veenduge, et Teil on lubatud failide jagamine. Täiendava informatsiooni saamiseks pöörduge, palun, oma süsteemiadministraatori poole.
3. Pärast arvuti ühendamist Switchiga saan ma Internetti kasutada ainult ühes arvutis.

See switch ei ole loodud internetti jagama mitme arvuti vahel. Soovitame Teil endale soetada internetiruuter nagu näiteks TW100-S4W1CA.
4. Kus asub switchi uplink port?

Kuna kõik switchi pordid on Auto-MDIX, võib kõiki porte kasutada uplink portidena.

Kui Teil endiselt esineb probleeme või on küsimusi TE100-S5/TE100-S8 kohta, palun võtke ühendust TRENDneti tehnilise toe osakonnaga

## Limited Warranty

TRENDnet warrants its products against defects in material and workmanship, under normal use and service, for the following lengths of time from the date of purchase.

### TE100-S5/TE100-S8 - 3 Years Limited Warranty

AC/DC Power Adapter, Cooling Fan and Power Supply carry a 1 year limited warranty

If a product does not operate as warranted during the applicable warranty period, TRENDnet shall reserve the right, at its expense, to repair or replace the defective product or part and deliver an equivalent product or part to the customer. The repair/replacement unit's warranty continues from the original date of purchase. All products that are replaced become the property of TRENDnet. Replacement products may be new or reconditioned. TRENDnet does not issue refunds or credit. Please contact the point-of-purchase for their return policies.

TRENDnet shall not be responsible for any software, firmware, information, or memory data of customer contained in, stored on, or integrated with any products returned to TRENDnet pursuant to any warranty.

There are no user serviceable parts inside the product. Do not remove or attempt to service the product by any unauthorized service center. This warranty is voided if (i) the product has been modified or repaired by any unauthorized service center, (ii) the product was subject to accident, abuse, or improper use (iii) the product was subject to conditions more severe than those specified in the manual.

Warranty service may be obtained by contacting TRENDnet within the applicable warranty period and providing a copy of the dated proof of the purchase. Upon proper submission of required documentation a Return Material Authorization (RMA) number will be issued. An RMA number is required in order to initiate warranty service support for all TRENDnet products. Products that are sent to TRENDnet for RMA service must have the RMA number marked on the outside of return packages and sent to TRENDnet prepaid, insured and packaged appropriately for safe shipment. Customers shipping from outside of the USA and Canada are responsible for return shipping fees. Customers shipping from outside of the USA are responsible for custom charges, including but not limited to, duty, tax, and other fees.



WARRANTIES EXCLUSIVE: IF THE TRENDNET PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, THE CUSTOMER'S SOLE REMEDY SHALL BE, AT TRENDNET'S OPTION, REPAIR OR REPLACE. THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. TRENDNET NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION MAINTENANCE OR USE OF TRENDNET'S PRODUCTS.

TRENDNET SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THAT THE ALLEGED DEFECT IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY CUSTOMER'S OR ANY THIRD PERSON'S MISUSE, NEGLIGENCE, IMPROPER INSTALLATION OR TESTING, UNAUTHORIZED ATTEMPTS TO REPAIR OR MODIFY, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, OR OTHER HAZARD.

LIMITATION OF LIABILITY: TO THE FULL EXTENT ALLOWED BY LAW TRENDNET ALSO EXCLUDES FOR ITSELF AND ITS SUPPLIERS ANY LIABILITY, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATE, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF THE POSSIBILITY OF SUCH DAMAGES, AND LIMITS ITS LIABILITY TO REPAIR, REPLACEMENT, OR REFUND OF THE PURCHASE PRICE PAID, AT TRENDNET'S OPTION. THIS DISCLAIMER OF LIABILITY FOR DAMAGES WILL NOT BE AFFECTED IF ANY REMEDY PROVIDED HEREIN SHALL FAIL OF ITS ESSENTIAL PURPOSE.

Governing Law: This Limited Warranty shall be governed by the laws of the state of California.

Some TRENDnet products include software code written by third party developers. These codes are subject to the GNU General Public License ("GPL") or GNU Lesser General Public License ("LGPL").

Go to <http://www.trendnet.com/gpl> or <http://www.trendnet.com> Download section and look for the desired TRENDnet product to access to the GPL Code or LGPL Code. These codes are distributed WITHOUT WARRANTY and are subject to the copyrights of the developers. TRENDnet does not provide technical support for these codes. Please go to <http://www.gnu.org/licenses/gpl.txt> or <http://www.gnu.org/licenses/lgpl.txt> for specific terms of each license.

PWP05202009v2

Sertifikaadid:

Seade on testitud ning vastab FCC ja CE reeglitele.

Seade vastab järgmistele tingimustele:

(1) Seade ei tohi põhjustada ohtlikke häireid.

(2) Seade peab võtma vastu kõiki signaale, sealhulgas signaale, mis võivad põhjustada soovimatuid häireid seadme töös.



Elektri- ja elektroonikatoodete jäätmeid ei tohi ära visata koos olmejäätkeidega. Abivahendite olemasolu korral palume ümbertöötlemiseks sorteerida. Jäätmete ümbertöötlemise kohta küsige nõu oma kohalikul jaemuujalt.



**MÄRKUS:** TOOTJA EI VASTUTA ÜHEGI TV VÕI RAADIO HÄIRE EEST, MIS ON PÕHJUSTATUD SEADME LUBAMATUST ÜMBEREHITAMISEST. IGASUGUNE ÜBERMODIFITSEERIMINE TÜHISTAB AUTORIVASTUTUSE SEADMELE.



## Product Warranty Registration

Please take a moment to register your product online.  
Go to TRENDnet's website at <http://www.trendnet.com/register>