

Firmware Upgrade Procedures

1. Save the downloaded firmware file to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
 - a. Make sure to remember the location where the extracted file will be saved.
3. Log into to the router's configuration page (default IP is 192.168.10.1)
4. Click on the **Maintenance** and click on **FW Upgrade**.
5. Depending on your web browser, in the **Upload Firmware** section, click **Browse** or **Choose File**.

Upgrade Firmware	
Current Firmware Version	V1.00.B12
Upgrade Firmware	<input type="button" value="Browse..."/> No file selected.
<input type="button" value="Apply"/>	

6. Navigate to the folder on your computer where the unzipped firmware file (.bin) is located and select it.
7. Click **Apply**. If prompted, click **Yes** or **OK**. Wait until the firmware upload completed and the device reboots.
8. To finalize the firmware update process you must reset the TEW-721BRM to factory default settings.
10. Log back into the TEW-721BRM, click on the **Maintenance** section. Under Restore Factory default click on **Restore**.

Note: You will need to reconfigure and access the router's management page using the predefined settings found on the top or bottom labels.