


## Firmware Upgrade Procedure

1. Save the downloaded firmware file to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
  - a. Make sure to remember the location where the extracted file will be saved.
3. Log into to the router's configuration page (default IP is 192.168.10.100).

**Note:** *If you purchased the TEW-740APBO2K, default IP for one unit is 192.168.10.50 and the other unit default IP is 192.168.10.51 which can be found on the MAC address label inside cover where Ethernet ports are located.*
4. Click on **Utility** and click on **System Upgrade**.
5. Next to **Upgrade Via Local PC**, click **Browse** or **Choose File** and navigate directories to select where the extracted firmware file is located (filename: webimg\_TEW-740APBO or webimg\_TEW-740APBO2K). Once the firmware file is selected, click **Upload**.



6. Wait until the firmware upload completed and the device reboots.
7. The firmware upgrade is completed.

### **Please note the following:**

- Do not interrupt the firmware upgrade process. Do not turn off the device or press the Reset button during the upgrade.
- If you are upgrade the firmware using a laptop computer, ensure that the laptop is connected to a power source or ensure that the battery is fully charged.
- Disable sleep mode on your computer as this may interrupt the firmware upgrade process.
- Do not upgrade the firmware using a wireless connection, only using a wired network connection.
- Any interruptions during the firmware upgrade process may permanently damage your router.