

Firmware Upgrade Procedures

1. Save the downloaded firmware file to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
 - a. Make sure to remember the location where the extracted file is saved will be saved.
3. Log into your router management page (default is 192.168.10.1).
4. Click on **Tools** and click on **Firmware**.
5. Depending on your web browser, next to **Upgrade Firmware**, click **Browse**.

Upgrade Firmware	
Location:	<input type="button" value="Browse..."/> No file selected

6. Navigate to the folder on your computer where the unzipped firmware file (*.bin*) is located and select it.
7. Click **Upgrade**.
8. Wait until the firmware upload completed and the device reboot.
9. To finalize the firmware update process you must reset the TEW-810DR to factory default settings. Click the Restore button located on the **Advanced > Administrator > Settings Management** and click **Load Default** button in **Load Factory Default** section.

Load Factory Defaults	
Load Default	<input type="button" value="Load Default"/>

10. Once the TEW-810DR is reset back to factory settings you will need to reconfigure the unit.