


Firmware Upgrade Procedure

1. Save the downloaded firmware file (.zip) to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
 - a. Make sure to remember the location where the extracted file will be saved.
3. Log into to the router's configuration page (default URL: default IP address <http://192.168.10.1>)
4. Navigate to the **Management** section and click on **Upgrade Firmware**.



5. Click **Browse** (or **Choose File**) and select the firmware file (.bin) from the extracted files and click the **Apply** button to start the firmware upgrade process.
6. Wait until the firmware upload has completed and the device reboots.
7. The firmware upgrade is complete.