

## Firmware Upgrade Procedure

1. Save the downloaded firmware file (.zip) to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
  - a. Make sure to remember the location where the extracted file will be saved.
3. Log into to the switch configuration page  
Default URL/IP address <http://192.168.10.200>  
Default User Name: admin      Default Password: admin
4. Navigate to the **Tools** section, click on **Firmware Upgrade** and select the Upgrade Mode **via HTTP Settings** option.
5. Click **Choose File** or **Browse** and navigate to the location of the firmware file (.hex) extension.
6. After selecting the file, click **Upgrade** at the top right to start the upgrade process and wait for the timer to complete.

### Firmware Upgrade

Image Select	
Next Boot Image ID	<input checked="" type="radio"/> Image1 <input type="radio"/> Image2
Running Image ID	Image1
Image1 Version	
Image2 Version	3.01.027
Upgrade Mode	Via HTTP Settings ▼
<input type="button" value="Apply"/>	
Via HTTP Settings	
Firmware File	<input type="button" value="Choose File"/> TRENDNET....002-FW.hex
Firmware Backup	Image1 ▼
<input type="button" value="Backup"/> <input type="button" value="Upgrade"/>	
Note: System will not reset automatically after burning image to flash.	

7. Wait until the firmware upload has completed and the device reboots.
8. The firmware upgrade is complete.