



## Firmware Upgrade Procedure

1. Save the downloaded firmware file (.zip) to your PC
2. Right click on the downloaded file and select **Extract All** or **Extract Here** option
  - a. Make sure to remember the location where the extracted file will be saved.
3. Log into to the switch configuration page  
Default URL/IP address <http://192.168.10.200>  
Default User Name: admin      Default Password: admin
4. Navigate to the **Tools** section, click on **Firmware Upgrade** and select the **via HTTP** option.
5. Click **Upgrade** and wait for the timer to complete.



6. At the Firmware Upgrade page, click **Browse** and select firmware file (.bin) from the extracted files and click the **Upgrade** button to start the firmware upgrade process.



7. Wait until the firmware upload has completed and the device reboots.
8. The firmware upgrade is complete.