


Step 1: Download and Install the **Camera Utility** located here:

www.trendnet.com/camerautility

The file is in a compressed format. Unzip the file and install the utility.

Step 2: Run the utility, select the camera to reset, then click the **Forgot Password** button.



Step 3: Click on the **Export** button.

Reset Password X

1 Step 1: Click Export to download the key request file (XML file) or take a photo of the QR code. Send the XML file or QR code photo to our technical engineers.

Export

2 Step 2: Input the key or import the key file received from the technical engineer to reset the password for the device.


Import File

New Password:


Confirm Password:

Confirm **Cancel**

Step 4: Select your **Desktop** then click the **Select Folder** button.




Step 5: Locate the file saved to your desktop and email it to ipcam@trendnet.com to request a password reset.



Uploading encrypted file

You will be emailed an encrypted file that will allow you to reset the password. Copy this file to your desktop. Run the utility again, select the camera and click the **Forgot Password** button.



On the Reset Password page, click the **Browse** button. Locate and select the file on your desktop. Enter the new password, confirm the password, and then click the **Confirm** button.

Reset Password X

1 Step 1: Click Export to download the key request file (XML file) or take a photo of the QR code. Send the XML file or QR code photo to our technical engineers.

2 Step 2: Input the key or import the key file received from the technical engineer to reset the password for the device.

Import File



 New Password:
Strong 

 Confirm Password:



Your password will now be reset to the new password you entered.

