



Quick Installation Guide TV-IP312PI (V1)

Table of Content

1 English

- 1. Before You Start
- 2. Hardware Installation and Configuration

1. Before You Start

Package Contents

- TV-IP312PI
- CD-ROM (Utility and User's Guide)
- Quick Installation Guide
- Mounting kit

Minimum Requirements

- Power over Ethernet (PoE) switch (e.g. TPE-S50) or PoE Injector (e.g. TPE-113GI)
- A networked computer and web browser
- Wired network
- Network cable

<u>Note</u>: The TV-IP312PI only works with Power over Ethernet (PoE) devices that follow the IEEE 802.3af standard.

Free Mobile App: TRENDnet IPView Requirements

Supported Operating Systems

Android (version 2.3.3 or above) iOS (version 5.1.1 or above)

1

2. Hardware Installation and Configuration

Note: You can also download the utility at http://www.trendnet.com/support/TV-IP312PI.

- 1. Do not install or mount the IP camera until after you complete the installation steps below. Temporarily place the IP camera next to your computer.
- 2. Insert the Utility CD-ROM into your CD-ROM drive.

TRENDNET	Select your language English 🔽	
TV4P310PI/ TV4P312PI	Instal Camera Utility Install TRENDnetVIEW Pro Software Guick Installation Guide User's Guide Product Registration	Install Camera Utility

3. Click Install Camera Utility.

Camera Utility - InstallShield Wizard	-		×
Preparing Setup Please wait while the InstallShield Wizard prepares the setup.		2	
Camera Utility Setup is preparing the InstallShield Wizard, which will guide yo of the setup process. Please wait.	u through	the res	t
	-		Ľ,
InstallShield			
		Cancel	

ENGLISH

ITALIANC

4. Run the utility and you will see your camera is set to Inactive under security.

	- 1							-	Refuesh	I Medly Network P	N SMARTHER
ioni number of an	re cenises: I						6	501	Tefresh		
110 -100	in type 11	owery 1.2	vi Address 🛛	iot 1	tricro Version II	NH KATAN I	PoN HILH	Unice Lenia	1.46	Emble DHCP	
015 19	9475491 21	noctvo 1	0.4644624	9000 W	-249.4H 1982-			W495.89	95135050348	Device Sector No.:	
										12 Ackinsor	
										999	
									- 1	Submet Meale	
										Galantay	
										Pvi Address	
										IP10 Gaberayi	
										39x6 Poefa Langers	
										HTTP PLAT	
										Adres Recoverds	
										-	Modily

After the utility is done scanning. Click on the IP address section of the camera you would like to access.

	+ Unite type	Locusty	1 Jul Address	Fort	Settiers Version	Ind latency	HIIF ANT	Unice Lenal No.	Exable DECP	
310 E	19 0/2231	inactive	192,168,10	5000	V524948 192+		10	W491.8595050700W	Device Serial No.:	
									D Ackinsor	
									909	
									Submet Meak	
									Outersay.	
									Pv5 Address	
									IPs6 Gaberray	
									3956 Poefia Langen	
									HTTP PLAT	
									Admin Paccentels	

Once you get to the login page you will be prompted to change the password. Please follow the password requirements and enter your new password.

TRENDNET	Indoor / Outdoor 3 MP HD PoE IR Network Camera TV-IP312PI
Activation	
User Name	admin
Password	
	Parameter much be between 0 and 16 between $(a \ge b + z \le 0.91, (0.95))$
Confirm	
	Please do not use original password OK
Copyright () 2017 TRENDnet. All Rights Reserve	d. 🛐 Product Warranty Registration

Once you login the camera will prompt you for a password change. Please change the default password.

Please enter your new administrator password			
User Name	admin		
Password			
Confirm			
	ОК		


- Now you can access the camera's configuration page for Live view and additional settings. For more details, please refer to the User's Guide.
- 9. Scan the QR code below to download a free mobile app to view the camera from your IOS or Android device. Please refer to the quick install guide for instructions on how to setup your camera in the app from your cameras download page at www.TRENDnet.com.





Android

iOS




- Connect the provided network cable from the Power over Ethernet switch (e.g. TPE-S50) to the network port on the IP Camera.
- Connect the switch to your network.

Mounting the camera

Note: For tips on capturing appropriate camera viewing angle, please refer to the user's guide.

1. Loosen the adjustable nut and manually position the camera as desire.




2. Place the provided template label on the wall or ceiling.




- 3. Drill holes at each marked position on the template. Make sure the drill bit matches the size of the holes on the template.
- 4. Insert the provided screw anchors into the holes.
- 5. Insert the cables through the hole in the wall or ceiling.

6. Align the mounting bracket with the screw anchors, and then use the provided screws to secure the camera to the mounting surface.



7. Manually adjust the zoom and focus. Using the free app, confirm the zoom and focus matches installation requirements.



8. Refer to User's Guide for more details on installation and configuration.

Declaration of Conformity

Manufacturer's Name and Address TRENDnet, Inc. 20675 Manhattan Place Torrance, CA 90501 USA

Zwolsestraat 156 2587 WB The Hague The Netherlands

CE

Product Information

 Model Number:
 TV-IP312PI

 Product Name:
 Indoor/Outdoor 3MP HD PoE IR Network Camera

 Trade Name:
 TRENDnet

TRENDnet hereby declare that the product is in compliance with the essential requirements and other relevant provisions under our sole responsibility.

EMC

EN 55022: 2010 + AC: 2011 Class A EN 61000-3-2: 2006 + A1: 2009 + A2: 2009 EN 61000-3-3: 2008 EN 50130-4: 2011 + A1: 2014

This product is herewith confirmed to comply with the Directives.

Directives:

Directive LVD 2014/35/EU Directive EMC 2014/30/EU Directive RoHS 2011/65/UE REACH Réglement (CE) N° 1907/2006

Person responsible for this declaration.

Place of Issue: Torrance, California, USA

Name: Sonny Su

Signature:

J-yd-

Date: January 05, 2017

Title: Director of Technology

TRENDNET

TRENDNET

Certifications

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received. Including interference that may cause undesired operation.

CE



Waste electrical an electronic products must not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or Retailer for recycling advice. Applies to PoE Products Only: This product is to be connected only to PoE networks without routing to the outside plant.

Note

The Manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Advertencia

En todos nuestros equipos se mencionan claramente las características del adaptador de alimentacón necesario para su funcionamiento. El uso de un adaptador distinto al mencionado puede producir daños físicos y/o daños al equipo conectado. El adaptador de alimentación debe operar con voltaje y frecuencia de la energía electrica domiciliaria exitente en el país o zona de instalación.

Technical Support

If you have any questions regarding the product installation, please contact our Technical Support. Toll free US/Canada: **1-866-845-3673** Regional phone numbers available at www.trendnet.com/support

TRENDnet

20675 Manhattan Place Torrance, CA 90501 USA

Product Warranty Registration

Please take a moment to register your product online. Go to TRENDnet's website at: www.trendnet.com/register