


## Firmware Upgrade Procedure


### Please note the following:

- Do not interrupt the firmware upgrade process. Do not turn off the device or press the Reset button during the upgrade.
- If you are upgrade the firmware using a laptop computer, ensure that the laptop is connected to a power source or ensure that the battery is fully charged.
- Disable sleep mode on your computer as this may interrupt the firmware upgrade process.
- Do not upgrade the firmware using a wireless connection, only using a wired network connection.
- Any interruptions during the firmware upgrade process may permanently damage your router.


1. Save the unzipped firmware file to your PC
2. Go to router's configuration page (default IP is [192.168.10.1](http://192.168.10.1))
3. 2. Click on **Configuration** at the top of the page, click on **Toolbox**, and click on **Firmware/Restore Setting**.



4. Under **Firmware/Configuration Filename**, depending on your web browser, click on **Browse** or **Choose File**.



5. A separate file navigation window should open.
6. Navigate to the folder on your computer where the unzipped firmware file (.bin) is located and select it.
7. Click **Upgrade**. If prompted, click **Yes** or **OK**. (Default Filename: <firmwarefilename>.bin).



8. Wait for the router to complete the firmware upgrade process and reboot.

**Important!** Do not turn off the device or press the reset button while this procedure is in progress.