


Installation

Note:

Android must be version 2.3 or higher.


1



Tap on the **Play Store** icon to download and install TRENDnet CloudView app. Once installed, tap the **TRENDnet CloudView** icon to open up the app.

Remote Camera Setup

1



- Tap the **Manually Add Camera** icon at the upper right corner of the screen.

2



- Tap the **Name** field. Enter a suitable camera name of your choice.

3




- Tap the **ID** field. Enter your cloud camera's 8 digit ID. The ID is located on a sticker on your camera.

4




• Tap the Username field. Enter the cloud camera's username . This is the username that you configured during the cloud camera setup.

5



• Tap the Password field. Enter your camera's password and then tap the Save icon. This is the password that you configured during the cloud camera setup.


6



• After the camera has been added, CloudView will return to the Camera List screen. Repeat steps 1-5 to add more cameras.

View Video

1



- Tap the desired **Camera**.

2



- Video will appear in portrait mode. The function toolbar will be located below the video.

3



- Rotate your Android device horizontally to view the video in landscape mode.

4




- Pinch the screen to zoom in and zoom out.

5



- In landscape mode, tap the screen to bring up the function toolbar.

6




- Above is the function toolbar. Buttons include: pan and tilt, snapshot, enable/disable microphone, enable/disable speaker, resolution, settings (profile and audio), refresh and information. If the button is greyed out, the IP camera does not support that function.

Local Camera Setup

Note:

- Before proceeding, you must establish a wireless connection to the network where your IP cameras are installed.
- This method will not allow you to see video while away from your local network. Remote camera setup is recommended.

1




• Tap the **Scan Camera** icon at the upper left corner of the screen.

2




• Tap the desired camera and then click the add icon

3



• Enter the camera's Username and Password and then tap **OK**.

4




• After the selected camera has been added, CloudView will return to the Camera List screen. Repeat steps 1-3 to add more cameras.

Wireless Configuration (Optional)

Note:

- Before proceeding, you must establish a wireless connection to the network where your IP cameras are installed.



1

Camera List


- Tap the **Scan Camera** icon at the upper left corner of the screen.



2

Scan Camera

- Tap the wireless icon next to the desired cameras.



3

Login

Name: TV-IP512C

Username: admin

Password:

OK Cancel


1 2 3 4 5 6 7 8 9 0

! @ # \$ % & + ? /

* . ' () - = < >

ABC 1/2 ; , ' " ' " ' " ' " ' " ' "

- Enter the camera's Username and Password and then tap **OK**.



4

Wireless Setting

Name: TV-IP512C

SSID: TRENDnet658

Key:

AP List

TRENDnet658

TRENDnet

TRENDnet

1 2 3 4 5 6 7 8 9 0

! @ # \$ % & + ? /

* . ' () - = < >

ABC 1/2 ; , ' " ' " ' " ' " ' "

- Select the desired SSID from the AP list, enter the Key and then click the Save icon.

Technical Support

If you have any questions regarding the product installation, please contact our Technical Support.

Toll free US/Canada: 1-866-845-3673

Regional phone numbers available
at www.trendnet.com/support

Product Warranty Registration

Please take a moment to register your product online. Go to TRENDnet's website at:

<http://www.trendnet.com/register>

TRENDnet

20675 Manhattan Place, Torrance, CA 90501, USA

Copyright © 2013. All Rights Reserved. TRENDnet.