TEW-444UB

108Mbps 802.11g Wireless USB 2.0 Adapter
Quick Installation Guide

Adaptateur USB 2.0 sans fil 108Mbps 802.11g
Guide d'installation rapide

Drahtloser 108 MBit/s 802.11g USB-2.0-Adapter
Kurzanleitung zur Installation

Adaptador USB 2.0 inalámbrico 802.11g a 108Mbps
Guía de instalación rápida

Адаптер 108 Мбит/сек 802.11g USB 2.0 для беспроводных соединений
Руководство по быстрой установке

Version 06.16.2005

TRENDnet®

TRENDware, USA
What's Next in Networking

Table of Contents

English QIG
1. Prepare for Installation

Thank you for purchasing the TEW-444UB. Your new 108Mbps 802.11g Wireless USB 2.0 Adapter will allow you to connect to 802.11g or 802.11b networks and begin wirelessly sharing the Internet, files, and other resources.

This guide will help you set up and configure your Wireless USB Adapter. Following this installation should be quick and easy. If you run into problems, please refer to the Troubleshooting section or the more detailed installation procedures on the User's Guide CD-ROM. If you need further technical support, please visit www.TRENDNET.com or call technical support by phone.

Verify Package Contents

Please make sure you have everything in the box:

TEW-444UB

Quick Installation Guide

USB Extension Cable

Driver & Utility CD-ROM

Minimum Hardware Requirements

Before installing this 802.11g Wireless USB Adapter, you should have:
1. USB enabled computer
2. 300 MHz processor and 32 MB of memory (Recommended)
3. CD-ROM drive
4. 802.11g or 802.11b Access Point (for Infrastructure Mode) or another 802.11g wireless adapter (for Ad-Hoc/Peer-to-Peer networking mode).
5. Windows 98SE/ME/2000/XP

Note: Do not connect the Wireless USB Adapter to your computer until you have finished installing the Utility and Driver.

The TEW-444UB is hot-pluggable. You can connect or disconnect the TEW-444UB while the computer is on.

Connect the TEW-444UB Wireless USB Adapter to your computer's USB port.

Note: You can use the included USB extension cable for your convenience to extend the cable connection between your computer and the TEW-444UB.

Windows 98SE/ME/2000/XP

1. Insert the TEW-444UB CD-ROM into your computer's CD-ROM drive; the installation menu window will appear automatically. If the window does not appear automatically, click **Start**, click **Run**, and type **E:\Autorun.exe** in the text-field. Click **OK**.

> **Note:** Replace "E" in "E:\Autorun.exe" with whichever letter is assigned to your CD-ROM drive.

**2.** On the Installation Menu, click **Install Utility**.

3. Follow the Install Shield Wizard's instructions to install the wireless configuration utility.

4. Click **Next**.

5. Click **Next**.

6. Click **Install.**

7. Click **Finish.**

8. On the Installation Menu, click **Exit**.

> **Note:** For Windows 98/ME, manually restart your computer.

4. Install Drivers

Windows 98SE/ME/2000/XP

1. After installing the utility software, connect the Wireless USB Adapter to your computer's USB port. Windows will detect new hardware and load the driver automatically.

> Congratulations!
> Installation is now complete.

Note: After driver installation is complete, the wireless icon will appear in your system tray (next to the clock on the bottom right corner of your screen). If it does not appear, restart your computer. **Go to section 5 Wireless Configuration.**

5. Wireless Configuration

1. Double click the wireless icon on your desktop.

802.11g
Wireless Client
Utility

2. Click **Profile Management** and click **Scan**.

3. Select your wireless network's **SSID** and click **Activate**.

4. Type a **Profile Name** for the Access Point you selected and click **OK**.

Troubleshooting

Q1: I completed all the steps in the quick installation guide, but my wireless USB Adapter isn't connecting to my access point. What should I do?

A1: First, you should verify that the Network SSID matches your wireless router or access point's SSID. Second, you should check your TCP/IP properties to ensure that Obtain an IP address automatically is selected. Third, you can click on the Site Survey link to check and see if there are any available wireless networks listed.

Q2: Windows is unable to recognize my hardware. What should I do?

A2: Make sure your computer meets the minimum requirements as specified in Section 1 of this quick installation guide. Also, you must install the wireless c onfiguration utility (as described in Section 3) before connecting the wireless USB Adapter.

Q3: I cannot open the wireless configuration utility. What should I do?

A3: Go to your device manager (control panel ➔ system) to make sure the adapter is installed properly. If you see a networking device with a yellow question mark or exclamation point, you will need to reinstall the device and/or the drivers.

If you still encounter problems, please refer to the User's Guide CD-ROM or contact technical support.

Certifications

This equipment has been tested and found to comply with FCC and CE Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.
(2) This device must accept any interference received.
Including interference that may cause undesired operation.

FC CE

TRENDnet

TRENDware, USA

What's Next in Networking

Product Warranty Registration

Please take a moment to register your product online.
Go to TRENDware's website at http://www.TRENDNET.com

TRENDnet Technical Support

US/Canada Support Center	European Support Center

Contact
   Telephone: 1(310) 626-6252
   Fax: 1(310) 626-6267
   Email: support@trendnet.com
 	
Tech Support Hours
   7:30am - 6:00pm Pacific Standard Time
   Monday - Friday
	Contact
	   Telephone
	      Deutsch **:** +49 (0) 6331 / 268-460
	      Français **:** +49 (0) 6331 / 268-461
	      Español **:** +49 (0) 6331 / 268-462
	      English **:** +49 (0) 6331 / 268-463
	      Italiano **:** +49 (0) 6331 / 268-464
	      Dutch **:** +49 (0) 6331 / 268-465
	      Fax: +49 (0) 6331 / 268-466
	
	Tech Support Hours
	   8:00am - 6:00pm Middle European Time
	   Monday - Friday

TRENDware International, Inc.
3135 Kashiwa Street**.** Torrance, CA 90505
http://www.TRENDNET.com