TRENDnet®

TC-K25C6 / TC-K50C6

Cat6 Keystone Jack

Quick Installation Guide

1. Strip approximately 30mm (1.2 in.) of jacket from the twisted pair cable.



2. Insert the twisted wire pairs into the termination cap and position each wire appropriately into the color labeled slots. Cut excess wires.



3. Clip the termination cap onto the keystone jack hinge.



4. Press the termination cap down until flush with the keystone jack. Ensure each wire is firmly anchored in each slot.



5. Feed the included cable tie through the cable fixture hole and tighten to secure the termination cap and keystone jack together.



Unloading the cable

1. Cut the cable tie.



2. Using a flathead screwdriver, gently pry each side of the termination cap until released.



T568B Pinout

1. White Orange	4. White Blue
2. Orange	5. Green
3. White Green	7. White Brown
6. Blue	8. Brown

c UL us LISTED
COMMUNICATION CIRCUIT ACCESSORIES
YOUR
E135643
XYK-ITP

RoHS Compliant