

Table of Contents

English	1
1. Before You Start	1
2. Hardware Installation	2
3. Accessing Storage Devices on TU3-S25	4
Troubleshooting	5

Version	06 1	7 201	ſ

Package Contents

- TU3-S25
- Multi-Language Quick Installation Guide
- CD-ROM (User's Guide)
- USB 3.0 Type A to micro B Cable (0.9m/3ft)
- Hard drive mouting screws

System Requirements

- USB 3.0 / 2.0 / 1.1 port
- 2.5" SATA I/II Internal Hard Drive
- CD-ROM Drive

Supported Operating Systems	CPU	Memory
Windows 7 (32/64-bit)	1GHz or above	1GB RAM or above
Windows Vista (32/64-bit)	800MHz or above	512MB RAM or above
Windows XP (32/64-bit) / 2000 / ME / 98SE	300MHz or above	256MB RAM or above
Mac OS X (10.6)	Intel Processor	1GB RAM or above
Mac OS X (10.5)	867MHz or above	512MB RAM or above
Mac OS X (10.4)	333MHz or above	256MB RAM or above
Mac OS X (10.1-10.3)	300MHz or above	256MB RAM or above

Note:

- 1. Hard Drive is NOT included.
- 2. Some operating systems do not support USB 3.0.

2. Hardware Installation





Note:

It is recommended that you format a brand new hard drive first. Please refer to question 2 in the troubleshooting section for more information.

Your Installation is complete.

Note: For Windows 2000, ME, 98SE and Mac OS X (10.1~10.6), please refer to the user guide on the User Guide CD-ROM.

Windows 7/Vista/XP



Your Configuration is complete

For detailed information regarding the TU3-S25 configuration and advanced settings, please refer to the Troubleshooting section, User's Guide on the CD-ROM, or TRENDnet's website at http://www.trendnet.com.

Register Your Product

To ensure the highest level of customer service and support, please take a moment to register your product Online at: www.trendnet.com/register

Thank you for choosing TRENDnet

- 1. My computer does not recognize the TU3-S25. What should I do?
 - 1. Verify that the computer meets the minimum requirements as listed in section 1.
 - 2. Try plugging the device into a different USB port on your computer.
- 2. How do I format my brand new hard drive?
 - 1. For Windows 7/Vista, right click on Computer on the Desktop and select Manage. When the Computer Management screen appears, click on Disk Management. Right click on the hard drive and click New Simple Volume. Follow the New Simple Volume wizard and then click Finish.
 - 2. For Windows XP, go to Start -> Settings -> Control Panel -> Administrative Tools -> Computer Management -> Disk Management. If the Initialize and Convert Disk Wizard appears, click Cancel. Right click the Unknown drive, click Initialize and then click OK. Right click on the unallocated region of the hard drive and select New Partition. Follow the New Partition Wizard instructions then click Finish. The hard drive will automatically start the formatting process.

Note:

- 1. Make sure that the selected hard drive is connected to the TU3-S25.
- 2. Make sure that the selected hard drive is not your primary (active) hard drive. Your primary (active) hard drive is usually your C: drive.
- 3. My computer does not list any drives? What should I do?
 - Verify that the device is installed properly. On Windows 7/Vista, right click on Computer, select properties and then click Device Manager. Click on Disk Drives and verify that USB 3.0 MassStorage USB Device is listed. On Windows XP, right click on My Computer click Properties. Click on Hardware and then Device Manager. Double click on Disk Drives and verify that USB 3.0 MassStorage USB Device is listed.
 - 2. If you are attaching a brand new hard drive, format the drive. Please refer to question 2 for more information.

If you still encounter problems or have any questions regarding the TU3-S25, please contact TRENDnet's Technical Support Department.

Certifications

This equipment has been tested and found to comply with FCC and CE Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received. Including interference that may cause undesired operation.



Waste electrical and electronic products must not be disposed of with household waste. Please recycle where facilities exist. Check with you Local Authority or Retailer for recycling advice.



NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

ADVERTENCIA

En todos nuestros equipos se mencionan claramente las caracteristicas del adaptador de alimentacón necesario para su funcionamiento. El uso de un adaptador distinto al mencionado puede producir daños fisicos y/o daños al equipo conectado. El adaptador de alimentación debe operar con voltaje y frecuencia de la energia electrica domiciliaria existente en el pais o zona de instalación.



Product Warranty Registration

Please take a moment to register your product online. Go to TRENDnet's website at http://www.trendnet.com/register

Copyright ©2010. All Rights Reserved. TRENDnet.