



# TRENDNET



## Quick Installation Guide



**TEG-S2400i**  
**TEG-S2600i**


# Table of Contents

Русский .....	1
1. Что нужно сделать в самом начале .....	1
2. Порядок подключения .....	2
3. Порядок использования коммутатора .....	3
Troubleshooting .....	5

# 1. Что нужно сделать в самом начале



## Применение



## 2. Порядок подключения

1. Присоедините сетевой провод к тыльной стороне устройства TEG-S2400i/ TEG-S2600i.




2. Присоедините сетевой кабель к передней части коммутатора и своему компьютеру.


3. Убедитесь в том, что индикатор **PWR** постоянно горит зеленым цветом.

# 3. Порядок использования коммутатора


1. Выберите Пуск → Настройки → Панель управления.




2. Дважды щелкните по значку Сетевые подключения.




3. Правой кнопкой мыши щелкните по значку Подключение локальной сети, затем по значку Свойства.



4. Щелкните по закладке **Общие сведения** и затем **Свойства**. Выберите **Internet Protocol (TCP/IP)** и затем **Свойства**. Измените IP-адрес на **192.168.223.10** и щелкните по кнопке **ОК**, чтобы изменения были приняты.



5. Откройте свой веб-браузер и введите **http://192.168.223.100**, затем нажмите на **Ввод**.



6. Имя пользователя: **admin**  
Пароль: **123**

7. левой стороны выберите соответствующую опцию для конфигурирования коммутатора SNMP.



**Установка завершена.**

**Примечание:** Подробнее о дополнительных возможностях узнайте в Руководстве пользователя.

## **Q1. How come I cannot see any light from any of my LED's?**

**A1.** Your TEG-S2400i/TEG-S2600i is not getting any power. Make sure that your surge protector or your outlet is getting power and make sure that the AC Power cord is properly connected to your switch.

## **Q2. After connecting several workstations to the switch, I have all workstations communicating with the server, but I cannot access the switch's web configuration utility. What should I do?**

**A2.** Please change your switch's IP address to match the network segment of your workstations. For configuring your switch's IP address, please consult the User's Guide.

## **Q3. I have connected several workstations into the switch, but one workstation does not connect to the network. The LEDs on one of the ports remain unlit, while the rest of the ports have blinking LEDs. What do I do?**

**A3.** You either have a faulty network card or a faulty network patch cable. Make sure that your network card and network cable are functional.

If you have any questions regarding your switch please contact TRENDnet Technical Support Department.

## **Certifications**

This equipment has been tested and found to comply with FCC and CE Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received.  
Including interference that may cause undesired operation.



**NOTE:** THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.



# TRENDnet

## TRENDnet Technical Support

### US/Canada Support Center

**Contact**

**Telephone:** 1(866) 845-3673

**Email:** support@trendnet.com

**Tech Support Hours**

24/7 Toll Free Tech Support



### European Support Center

**Contact**

**Telephone:**

Deutsch : +49 (0) 6331 / 268-460

Français : +49 (0) 6331 / 268-461

0800-90-71-61 (numéro vert)

Español : +49 (0) 6331 / 268-462

English : +49 (0) 6331 / 268-463

Italiano : +49 (0) 6331 / 268-464

Dutch : +49 (0) 6331 / 268-465

**Fax:** +49 (0) 6331 / 268-466

**Tech Support Hours**

8:00am - 6:00pm

Middle European Time

Monday - Friday

## Product Warranty Registration

Please take a moment to register your product online.

Go to TRENDnet's website at <http://www.trendnet.com>

## TRENDnet

3135 Kashiwa Street

Torrance, CA 90505

USA