



# **TEW-501PC – TEW-503PI F.A.Q's**

Q: How do I connect to my wireless network?

A:


**Step 1** Open the utility by double clicking on the icon in the system tray.





Step 2 Click on the AP List tab then click Refresh.





Step 3 Highlight the wireless network you want to connect to, and then click Connect.

## Q: I cannot open the utility. The icon is missing or everything is grayed out in the utility.


A: The Windows Wireless Zero Configuration Utility is running. Make sure you disable it

Step 1 Click on Start then Run and type in ncpa.cpl and click OK.




**Step 2** This will open the **Network Connections** window. Right click on your **Wireless Network Connection** and click on **properties**.





Step 3 Click on the Wireless Networks tab and uncheck Use Windows to configure my wireless network settings at the top. Click OK.





## Q: Why is the Wireless Networks tab missing under the properties of my wireless network connection?


A: The Wireless Zero Configuration service is not running.

**Step 1** Click on **Start** then **Run**. Type in **services.msc** and click **OK**.




**Step 2** This will open the services window. Double click on the **Wireless zero configuration** service.





**Step 3** Make sure the **Startup type** is set to **Automatic** and click **Start** to start the service. Click **Apply** then **OK**.





Step 4 You should now have the Wireless Networks tab.

#### Q: How do I enable encryption on my TEW-501PC or TEW-503PI?


**Note:** To connect to a secured network you must create a profile.

**Step 1** Open the utility by double clicking on the icon in the system tray.




Step 2 Click on the "Profile Setting" tab then click "Add".






**Step 3** Enter in the SSID of the network that you want to connect to in the "Network Name" field and click "Next"





**Step 4** Choose the authentication mode that is being used on the access point that you are connecting to and click "Next".






**Step 5** Enter the security parameters defined by the access point you are connecting to and click "Next."




Wireless Monitor	
Profile Setting	
Input Method :	<b>№</b> ×Hexadecimal ( 0-9, A-F
Key:	*******
KeyIndex:	<b>⇔</b> (1) <b>▼</b>
01010101010101010101010101010101010101	
Back Next Exit	

Step 6 Enable the IP Setting and click "Next".





**Step 7** Enable DHCP and click "Complete" if you are using a dynamic IP address. If you are using a static IP address, disable DHCP and manually enter the desired IP address, subnet mask, default gateway and DNS server addresses.



### Q: What is Ad-Hoc Mode?

A: Peer-to-peer wireless connection between computers when no router or access point is used.



### Q: Why am I getting low signal strength?

A: There are a number of factors that can impact the range of wireless devices.

- 1) Keep the number of obstructions to a minimum. Each obstruction can reduce the range of a wireless device. Position the wireless devices in a manner that will minimize the amount of obstructions between them.
- 2) Building materials can have a large impact on your wireless signal. In an indoor environment try to position the wireless devices so that the signal passes through drywall or open doorways or space.
- 3) Antenna position can also have a large impact on your wireless signal. Use the adapter's site survey tool to determine the best antenna position for your wireless devices.
- 4) Interference from devices that produce RF noise can also impact your signal. Position your wireless devices away from Microwaves, UPS's, monitors, HAM radios, etc. Also, anything operating on the 2.4ghz frequency will cause interference. Such as 2.4ghz cordless phones or other wireless remotes operating on the 2.4ghz frequency.

If you are experiencing low, or no, signal strength consider repositioning the wireless devices, repeating the signal or using stronger antenna's to boost the signal strength.