

PCI Wireless Network Adapter





User's Manual

Rev 1.0

Regulatory compliance

FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-  Reorient or relocate the receiving antenna.
-  Increase the separation between the equipment and receiver.
-  Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-  Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

CE Mark Warning

This is a Class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

About this manual

This User's Manual describes how to install and operate your PCI Wireless Network adapter. Please read this manual before you install the product.

This manual includes the following topics:

- Product description and features.
- Software installation procedure.
- Hardware installation procedure.
- FAQ

Table of Contents

Regulatory compliance

About this manual

<i>Chapter 1- Introduction</i>	5
Features	5
What is Wireless LAN?	6
Wireless LAN Modes	6
Notes on Wireless LAN Configuration	7
<i>Chapter 2 - Hardware Installation</i>	8
Package Contents	8
System Requirements for the Adapter	8
Install the PCI Adapter	8
LEDs Indicators	9
Connecting External Antenna to the Adapter	10
<i>Chapter 3 – Driver Installation for Windows</i>	11
Driver installation for Windows 98	11
Driver installation for Windows 2000	14
Driver installation for Windows ME	17
Driver installation for Windows NT4.0	19
<i>Chapter 4 – Using the Wireless Utility</i>	24
Installation in Windows	24
Configuring the PCI Wireless Network Adapter	28
<i>Chapter 5 –Installing Network Protocols</i>	33
Installing the Network Protocols for Windows 98 and Millennium	33
<i>Appendix A – FAQ</i>	36
<i>Appendix B – Specifications</i>	37

Chapter 1 - Introduction

Thank you for purchasing the PCI Wireless Network Adapter. This high-speed PCI Wireless Network Adapter provides you with an innovative wireless networking solution. The Adapter is easy to set up and use. With this innovative wireless technology, you can share files and printers on the network—without inconvenient wires!

The Adapter is a network Adapter with a rate of 1, 2, 5.5, and 11 Mbps operating in the ISM band using Direct Sequence Spread Spectrum (DSSS) transmission implementing the IEEE 802.11b standard. This Adapter provides Device Drivers for Windows 98, Windows 2000, Windows ME, and Windows NT4.0. It also provides tools for the configuration of the Adapter. The tool, as well as the installation steps of the plug-and-play procedure for the Microsoft Windows 98, Windows ME, Windows 2000, and Windows NT4.0 operating systems, is described in this document.

Features

The PCI Wireless Network Adapter offers compliance with the IEEE 802.11b specification. This feature allows them to communicate with other wireless devices that support the standard. Features of the Adapter are:

- ✂✂ **Uses 2.4GHz frequency band, which complies with worldwide requirement**
- ✂✂ **Wireless interface following the IEEE 802.11b standard**
- ✂✂ **Using PCI interface**
- ✂✂ **Enciphering/deciphering of wireless data by the implementation of the WEP algorithm**
- ✂✂ **Wire-free access to networked resources from anywhere beyond the desktop**
- ✂✂ **Allows users move between Access Points without resetting their connection reconfiguration**
- ✂✂ **Delivers data rate up to 11 Mbps**
- ✂✂ **Supports 11, 5.5, 2, and 1 Mbps rates**
- ✂✂ **Provide PCI Wireless Network Adapter Configuration utility**
- ✂✂ **The Adapter uses external Antenna with LEDs indicating Power and Link**
- ✂✂ **Supports most popular operating systems: Window 98/2000/ME/NT4.0**

What is Wireless LAN?

Wireless Local Area Network (WLAN) systems offer a great number of advantages over traditional wired systems. WLAN is flexible and easy to setup and manage. They are also more economical than wired LAN systems.

Using radio frequency (RF) technology, WLAN transmit and receive data through the air. WLAN combine data connectivity with user mobility. For example, users can roam from a conference room to their office without being disconnected from the LAN.

Using WLAN, users can conveniently access-shared information, and network administrators can configure and augment networks without installing or moving network cables.

WLAN technology provides users with many convenient and cost saving features:

- ?? **Mobility:** WLAN provide LAN users with access to real-time information anywhere in their organization, providing service opportunities that are impossible with wired networks.
- ?? **Ease of Installation:** Installing is easy for novice and expert users alike, eliminating the need to install network cables in walls and ceilings.
- ?? **Scalability:** WLAN can be configured in a variety of topologies to adapt to specific applications and installations. Configurations are easily changed and range from peer-to-peer networks suitable for a small number of users to full infrastructure networks of thousands of users roaming over a broad area.

Wireless LAN Modes

Wireless LANs can be configured in one of two ways:

Ad-hoc Networking	Also known as a peer-to-peer network, an ad-hoc network is one that allows all workstations and computers in the network to act as servers to all other users on the network. Users on the network can share files, print to a shared printer, and access the Internet with a shared modem. However, with ad-hoc networking, users can only communicate with other wireless LAN computers that are in the wireless LAN workgroup, and are within range.
Infrastructure Networking	Infrastructure networking differs from ad-hoc networking in that it includes an access point. Unlike the ad-hoc structure where users on the LAN contend the shared bandwidth, on an infrastructure network the access point can manage the bandwidth to maximize

	<p>bandwidth utilization.</p> <p>Additionally, the access point enables users on a wireless LAN to access an existing wired network, allowing wireless users to take advantage of the wired networks resources, such as Internet, email, file transfer, and printer sharing.</p> <p>Infrastructure networking has the following advantages over ad-hoc networking:</p> <ul style="list-style-type: none">?? Extended range: each wireless LAN computer within the range of the access point can communicate with other wireless LAN computers within range of the access point.?? Roaming: the access point enables a wireless LAN computer to move through a building and still be connected to the LAN.?? Wired to wireless LAN connectivity: the access point bridges the gap between wireless LANs and their wired counterparts.
--	---

Notes on Wireless LAN Configuration

When configuring a wireless LAN (WLAN), be sure to note the following points:

- ?? Optimize the performance of the WLAN by ensuring that the distance between access points is not too far. In most buildings, WLAN Adapters operate within a range of 100 ~ 300 feet, depending on the thickness and structure of the walls.
- ?? Radio waves can pass through walls and glass but not metal. If there is interference in transmitting through a wall, it may be that the wall has reinforcing metal in its structure. Install another access point to circumvent this problem.
- ?? Floors usually have metal girders and metal reinforcing struts that interfere with WLAN transmission.

This concludes the first chapter. The next chapter deals with the hardware installation of the Adapter.

Chapter 2 - Hardware Installation

This chapter covers connecting your PCI Wireless Network Adapter to PCI slot of desktop PC.

Package Contents

Please make sure that items below are included on package.


- ✂✂ One PCI Wireless Network Adapter
- ✂✂ One Driver / Utility CD-ROM (this use's manual included)
- ✂✂ One Quick Installation Guide
- ✂✂ Antenna

System Requirements for the Adapter

- ✂✂ Operating System: Microsoft Windows 95/98/ME/2000/NT4.0/XP
- ✂✂ Desktop PC with CD-ROM drive
- ✂✂ One free PCI slot
- ✂✂ Pentium-Class 90MHz or higher

Install the PCI Adapter


NOTE: These instructions apply to most Personal Computers. For detailed information on inserting PCI Adapter into your computer, please consult the Computer's User's Manual.



The PCI wireless Network Adapter

1. Turn off the computer, unplug the power cord and remove the computer's cover.
2. Pick a free PCI expansion slot and remove the protective bracket.
3. Insert the Adapter into the slot until it is fully seated.
4. Secure the adapter bracket with the screw from step 2.
5. Replace the computer's cover.
6. Reconnect the power cord and turn on the computer.

LED Indicators




Side view of the PCI Adapter

The following table describes the meaning of LED indicators:

LED	MEANING
POWER	Indicates that the Adapter is powered on (solid green).
LINK	Indicates link status. The LED lights up (solid green) while the wireless connection is made. If the LED is blinking green, the adapter is searching for possible wireless connection.

Connecting External Antenna to the Adapter

After installing the Adapter on computer, connect external Antenna to the Adapter from the SMA connector. Hold the antenna in the desired orientation and then turn the lock nut clockwise until snug (do not over tighten the nut). To adjust the antenna direction, turn the nut counter clockwise one full turn, adjust the antenna and then tighten the nut.



Chapter 3 – Driver Installation for Windows

The following sections cover PCI Wireless Network Adapter driver installation in the Windows 2000/ME/98//NT operating systems.

Note: You have to install your hardware first before you begin to install the drivers.

Driver installation for Windows 95/98

Follow the steps below to install the PCI Wireless Network Adapter drivers for Windows 95/98.

1. Insert the PCI Wireless Network Adapter to PCI slot of desktop PC. (Refer to Page8 – Hardware installation.)
2. After Windows 95/98 detects the PCI Wireless Network Adapter, the *Add New Hardware Wizard* window appears. Click **Next** to continue the installation.



3. A screen appears prompting you to select an installation method. Select **Search for the best driver for your device. (Recommended)** and click **Next** to continue.



4. Ensure that the **CD-ROM drive** is selected. Insert the driver CD-ROM into your CD-ROM drive and click **Next** to continue.




5. The following screen appears showing the driver search result. Click Next to continue the installation.



6. Windows 98 copies files to your hard disk. The following screen will appear to inform you when the software installation has finished. Click **Finish** to finish the installation.



7. The following screen will ask you to restart your computer to finish the hardware setting up. Click **Yes** to restart your computer to make the hardware setting available.



P.S. : In most cases, Windows will automatically copy all of the files needed for networking. If Windows ask you for the files and prompt you to input the path to the files, follow the instructions on your screen, and then click **OK** to continue.

Driver installation for Windows 2000

Follow the steps below to install the PCI Wireless Network Adapter drivers for Windows 2000.

1. Insert the PCI Wireless Network Adapter to PCI slot of desktop PC. (Refer to Page8 – Hardware installation.)
2. After Windows 2000 detects the PCI Wireless Network Adapter, the *Found New Hardware Wizard* window appears. Click **Next** to start the installation.




3. A screen appears prompting you to select an installation method. Select **Search for a suitable driver for my device (recommended)** and click **Next** to continue.



4. Ensure that the **CD-ROM driver** is selected and insert the driver CD-ROM into your CD-ROM drive and click **Next** to continue.




- The following screen appears showing the driver search result. Click Next to continue the installation.



- The following screen appears. Click **Yes** to continue



7. The Windows has finished installing software for the device. Click **Finish** to finish the installation.



Driver installation for Windows ME

Follow the steps below to install the PCI Wireless Network Adapter drivers for Windows ME.


1. Insert the PCI Wireless Network Adapter to PCI slot of desktop PC. (Refer to Page8 – Hardware installation.)
2. After Windows ME detects the PCI Wireless Network Adapter, the *Add New Hardware Wizard* window appears. Select **Automatic search for a better driver (Recommended)** and insert the driver CD-ROM into CD-ROM drive and click **Next** to continue.



3. The system will find the setup files and follow the instruction to copy files to your hard disk. The following screen will appear when the software installation has finished. Click **Finish** to finish the installation.



4. The following screen will ask you to restart your computer to finish the hardware setting up. Click **Yes** to restart your computer to make the hardware setting up available.



P.S. : In most cases, Windows will automatically copy all of the files needed for networking. If Windows ask you for the files and prompt you to input the path to the files. Follow the instructions on your screen, and then click **OK** to continue.


Driver installation for Windows NT4.0

This installation procedure assumes that you have installed the network component on your computer.


To check whether the network component has been installed, double click the **Network** icon in the **Control Panel**. If it has not been installed, refer to the Windows NT 4.0 installation guide for instructions on installing the component.

Follow the steps below to install the driver.


1. Insert the PCI Wireless Network Adapter to PCI slot of desktop PC. (Refer to Page8 – Hardware installation.)
2. Log in to NT 4.0 as **Administrator**.
3. Double click the **Network** icon in the **Control Panel**, and select the **Adapters** tab as shown in the following screen. Then click **Add** to add a new adapter to continue.




4. The following screen appears. Then click **Have Disk** to continue.




5. The following screen appears. Type **K:\WinNT40** where **K** is your CD-ROM drive letter. Insert the driver disk, and click **OK** to continue.




6. After finding the installation file, the *Select OEM Option* window is displayed as follows. Select **IEEE802.11b WLAN PCI Card v2.5** and click **OK** to continue.




7. You are returned to the *Network* window. Click **Close** to exit the *Network* window.




8. The Microsoft TCP/IP properties window appears. Please specify an IP address or select to obtain an IP address from DHCP Server and then click **OK** to continue.



9. The following window appears. Please read the description and click **Yes** to continue if there is no questions.



10. The following window appears. Click **Yes** to restart your computer to make the new setting available.




Chapter 4 – Using the Wireless Utility

The following sections cover the PCI Wireless Network Adapter utility installation and configuration.


Installation in Windows

After you have installed the PCI Wireless Network Adapter driver and have rebooted the computer. Please follow the steps below.


1. double click **Setup.exe** under the **Utility** folder in the CD-ROM.




2. Once you see the following screen, click **Next** to continue.




3. The screen will show you the default destination chosen by the utility. Click **Next** to continue or click the **Browse** button to select an alternate destination.




4. The following screen shows the current settings, click **Next** to continue or click **Back** to change the **Destination Folder** in step 3.



5. The following screen shows you the Setup status by percentage.






6. Once the configuration Utility has been successfully installed, the Wizard will ask you to restart your computer. Select **Yes, I want to restart my computer now.**, then click **Finish** to restart your computer and complete set up.



After you have installed the utility and restarted the computer, you will see the wireless utility icon in the Windows taskbar:




Wireless Utility icon

Icon	Meaning
	Green: indicates a connection is active.
	Yellow: indicates poor connection or the wireless LAN card is looking for an available access point.
	Red: indicates very poor connection or no connection.

Double-click the icon to open the configuration utility.

Configuring the PCI Wireless Network Adapter


1. This screen shows you the status of your current connection. Click **Re-Search** to search for wireless connection (the adapter will search for the connection automatically when it is activated).




Link Quality % and **Signal Strength %** available in **Infrastructure** mode only

2. Select the **“Configuration”** tab. The **Profile** allows you to save configurations in different profiles for different environments. The **default** profile will have the settings that you are going to set in the **Configuration**. You can type in a new profile name, finish the settings in Configuration below, and then click **Create** button to create a new profile. To use an existing Profile, just click on the profile drop box, select the desired profile name and then click **Activate**. You can remove a profile name by clicking on the profile drop box, select the desired profile name and then click **Remove**. You can also modify the profile, by activating the profile name, make changes, and then click on **Apply Changes**.
 In **Configuration**, under the **Wireless Mode** drop-box, you may choose either Infrastructure or Ad-Hoc. The Infrastructure mode allows a wireless adapter to communicate with a wired network via an **Access Point**, while the Ad-Hoc mode allows wireless-to-wireless, peer-to-peer communication. If you choose Infrastructure, the **SSID** should have the same name as the Access Point's SSID. If you choose **Ad-Hoc**, all clients in the same wireless network should share the same **SSID** name and same **Channel** number. You may also select which **Transfer Rate** you wish to use: **1, 2, 5.5, 11Mbps** or **Auto Rate** (recommended). Under **Power Saving Mode**, select **Disabled** for uninterrupted data communication, or **Enabled** to allow your Wireless Network Adapter to enter

“sleep” mode. Click **Apply** to save the settings.



3. Select the “**Site Survey**” tab. The list on the adjacent screen shows you available Access Points and their status. Click **Search** to search for available Access Points. Click on the desired Access Point and click **Connect** to connect to the selected Access Point. Click **OK** when you are finished.




4. Click on the “**Encryption**” tab. Under the drop-box, you can choose to have WEP encryption **Disabled, 64-Bit, or 128-Bit**. Wired Equivalent Privacy (WEP) is an encryption scheme used to protect wireless data communication. The Disabled setting prevents the sharing of data with other computers on the WEP network. For data sharing to be enabled, select the level of encryption desired, either 64 or 128-bit.

After selecting the level of encryption, you can enter up to 4 sets of WEP Keys (Key 1~4). WEP uses Hex decimal key, you can enter any combination of numbers from 0 to 9 and alphabets from A to F as the encryption key. A 64-bit key has 10 characters (i.e. **01234abcde**) and the 128-bit key has 26 characters (i.e.


01234567890123456789abcdef). After entering the keys, at **Default TX Key**, select the key number that you would like to use and click on **Apply Changes**.

When the WEP is enabled, the wireless card can only connect to wireless devices with same level of encryption and same set of WEP key.




5. Select the “**Advanced**” tab. You can choose the **fragmentation threshold** (bytes) to define the maximum data frame size your adapter will transmit. When the packet error rate is high, you may set the threshold value to transmit shorter frames. You may select **RTS/CTS threshold** (bytes) to define when your adapter send out RTS/CTS frames to reserve bandwidth for transmission. By using the RTS/CTS function, you may request bandwidth from AP to allow you to have better chance to send out your data. For the **Security**, it's only applicable while WEP is enabled. You can choose the **Deny Unencrypted Data Frames** to deny unencrypted data frames to prevent unknown intruders from probing your wireless station. For the **Authentication Type**, the current supported algorithms are Open System, and Shared Key. The algorithm will be invoked when associated to an Access Point. To associate to the desired Access Point you must set the algorithm the same as the desired Access Point. **Preamble Type** is for framing synchronization. The possible settings are **Long** and **Short**. The setting must be the same as the setting of the Access Point you are connecting to.

Note: Please note that the default values for *Fragmentation Threshold* and *RTS/CTS Threshold* are recommended. However, you can adjust the settings (one at a time) to find the settings with the best performance for your wireless connection. To do this, you will need *Network Benchmark* software. Use the software to compare the default setting performance with the adjusted setting performance.



6. The “**About**” tab shows you copyright and version information about the driver, the configuration utility, and the firmware. Click **OK** to complete the configuration.



Chapter 5 – Installing Network Protocols

Protocols are necessary for computers to be recognized on your network. Windows 2000 users need to check their Windows User Guides for protocol installation.


Installing the Network Protocols for Windows 95/98 and Millennium

1. From the **Start Menu**, select **Settings** and bring up the **Control Panel**. From the Control Panel, double-click on the **Network** icon.




Note: Before adding any network protocols, verify that the protocol is not already installed. Never install duplicate protocols.


2. Select *IEEE802.11bWLAN PCI Card v2.5* from the list and click the **Add** button.



3. Highlight **Protocol** and click the **Add** button.



4. Select **Microsoft** from the list of "Manufacturers" and **TCP/IP** from the list of "Network" Protocols" and click the **OK** button to finish the installation.



Appendix A – FAQ

For Technical Support, please send e-mail to: techsupport@trendware.com

1. What is IEEE 802.11 standard?

✍✍ The IEEE 802.11 is a wireless LAN industry standard, and the objective of IEEE 802.11 is to make sure that different manufactures' wireless LAN devices can communicate to each other.

2. What is WEP?

✍✍ As described in the IEEE 802.11 standard, WEP (Wired Equivalent Privacy) is a data privacy mechanism based on a 40 bit shared key algorithm.

3. My desktop PC cannot recognize the PCI Wireless Network Adapter.

✍✍ Please make sure that the Adapter is inserted into the PCI slot of your desktop PC properly (check this when the PC is powered off).
✍✍ And also make sure that the PCI controller is enabled in the BIOS of your desktop PC.
✍✍ Try installing the card in a different PCI slot.

4. In Infrastructure mode, my desktop PC cannot communicate with the others PCs on the network.

✍✍ Make sure that the SSID is same as the Access Point and other PC.
✍✍ Check if the WEP is enabled on the Access Point, if it is, set your Adapter's WEP the same as the Access Point.
✍✍ Also check the Access Point's Authentication Type and Preamble Type and match those settings.

5. In ad-hoc mode, my desktop PC cannot communicate with the others PCs on the network.

✍✍ Make sure the SSID and the Channel number are the same as other wireless stations.
✍✍ Check if WEP settings are the same in all wireless stations.
✍✍ Check the **Network Properties**, make sure proper protocol is installed and **File and Printer Sharing** is enabled.

Appendix B – Specifications

Standards:	IEEE 802.11b PCI Local Bus 2.1 Compliance
Channels:	11 Channels (US, Canada) 13 Channels (Europe) 14 Channels (Japan)
Antenna:	Dipole Antenna with revised SMA Connector (108 mm)
Frequency:	2.4 to 2.4835GHz (Industrial Scientific Medical Band)
Data Rate:	up to 11Mbps
Operating Ranges:	Indoor (varies depends on the environment): Up to 50M @ 11Mbps Up to 80M @ 5.5Mbps Outdoor (varies depends on the environment): Up to 150M @ 11Mbps Up to 300M @ 5.5Mbps
Dimensions:	135 x 22 x 121 mm (without the antenna)
Temperature:	Operating: 0° ~ 55° C Storage: -25° ~ 70° C
Humidity:	10% to 90% (non-condensing)
Certifications:	FCC, CE

Contact Information:

TRENDware International, Inc.
3135 Kashiwa Street
Torrance, CA 90505
Tel: 310-891-1100
Fax: 310-891-1111
E-mail:
sales@trendware.com
techsupport@trendware.com
www.trendware.com