



TRENDNET®



User's Guide

TPE-80WS

TABLE OF CONTENT

1.0 INTRODUCTION	3
1.1 MAIN FEATURES	3
1.2 START TO MANAGE THIS SWITCH	5
2.0 WEB MANAGEMENT	6
2.1 CONFIGURATIONS	7
2.1.1.1 SYSTEM INFORMATION	7
2.1.1.2 DHCP	8
2.1.1.3 RELOCATE HTTP PORT NUMBER	8
2.1.1.4 TAG VLAN MANAGEMENT GROUP (CPU PORT)	8
2.1.2 PORTS	9
2.1.3 PORT-BASED VLAN	10
2.1.4 TAG-BASED VLAN	12
2.1.5 PORT TRUNKING	14
2.1.6 PORT MIRRORING	15
2.1.7 QUALITY OF SERVICE	16
2.1.8 STORM CONTROL	17
2.1.9 LACP	18
2.1.10 RSTP	20
2.1.11 IGMP	22
2.1.12 802.1X	23
2.1.13 PoE STATUS AND COMMAND OPERATION	24
2.2 MONITORING	25
2.2.1. PORT STATISTICS	25
2.2.2 DETAILED PORT STATISTIC	26
2.2.3 LACP STATUS	27
2.2.4 RSTP STATUS	28
2.2.5 IGMP STATUS	29
2.2.5 PING	29
2.3 MAINTENANCE	30
2.3.1 WARM REBOOT	30
2.3.2 FACTORY DEFAULT	30
2.3.3 FIRMWARE UPDATE	31
2.3.4 CONFIG FILE	31
3.0 TERMINAL MODE MANAGEMENT	32



1.0 Introduction

TPE-80WS Web Smart PoE Switch is a high performance web-smart switch that provides up to 8 10/100/1000Mbps copper Ethernet ports, this device provides a great flexibility for nowadays variety of network application but at lower cost. User doesn't have to learn many sophisticated management function which are usually shown in SNMP switch but just to learn some simple or common control or setting function through either out-of-band RS232 port or Ethernet port, however, some new, advanced and important function such as Tag-VLAN, Trunking, RSTP and IGMP are also supported same as SNMP switch, this means, user doesn't have to pay high cost as tradition layer 2 SNMP switch does while he still can get advanced or common function to meet requirement of general network application. This makes it very suitable for small or medium size company to build up simple network at beginning phase with lower cost. Besides, a optional long-ear accessory also makes it possible to operate in the rack mount environment.

Non-blocking and maximum wire speed performance are designed on all switched ports, it not only supports auto-negotiation but also AUTO-MDIX function on all switched 8 10/100/1000M RJ-45 Gigabit copper ports no matter running with half or full duplex mode, these function make user easy to use and reduce the matching effort between straight and cross-over line issues.

TPE-80WS Web Smart PoE Switch supports both port-based and 802.1Q (tag-based) VLAN to catch-up the application needed in incoming VLAN age. To increase bandwidth application, it supports up to 4 trunk groups with maximum 8 ports on one Trunk, moreover, these trunk ports are with fair-over function to provide redundant back-up when one or some of trunk ports malfunction. Moreover, to reduced convergent time of STP protocol, Rapid STP (RSTP) is supported, to support multicast application IGMP is also supported. ,

Fully LED status display ease user's installation, a reset button is also provided to make user easy to go back to default setting.

1.1 Main Features

This switch provides the following main features:

- Non-blocking, full-line speed, store-and-forward
- Support jumbo frame, Max. packet length 9600 bytes
- Auto-Negotiation and Auto-MDIX on all 10/100/1000M copper ports
- Up to 8 10/100/1000 RJ-45 copper ports
- 144K byte packet buffer, 8K MAC entries
- Support port-based VLAN and tag-based (802.1Q) VLAN
- Support RSTP, IGMP, DHCP
- Support “relocate port number” to “ http operation “

- Port trunk with fail-over capability
- Support flow control for both full/half duplex operations
- Support Multicast storm, Broadcast Storm control as well as Flooding Control
- Support port mirroring
- LED display for each port to show link and activity status
- Desktop and optional Rack mountable kit
- Reset to default “ push button “ and field code upgradeable

1.2 Start to Manage This Switch

Either way user may start to manage this switch, web mode through Ethernet port or terminal mode through RS232 port.

1.2.1 Web mode default setting are:

Default IP Address: 192.168.223.100

Default IP mask: 255.255.255.0

Default gateway: 192.168.223.254

Default Password: admin

1.2.2 Terminal mode default setting are: baud rate: 115,200, attribute: 8, None, 1, None Terminal mode operation: (password: admin)

Once terminal is connected, the basic operation rule are shown below

Press “ ? “ to find root operation page, then choose command by typing little alphabets

After enter command page, Press “ ? “ to find command parameters and format, and type “ command ? “ to get explanation.

Type “ up “ or “ / “ to go back to previous page

2.0 Web management

After login is successfully validated, the switch's home page will show up. The left part on the page provides the *function menus*, while the right part provides the individual configuration value or system parameters value. Functions are divided into three categories, they are **Configuration, Monitoring and Maintenance**; all functions are shown briefly below

Configuration

- **System** – system values, such as H/W, F/W version, IP, IP mask, MAC address...etc
- **Ports** – port status and configure port parameters
- **Port-based VLAN** – to setup the port-based VLAN
- **Tag-based VLAN** – to configure the tag-based VLAN
- **Port Trunking** – to build up the trunk function
- **Port Mirroring** – to setup the port mirroring function
- **Quality of Service** – to configure the Quality of Service function
- **Storm Control** – to set all kinds of storm limit
- **LACP** – to set LACP parameter
- **RSTP** – to set RSTP parameter
- **IGMP** – to set IGMP parameter
- **802.1X** – to set 802.1X parameter

Monitoring:

- **Port Statistics** – to statistic traffic on each ports
- **Detailed Port Statistics** – to statistic more detailed traffic on each ports
- **LACP status** – to show LACP status
- **RSTP status** – to show RSTP status
- **IGMP status** – to show IGMP status
- **Reset** – to reboot the switch with/without writing default configurations
- **Ping** – provide ping function and ping result

Maintenance

- **Warm Reboot** – to restart system
- **Factory Default** – to get parameter value back to factory default
- **Firm Upgrade** – to upgrade code
- **Config File** – to backup configuration data
- **Logout** – to logout

2.1 Configurations

2.1.1.1 System information

The system diagram shows every common system information, they are H/W, F/W version, MAC address, IP address, subnet mask, IP gateway, default VLAN value of management port, name, password, timeout value, and SNMP communities...etc. Once user finish the setting, he must press the “ Apply “ button to execute all his setting, and whenever he needs, he may press the “ Refresh “ button to get updated status of system information.

System Configuration

Model Name	8G_PoE_Smart
MAC Address	00-0a-17-02-14-ec
F/W Version	2.0
H/W Version	1.0
DHCP Enabled	<input type="checkbox"/>
IP Address	<input type="text" value="192.168.223.110"/>
Subnet Mask	<input type="text" value="255.255.255.0"/>
Gateway	<input type="text" value="0.0.0.0"/>
HTTP Listening Port Number	<input type="text" value="80"/> (1024 - 65535)
Tag VLAN Management Group	<input type="text" value="1"/> ▼
Name	<input type="text"/>
Password	<input type="text"/>
Inactivity Timeout (secs)	<input type="text" value="0"/>
SNMP enabled	<input checked="" type="checkbox"/>
SNMP Trap destination	<input type="text" value="0.0.0.0"/>
SNMP Read Community	<input type="text" value="public"/>
SNMP Write Community	<input type="text" value="private"/>
SNMP Trap Community	<input type="text" value="public"/>

Apply

Refresh

2.1.1.2 DHCP

The default DHCP is off, so Default IP or user defined IP is used when this machine is turning-ON, but if this switch needs an IP assigned from DHCP server, user may click the square field and then press “ Apply “ to get an IP which will be assigned by DCHP server “. User must be aware that if he enable DHCP from web page, and if the DHCP server is working, then after enable DHCP, he will lose contact of web page, because the IP address has been changed.

2.1.1.3 relocate HTTP port number

The default port number of **HTTP command** is 80, but unauthorized user may intrude this switch if he knows the IP of this switch, network manager may relocate this port number to other value, from 1024 to 65535, the same idea as above, once network manager change the value of HTTP’s port number, he will lost contact and he must regain web page by command modified as below:

http://192.168.223.100:port_value

2.1.1.4 Tag VLAN management group (CPU port)

At first time you turn on this device, all ports belong to default VLAN ID group (VID=1), so they can communicate to each other, and hence any port can be used as web management port to talk with CPU port inside, but, for example, assume user uses port 1 as web management port, then user create VLAN ID=10 on port 7,8 and create another VLAN ID = 20 on port 5,6, now 3 VLAN groups will be shown on VALN group table after he press “ Apply “ button. If VLAN 10 and VLAN ID 20 must be isolated, then user must delete member port 5,6,7,8 in default VLAN group(VID = 1). Be aware that CPU port is still remain on VID=1 group now, user can only perform web management through one of 4 ports, that is port 1,2,3,4, but if user want to perform web management from other port in **existing** different VLAN group, for example port 8 in VID =10, then at this moment, he must go to system configuration page, and select **Tag VLAN Management Group** to 10, then, press “ Apply “ command, then move RJ-45 (web management port) from port 1 to port 8, then user can perform web management from new RJ-45 port again. But if user forget what group that CPU belongs to, there are two ways to solve this condition below.

- (1) Through console port, change VLAN ID of CPU port if he gets password, or
- (2) Press “**Reset**” button **few seconds**, let system return to default settings, that is,
---- >> IP address=192.168.223.100; ... VID=1, all settings return to factory default

2.1.2 Ports

Port status page always shows current port status of all 8 ports. User can set link mode, enable or disable flow control and jumbo frame, however, be noticed that the jumbo frame is global setting, it can't be set on individual port but on all ports at a time. A default diagram is shown below,

Port Configuration

Port	Link Status	Link Mode	Flow Control
1	100FDX	Auto Speed	<input type="checkbox"/>
2	Down	Auto Speed	<input type="checkbox"/>
3	Down	Auto Speed	<input type="checkbox"/>
4	Down	Auto Speed	<input type="checkbox"/>
5	Down	Auto Speed	<input type="checkbox"/>
6	Down	Auto Speed	<input type="checkbox"/>
7	Down	Auto Speed	<input type="checkbox"/>
8	Down	Auto Speed	<input type="checkbox"/>

Enable Jumbo Frames

Apply Refresh

Choose and click the ports you want to set, for example, choose port 1, and set port 1 Flow Control enable, then press "Apply", after execution, diagram will shown below

Port Configuration

Port	Link Status	Link Mode	Flow Control
1	100FDX	Auto Speed	<input checked="" type="checkbox"/>
2	Down	Auto Speed	<input type="checkbox"/>
3	Down	Auto Speed	<input type="checkbox"/>
4	Down	Auto Speed	<input type="checkbox"/>
5	Down	Auto Speed	<input type="checkbox"/>
6	Down	Auto Speed	<input type="checkbox"/>
7	Down	Auto Speed	<input type="checkbox"/>
8	Down	Auto Speed	<input type="checkbox"/>

2.1.3 Port-based VLAN

Port-based VLAN is a kind of VLAN which is a group of ports marked as a kind by group ID, different VLAN (different ID) can't communicate to each other. Before the setting, user must be aware of that there is a default Port-based VLAN, his group ID is 1, so, if user wants to set another new port-based VLAN, better set another group ID rather than 1. After press “ Apply ” button, the screen will show a new port-based VLAN if he add a new group or screen will delete a port-based VLAN if he delete a group. The important thing is that port-based VLAN is valid only within same device, it will never be valid cross the devices. A default diagram is shown below.

Port-based VLAN (User Group) Configuration

Port-based VLAN Group (User Group) Table									
No.	Group ID	Member Port							
		1	2	3	4	5	6	7	8
1	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Add/Edit a VLAN (User) Group									
Group ID	Member Port								
	1	2	3	4	5	6	7	8	
1 <input type="button" value="v"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	

Choose and click the ports you want to group, for example, choose port 1, port 2 and set their group ID 2, then press “Apply”, after execution, diagram will shown below

Port-based VLAN (User Group) Configuration

Port-based VLAN Group (User Group) Table									
No.	Group ID	Member Port							
		1	2	3	4	5	6	7	8
1	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
2	2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Add/Edit a VLAN (User) Group									
Group ID	Member Port								
	1	2	3	4	5	6	7	8	
2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	

2.1.4 Tag-based VLAN

Tag-based VLAN is another kind of VLAN which is a group of ports marked as same kind by assigning a tag-value on each port, same as port-based VLAN, different VLAN (different ID) can't communicate to each other, and before the setting, there is a default tag-based VLAN, which ID is 1 (VLAN ID=1), so, if he wants to set another new tag-based VLAN, better set another VLAN ID rather than 1 (tag-base VALN ID ranged from 1 ~ 4094). After press “ Apply “ button, the screen will show a new tag-based VLAN if user add a new VALN, or, a tag-VLAN will be vanished if user delete a VLAN. Two important things must be emphasized here, one is that tag-based VLAN members are valid not only within same device, but also cross the devices as long as they are with same VLAN ID; the other important thing is user must keep in mind that the management-port (CPU port)VLAN ID should be the same as some member VLAN ID if user want to management through that port, or, management communication will be failed because different VLAN (different ID) can't communicate to each other.

A default diagram is shown below.

Tag-based (802.1q) VLAN Configuration

Tag-based (802.1q) VLAN Group Table										
Select	No.	VLAN ID	Member Port							
			1	2	3	4	5	6	7	8
<input checked="" type="checkbox"/>	1	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Add/Edit a VLAN Group									
VLAN ID (1-4094)	Member Port								
	1	2	3	4	5	6	7	8	
<input type="text"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

After assign a tag VLAN, there are further attributes parameter can be assigned for some

advanced tag-VLAN application, here below are explanation when entering the “ Port Config “, they are:

1. VLAN Aware mode:

Enable - Strip VLAN tag from received frame, and insert VLAN tag in transmitted frame except ingress frames which tag VID = PVID

Disable – default state, this means, switch doesn’t do VLAN tag stripping and insertion.

2. Ingress filtering:

Enable - Check ingress frame VLAN ID. Ingress frame will be dropped if frame's VID is not the same as the VID of the ingress port which belongs to a member of a VLAN group

Disable – Don’t do ingress VLAN frame checking, the frame will be flood if VID is not the same

3. Accept Packet Type:

ALL - Accept all ingress frames

Tagged only - Only accept ingress frames with VLAN tag

4. Port VID:

Set port VLAN ID for untagged ingress frames. Set "None" for trunk port member.

Tag VLAN Per Port Configuration

Port	VLAN aware Enabled	Ingress Filtering Enabled	Acceptable Packet Type	Port VID
1	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/> All <input checked="" type="checkbox"/> Tagged Only	1
2	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/> All <input checked="" type="checkbox"/> Tagged Only	1
3	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/> All <input checked="" type="checkbox"/> Tagged Only	1
4	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/> All <input checked="" type="checkbox"/> Tagged Only	1
5	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/> All <input checked="" type="checkbox"/> Tagged Only	1
6	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/> All <input checked="" type="checkbox"/> Tagged Only	1
7	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/> All <input checked="" type="checkbox"/> Tagged Only	1

8	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/> All <input type="checkbox"/> Tagged Only	1
---	--------------------------	--------------------------	--	---

Apply	Cancel
-------	--------

2.1.5 Port Trunking

A default diagram is shown below, and up to 4 groups are provided

Port Trunking (Aggregation) Configuration

Group\Port	1	2	3	4	5	6	7	8
Normal	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Group 1	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Group 2	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Group 3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Group 4	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Apply	Refresh
-------	---------

Choose and click the trunk ports you want to group, for example, choose port 1, port 2 into group 1, then press “Apply”, after execution, diagram will shown below

Port Trunking (Aggregation) Configuration

Group\Port	1	2	3	4	5	6	7	8
Normal	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Group 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Group 2	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Group 3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Group 4	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Apply	Refresh
-------	---------

2.1.6 Port Mirroring

A default diagram is shown below,

Port Mirroring Configuration

Mirror Port	1
Port	Mirror Source
1	<input type="checkbox"/>
2	<input type="checkbox"/>
3	<input type="checkbox"/>
4	<input type="checkbox"/>
5	<input type="checkbox"/>
6	<input type="checkbox"/>
7	<input type="checkbox"/>
8	<input type="checkbox"/>

Apply	Refresh
-------	---------

Choose and click the ports you want to monitor, for example, choose port 2

To be monitored, then press “Apply”, after execution, diagram will shown below

Port Mirroring Configuration

Mirror Port	1
Port	Mirror Source
1	<input type="checkbox"/>
2	<input checked="" type="checkbox"/>
3	<input type="checkbox"/>
4	<input type="checkbox"/>
5	<input type="checkbox"/>
6	<input type="checkbox"/>
7	<input type="checkbox"/>
8	<input type="checkbox"/>

2.1.7 Quality of Service

A default diagram is shown below,

Quality of Service (QoS) Configuration

QoS Mode **Port-based** ▼

Default Class Table

Port	Default Class
1	high ▼
2	high ▼
3	high ▼
4	high ▼
5	high ▼
6	high ▼
7	high ▼
8	high ▼

Apply Cancel

QoS Mode **802.1p** ▼
Prioritize Traffic Custom ▼

User Priority Table

Port	1	2	3	4	5	6	7	8
Priority	0 ▼	0 ▼	0 ▼	0 ▼	0 ▼	0 ▼	0 ▼	0 ▼

802.1p Priority - Class Mapping Table

Priority	Class	Priority	Class	Priority	Class	Priority	Class
0	normal ▼	1	low ▼	2	low ▼	3	normal ▼
4	medium ▼	5	medium ▼	6	high ▼	7	high ▼

Apply Cancel

Choose the priority level for the port you want to set; then same priority will get the same priority service.

2.1.8 Storm Control

A default diagram is shown below,

Storm Control Configuration

Storm Control	
Number of frames per second	
Broadcast Rate	No Limit
Multicast Rate	No Limit
Flooded Unicast Rate	No Limit

Choose and click type of storm you want to control, for example, choose Broadcast storm with 3,964 frames per second as upper limit, once the Broadcast frame rate higher than 3,964 frame per second, this port will be disabled. Press “Apply”, after execution, diagram will be shown below

Storm Control Configuration

Storm Control	
Number of frames per second	
Broadcast Rate	3964
Multicast Rate	No Limit
Flooded Unicast Rate	No Limit

2.1.9 LACP

Different from the static port trunking, LACP provides another way to dynamically aggregate port to a group (trunk) according to IEEE 802.3ad. A default diagram is shown below,

LACP Port Configuration

Port	Protocol Enabled	Key Value
1	<input type="checkbox"/>	auto
2	<input type="checkbox"/>	auto
3	<input type="checkbox"/>	auto
4	<input type="checkbox"/>	auto
5	<input type="checkbox"/>	auto
6	<input type="checkbox"/>	auto
7	<input type="checkbox"/>	auto
8	<input type="checkbox"/>	auto

Two parameters need to be set per port basis in this webpage:

- **Protocol Enabled** – to enable/disable LACP protocol for a port.
- **Key Value** – a number (1~255) to identify the LACP group for a port. All member ports in a LACP group have the same key values. Key number will be automatically generated if “auto” value is set

Choose and click the trunk ports you want to group. For example, select port 7 and port 8 to group into a LACP group with key value 20 for both ports, then press “ Apply” to activate the setting. The following figure is the result:

LACP Port Configuration

Port	Protocol Enabled	Key Value
1	<input type="checkbox"/>	auto
2	<input type="checkbox"/>	auto
3	<input type="checkbox"/>	auto
4	<input type="checkbox"/>	auto
5	<input type="checkbox"/>	auto
6	<input type="checkbox"/>	auto
7	<input checked="" type="checkbox"/>	20
8	<input checked="" type="checkbox"/>	20

Apply

Refresh

2.1.10 RSTP

The Spanning-Tree Protocol (STP) is IEEE 802.1d standardized method for avoiding loops in switched networks. Enable STP to ensure that only one path at a time is active between any two nodes on the network.

The Rapid-Spanning-Tree-Protocol (RSTP) is a more advanced protocol than STP according to IEEE 802.1w standard. RSTP can shorten spanning tree convergent time while network topology is changed. A default diagram is shown below,

RSTP Configuration

System Configuration	
System Priority	32768
Hello Time	2
Max Age	20
Forward Delay	15
Force version	Normal

Port Configuration			
Port	Protocol Enabled	Edge	Path Cost
Aggregations	<input type="checkbox"/>		
1	<input type="checkbox"/>	<input checked="" type="checkbox"/>	auto
2	<input type="checkbox"/>	<input checked="" type="checkbox"/>	auto
3	<input type="checkbox"/>	<input checked="" type="checkbox"/>	auto
4	<input type="checkbox"/>	<input checked="" type="checkbox"/>	auto
5	<input type="checkbox"/>	<input checked="" type="checkbox"/>	auto
6	<input type="checkbox"/>	<input checked="" type="checkbox"/>	auto
7	<input type="checkbox"/>	<input checked="" type="checkbox"/>	auto
8	<input type="checkbox"/>	<input checked="" type="checkbox"/>	auto

Apply

Refresh

Use the following parameters in the webpage to configure RSTP function:

■ **System Configuration**

- **System Priority** – A value to identify the root bridge. The bridge with lowest value has the highest priority and is selected as the root. 16 numbers are provided in this field from 0 to 61140 in increments of 4096.
- **Hello Time** -- the number of seconds among the transmission of Spanning-Tree Protocol configuration messages. Enter a number 1 through 10. (default is 2)
- **Max Age** – the number of second bridge waits without receiving Spanning-Tree Protocol configuration messages before attempting a reconfiguration. Enter a number 6 through 40. (default is 20)
- **Forward Delay** -- the number of seconds a port waits before changing from its Spanning-Tree Protocol learning and listening states to the forwarding state. Enter a number 4 through 30. (default is 15)
- **Force Version** – normal: use RSTP; compatible: compatible with old STP protocol

■ **Port Configuration**

- **Aggregations** – Enable/disable the RSTP protocol on aggregation links
- **Protocol Enabled** – Enable/disable the RSTP protocol per port basis
- **Edge** – Enable/disable to expect a port to be an edge port (an end station) or a link to another STP device
- **Path Cost** – A value on a port that switch uses to determine which port are the forwarding ports. The lowest number is forwarding ports. The value can be set from 1 to 200000000 or “auto” to be automatically generated.

2.1.11 IGMP

The Internet Group Management Protocol (IGMP) is an internal protocol of the Internet Protocol (IP) suite. IGMP can manage the multicast traffic if the members (switches, router or other network devices) of group support IGMP. This switch provides IGMP snooping feature to detect IGMP queries, report packets and manage the IP multicast traffic through the switch. This feature can limit the forwarding of multicast frames to only ports that are a member of multicast group. Only **IPv4** IGMP frames are recognized for this system.

IGMP Configuration

IGMP Enabled	<input checked="" type="checkbox"/>
Router Ports	1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> 4 <input type="checkbox"/> 5 <input checked="" type="checkbox"/> 6 <input checked="" type="checkbox"/> 7 <input type="checkbox"/> 8 <input type="checkbox"/>
Unregistered IPMC Flooding enabled	<input type="checkbox"/>

VLAN ID	IGMP Snooping Enabled	IGMP Querying Enabled
1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

The following parameters are provided for configuring IGMP snooping for this system:

- **IGMP Enabled** – to globally enable/disable IGMP snooping function
- **Router Ports** – to specify administrative router ports for IGMP frames
- **Unregistered IPMC Flooding Enabled** – to set forwarding option for unregistered (not joined) IP multicast traffic. Enabled: to flood frames; Disable: to forward frames to **router ports** only

Two options can be set for each existing VLAN group:

- **IGMP Snooping Enabled** – to enable/disable snooping IGMP frames
- **IGMP Querying Enabled** – to enable/disable sending IGMP querying frames

The example webpage show in above shows the configuration of IGMP function which has IGMP enabled, uses port 5 and 6 as router ports to forward the IGMP frames, forwards unregistered IPMC frames to router ports (port 5 and 6), and enables snooping IGMP and sending querying frames for the VLAN group which VID = 1.

2.1.12 802.1x

A default diagram is shown below, user must contact the manager of RADIUS server, and then get IP, UDP port number and secret to operate 802.1X.

802.1X Configuration

Mode	Disabled ▾
RADIUS IP	0.0.0.0
RADIUS UDP Port	1812
RADIUS Secret	

Port	Admin Mode	Port State	Action		
1	Force Authorized ▾	802.1X Disabled	Re-authenticate	Force Reinitialize	Statistics
2	Force Authorized ▾	802.1X Disabled	Re-authenticate	Force Reinitialize	Statistics
3	Force Authorized ▾	802.1X Disabled	Re-authenticate	Force Reinitialize	Statistics
4	Force Authorized ▾	802.1X Disabled	Re-authenticate	Force Reinitialize	Statistics
5	Force Authorized ▾	802.1X Disabled	Re-authenticate	Force Reinitialize	Statistics
6	Force Authorized ▾	802.1X Disabled	Re-authenticate	Force Reinitialize	Statistics
7	Force Authorized ▾	802.1X Disabled	Re-authenticate	Force Reinitialize	Statistics
8	Force Authorized ▾	802.1X Disabled	Re-authenticate	Force Reinitialize	Statistics
			Re-authenticate All	Force Reinitialize All	

Apply Refresh

2.1.13 PoE status and command operation

Some status definition described below before you read or execute the command,

Non-PD, this means there is an ethernet device but not PD device is loaded

No Load: there is not any PD device being loaded to that port, but non-PD may be

Loaded: a PD device is being loaded, class level and allocated power is shown

PD Error: over current event (exceed 350 ma) happened, and port is disabled automatically

Dedicated class, display the class level of current loaded PD device

Allocated power, maximum allocated power to that port , but not current power

PoE Port Configuration

Port	PSE Power	Detected Class	Allocated Power	PoE Status
1	Enable	3	15 W	Loaded
2	Enable	N/A	0 W	No Load
3	Disable	3	0 W	PD Error
4	Enable	N/A	0 W	No Load
5	Enable	N/A	0 W	No Load
6	Enable	N/A	0 W	No Load
7	Enable	N/A	0 W	No Load
8	Enable	N/A	0 W	Non-PD

System Max. Supplied Power (A)	120 Watt
Total Allocated Power (B)	15 Watt
Power Balance (C = A - B)	105 Watt

Apply Refresh

IEEE 802.3af Class - Power Table					
IEEE 802.3af Class	0	1	2	3	4
PSE Output Power	15W	4W	7W	15W	Reserved

2.2 Monitoring

2.2.1. Port Statistics

Choose and click command manual, after execution, diagram will shown below, user can clear counter or refresh as will

Statistics Overview for all ports

Port	Tx Bytes	Tx Frames	Rx Bytes	Rx Frames	Tx Errors	Rx Errors
1	0	0	0	0	0	0
2	4837	7	1122	9	0	0
3	0	0	0	0	0	0
4	0	0	0	0	0	0
5	0	0	0	0	0	0
6	0	0	0	0	0	0
7	0	0	0	0	0	0
8	0	0	0	0	0	0

Clear

Refresh

2.2.2 Detailed Port Statistic

Choose and click command manual, more detailed count will be displayed like below, user can analyze frame per frame size, byte and error types.

Statistics for Port 2

Clear Refresh

[Port 1](#)
[Port 2](#)
[Port 3](#)
[Port 4](#)
[Port 5](#)
[Port 6](#)
[Port 7](#)
[Port 8](#)






Receive Total		Transmit Total	
Rx Packets	152	Tx Packets	32
Rx Octets	12525	Tx Octets	19735
Rx High Priority Packets	-	Tx High Priority Packets	-
Rx Low Priority Packets	-	Tx Low Priority Packets	-
Rx Broadcast	-	Tx Broadcast	-
Rx Multicast	-	Tx Multicast	-
Rx Broad- and Multicast	112	Tx Broad- and Multicast	0
Rx Error Packets	0	Tx Error Packets	0
Receive Size Counters		Transmit Size Counters	
Rx 64 Bytes	-	Tx 64 Bytes	-
Rx 65-127 Bytes	-	Tx 65-127 Bytes	-
Rx 128-255 Bytes	-	Tx 128-255 Bytes	-
Rx 256-511 Bytes	-	Tx 256-511 Bytes	-
Rx 512-1023 Bytes	-	Tx 512-1023 Bytes	-
Rx 1024- Bytes	-	Tx 1024- Bytes	-
Receive Error Counters		Transmit Error Counters	
Rx CRC/Alignment	-	Tx Collisions	-
Rx Undersize	-	Tx Drops	-
Rx Oversize	-	Tx Overflow	-
Rx Fragments	-		
Rx Jabber	-		
Rx Drops	-		

2.2.3 LACP Status

Choose and click command manual, after execution, diagram will shown like below, user can refresh as will

LACP Status

LACP Aggregation Overview								
Group/Port	1	2	3	4	5	6	7	8
State								

Legend		
	Down	Port link down
	Blocked	Port Blocked by RSTP. Number is Partner port number if other switch has LACP enabled
	Learning	Port Learning by RSTP
	Forwarding	Port link up and forwarding frames
	Forwarding	Port link up and forwarding by RSTP. Number is Partner port number if other switch has LACP enabled

Refresh

LACP Port Status			
Port	Protocol Active	Partner Port Number	Operational Port Key
1	no		
2	no		
3	no		
4	no		
5	no		
6	no		
7	no		
8	no		

2.2.4 RSTP Status

Choose and click command manual, after execution, diagram will shown like below, user can refresh as will

RSTP Status

RSTP VLAN Bridge Overview						
VLAN Id	Bridge Id	Hello Time	Max Age	Fwd Delay	Topology	Root Id
1	32769:00-01-c1-00-00-02	2	20	15	Steady	This switch is Root!

Refresh

RSTP Port Status						
Port/Group	Vlan Id	Path Cost	Edge Port	P2p Port	Protocol	Port State
Port 1						Non-STP
Port 2						Non-STP
Port 3						Non-STP
Port 4						Non-STP
Port 5						Non-STP
Port 6						Non-STP
Port 7						Non-STP
Port 8						Non-STP

2.2.5 IGMP Status

Choose and click command manual, after execution, diagram will shown like below, user can refresh as will

IGMP Status

VLAN ID	Querier	Queries transmitted	Queries received	v1 Reports	v2 Reports	v3 Reports	v2 Leaves
1	Idle	0	0	0	0	0	0

Refresh

2.2.5 Ping

A default diagram is shown below,

Ping Function

Ping parameters	
Target IP address	<input type="text"/>
Count	1 <input type="button" value="v"/>
Time Out (in secs)	1 <input type="button" value="v"/>

Apply

Ping Results	
Target IP address	0.0.0.0
Status	Test complete
Received replies	0
Request timeouts	0
Average Response Time (in ms)	0

Refresh

Fill up the IP address you want to ping, set Time Out time and Counts, for example, IP = 192.168.223.254, count = 5, time pout = 5 sec, then press “Apply”, then press “Refresh” after execution, diagram will shown below

Ping Results	
Target IP address	192.168.223.254
Status	Test complete
Received replies	0
Request timeouts	5
Average Response Time (in ms)	0

Refresh

2.3 Maintenance

2.3.1 Warm Reboot

Choose and click command manual, diagram will shown like below, user can press Yes or No

Warm Reboot

Are you sure you want to perform a warm reboot?

2.3.2 Factory Default

Choose and click command manual, diagram will shown like below, user can press Yes or No

Factory Default

Are you sure to reset configurations to factory default?

2.3.3 Firmware Update

Choose and click command manual, diagram will be shown, and then direct the location of the file that to be updated, then press “ upload “, if success, it will be shown below

Software successfully loaded



2.3.4 Config File

Choose and click command manual, diagram will be shown, and then direct the location of the file that to be backup, give a name, then press “ Backup “

Configuration File Backup/Restore

Configuration File Backup



Choose and click command manual, diagram will be shown, and then direct the location of the file that to be restored, then press “ Restore “ It will show transfer completed if it success.

Configuration File Restore



3.0 Terminal Mode management

Terminal mode is easy to operate, it is useful when in-band ethernet communication is malfunction, or user wants to do some parameter setting, for example, before in-band management through Ethernet works, user would be able to modify IP address, subnet mask, ...etc, through the terminal mode.

No password is needed in terminal mode operation, but before it starts, user must set up the terminal parameters, such as Hyper Terminal in Microsoft Window,

Select COM #: COM 1, COM 2, ...then,

Set Baud rate to: 115,200, per second

Set Attribute to 8, None, 1, None (8 bit, No parity, 1 stop bit, No protocol in hardware)

Password: admin

Once terminal is connected, the basic operation rule are shown below

Press “ ? “ to find root operation page, then choose command by typing little alphabets

The screen will show as below

>?

Commands at top level:

System - System commands

Console - Console commands

Port - Port commands

MAC - MAC commands

VLAN - 802.1q (Tag-based) VLAN commands

Aggr - Aggregation commands

LACP - IEEE 802.3ad Link Aggregation commands

RSTP - IEEE 802.1w Rapid Spanning Tree commands

User Group - User Group (Port-based VLAN) commands

QoS - QoS commands

Mirror - Mirror commands

IP - IP commands

Dot1x - Dot1x commands

IGMP - IGMP Snooping commands

Debug - Debug commands

>

After enter command page, Press “ ? “ to find command parameters and format, for

example

>system

System>

System>?

Commands at System level:

System Configuration [all]

System Restore Default [keep IP]

System Name [<name>]

System Reboot

System Xmodem

System SNMP [enable|disable]

System Trap [<IP Address>]

System Read community [<community string>]

System Write community [<community string>]

System Trap community [<community string>]

further more, type “ command “ to get more information, such as type “configuration”

System>configuration

System Configuration:

Name:

S/W Version: 1.1

CVS Tag: sw_8051_2_29e

Compile Date: Dec 18 2006 12:26:43

H/W Version: 1.0

MAC address: 00-0a-17-02-10-06

SNMP: enabled

Trap IP: 0.0.0.0

Read community: public

Write community: private

Trap community: public

Type “ up “ or “ / “ go back to previous page

All others command are operated likewise.

Limited Warranty

TRENDnet warrants its products against defects in material and workmanship, under normal use and service, for the following lengths of time from the date of purchase.

TPE-80WS 5 Years

If a product does not operate as warranted above during the applicable warranty period, TRENDnet shall, at its option and expense, repair the defective product or deliver to customer an equivalent product to replace the defective item. All products that are replaced will become the property of TRENDnet. Replacement products may be new or reconditioned.

TRENDnet shall not be responsible for any software, firmware, information, or memory data of customer contained in, stored on, or integrated with any products returned to TRENDnet pursuant to any warranty.

There are no user serviceable parts inside the product. Do not remove or attempt to service the product through any unauthorized service center. This warranty is voided if (i) the product has been modified or repaired by any unauthorized service center, (ii) the product was subject to accident, abuse, or improper use (iii) the product was subject to conditions more severe than those specified in the manual.

Warranty service may be obtained by contacting TRENDnet office within the applicable warranty period for a Return Material Authorization (RMA) number, accompanied by a copy of the dated proof of the purchase. Products returned to TRENDnet must be pre-authorized by TRENDnet with RMA number marked on the outside of the package, and sent prepaid, insured and packaged appropriately for safe shipment.

WARRANTIES EXCLUSIVE: IF THE TRENDNET PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, THE CUSTOMER'S SOLE REMEDY SHALL BE, AT TRENDNET'S OPTION, REPAIR OR REPLACEMENT. THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. TRENDNET NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE OR USE OF TRENDNET'S PRODUCTS.

TRENDNET SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THAT THE ALLEGED DEFECT IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY CUSTOMER'S OR ANY THIRD PERSON'S MISUSE, NEGLIGENCE, IMPROPER INSTALLATION OR TESTING, UNAUTHORIZED ATTEMPTS TO REPAIR OR MODIFY, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, OR OTHER HAZARD.

LIMITATION OF LIABILITY: TO THE FULL EXTENT ALLOWED BY LAW TRENDNET ALSO EXCLUDES FOR ITSELF AND ITS SUPPLIERS ANY LIABILITY, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF THE POSSIBILITY OF SUCH DAMAGES, AND LIMITS ITS LIABILITY TO REPAIR, REPLACEMENT, OR REFUND OF THE PURCHASE PRICE PAID, AT TRENDNET'S OPTION. THIS DISCLAIMER OF LIABILITY FOR DAMAGES WILL NOT BE AFFECTED IF ANY REMEDY PROVIDED HEREIN SHALL FAIL OF ITS ESSENTIAL PURPOSE.

Governing Law: This Limited Warranty shall be governed by the laws of the state of California.

Note: AC/DC Power Adapter, Cooling Fan, Cable and Power Supply carry 1-Year Warranty



TRENDNET®

TRENDnet Technical Support

US • Canada

Toll Free Telephone: 1(866) 845-3673

24/7 Tech Support



Europe (Germany • France • Italy • Spain • Switzerland • UK)

Toll Free Telephone: +00800 60 76 76 67

English/Espanol - 24/7

Francais/Deutsch - 11am-8pm, Monday - Friday MET

Worldwide

Telephone: +(31) (0) 20 504 05 35

English/Espanol - 24/7

Francais/Deutsch - 11am-8pm, Monday - Friday MET

Product Warranty Registration

Please take a moment to register your product online.

Go to TRENDnet's website at <http://www.trendnet.com/register>

TRENDNET®

20675 Manhattan Place
Torrance, CA 90501
USA