



Quick Installation Guide



TEG-S3000i

Table of Contents

English	1
1. Before You Start	1
2. Chassis Modules	2
3. How to Connect	3
4. Using the Chassis	4
Troubleshooting	6

1. Before You Start



System Requirements

1. Workstations with network cards
2. TCP/IP protocol installed in all workstations
3. A web browser such as Internet Explorer or Netscape Navigator
4. RJ-45 Network Patch Cable to connect your workstations to the TEG-S3000i

Back Panel Optional Modules
(Gigabit Slot)

TEG-S3M2CG TEG-S3M2MG TEG-S3M11CF



**3-Slot Gigabit Layer 2
Managed Chassis**
(TEG-S3000i)



Front Panel Optional Modules
(100Mbps Slots)









TEG-S3M8FX

TEG-S3M8TX

TEG-S3M8S15

2. Chassis Modules

TRENDnet offers an exclusive line of modules for flexible and scalable configuration. Any of our modules below can easily be integrated into your current network topology.

<p>TEG-S3M8TX 8-Port 10/100Mbps RJ-45 Module</p>	
<p>TEG-S3M8FX 8-Port 100Base-FX SC Type Multi-Mode Fiber Module</p>	
<p>TEG-S3M8S15 8-Port 100Base-FX SC Type Single-Mode Fiber Module (15km)</p>	
<p>TEG-S3M2CG 2-Port 10/100/1000Mbps Copper Gigabit Module</p>	
<p>TEG-S3M2MG 2-Port 1000Base Mini-GBIC Slot Module</p>	
<p>TEG-S3M11CF 1-Port 10/100/1000Mbps Copper Gigabit & 1-Port 1000Base-SX Fiber Module</p>	

3. How to Connect

In this example, the TEG-S3M8TX is used. Please use applicable cables (i.e. fiber or copper) to connect the TEG-S3000i to your main network.

1. For 10/100Mbps modules, unscrew the face plates in front of the TEG-S3000i. For Gigabit modules, unscrew the face plate at the back of TEG-S3000i.

2. Slowly slide the module in and push the module all the way to end of the chassis. After locking the module in place, tighten the thumb screws.

3. Connect the AC Power cord to the back of the TEG-S3000i.




4. Connect the network cable to the front of the switch and your PC.

5. Turn on the TEG-S3000i.


6. Verify that the **PWR** LED displays a solid green light.

4. Using the Chassis

1. Go to **Start** → **Settings** → **Control Panel**.




2. Double-Click the **Network Connection** Icon.



3. Right-Click **Local Area Connection**, and select **Properties**.



4. Click the **General** tab, select **Internet Protocol(TCP/IP)**, and click **Properties**. Change the IP address to 192.168.16.222 and click **OK** to apply the settings.




5. Open your web browser, type **http://192.168.16.1**, and press **Enter**.



6. User Name: **root**
Password: **root**

7. Select the appropriate option to configure the Gigabit Managed Chassis.



Your installation is now complete.

Note: For more detail on advanced features, please consult the User's Guide.

Q1: How come I cannot see any light from any of my LED's?

A1: Your TEG-S3000i is not getting any power. Make sure that your surge protector or your outlet is getting power and make sure that the AC Power cord is properly connected to your TEG-S3000i.

Q2: I changed my IP settings to 192.168.16.222 to access the switch, but I still cannot get into the Web configuration page. What should I do?

A2: Make sure there is no other network device using the same IP address. Afterwards, consult the User's Guide to access the switch through the Console Port. Once you reach the command line interface, perform a factory reset and try again.

Q3: I performed a factory reset on the TEG-S3000i, but I still cannot access the web configuration page. What should I do?

A3: If you are configuring more than one TEG-S3000i, then it is possible that you are experiencing IP conflict between these two switches. Please configure each switch one at a time, and make sure you assign a unique IP address to each switch.

If you have any questions regarding the TEG-S3000i please contact TRENDnet Technical Support Department.

Certifications

This equipment has been tested and found to comply with FCC and CE Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received.
Including interference that may cause undesired operation.



Waste electrical and electronic products must not be disposed of with household waste. Please recycle where facilities exist. Check with you Local Authority or Retailer for recycling advice.



NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.



TRENDnet

TRENDnet Technical Support

US/Canada Support Center

Contact

Telephone: 1(888) 777-1550

Fax: 1(310) 626-6267

Email: support@trendnet.com

Tech Support Hours

7:30am - 6:00pm

Pacific Standard Time

Monday - Friday

European Support Center

Contact

Telephone:

Deutsch : +49 (0) 6331 / 268-460

Français : +49 (0) 6331 / 268-461

0800-907-161 (numéro vert)

Español : +49 (0) 6331 / 268-462

English : +49 (0) 6331 / 268-463

Italiano : +49 (0) 6331 / 268-464

Dutch : +49 (0) 6331 / 268-465

Fax: +49 (0) 6331 / 268-466

Tech Support Hours

8:00am - 6:00pm

Middle European Time

Monday - Friday

Product Warranty Registration

Please take a moment to register your product online.

Go to TRENDnet's website at <http://www.trendnet.com>

TRENDnet

3135 Kashiwa Street

Torrance, CA 90505

USA