



Fiber Converters

TFC-1000 Series

- Guía de instalación rápida [1]

1. Antes de iniciar

Contenidos del paquete

- Convertidor de fibra
- Guía de instalación rápida multilingüe
- Alimentación eléctrica de CA

Si cualquiera de los contenidos anteriores se encuentra, por favor contacte a su distribuidor.

Requisitos mínimos

- Un entorno bastante fresco y seco
- Un ambiente donde no haya generadores de campos electromagnéticos fuertes (como motores), vibraciones, polvo o exposición directa a la luz solar
- Un chasis TFC-1600 (opcional) o una superficie firme y nivelada capaz de sostener el peso del Convertidor de fibra.
- 1000Mbps Gigabit Ethernet Switch
- Cables de fibra para conexiones multimodo o de modo sencillo
- Cat. 5e or Cat. 6 RJ-45 Ethernet Cable


Equipo Opcional

- Rack estándar de 19"
- Chasis TFC-1600
- Módulo Mini-GBIC (por ejemplo, TEG-MGBSX, TEG-MGBS10, TEG-MGBS40, TEG-MGBS80, TEG-MGBS10D35, TEG-MGBS40D35) para ranuras Mini-GBIC (sólo para TFC-1000MGB/TFC-1000MGA)

2. Hardware Installation

Instalación de 2 convertidores de fibra de forma independiente

1. Conecte un cable de ethernet RJ-45 desde el puerto ethernet de los convertidores de fibra hasta un puerto ethernet del conmutador (como el TEG-S24Dg).



2. Conecte el cable de fibra a los convertidores.



3. Conecte el adaptador de corriente a la parte posterior del convertidor.



Nota:

1. Para el TFC-1000MSC / S20/ S50 / S70, los cables TX y RX se deben colocar al revés en la conexión de fibra contraria.

2. Cableado

- Cable de fibra óptica multimodo: TFC-1000MSC, TFC-1000MGB/ TFC-1000MGA con módulo TEG-MGBSX
- Cable de fibra óptica monomodo: TFC-1000S20, TFC-1000S50, TFC-1000S70, TFC-1000MGB/TFC-1000MGA con módulo TEG-MGBS10/TEG-MGBS40/ TEG-MGBS80
- Cable de fibra óptica trenzado: TFC-1000S10D3, TFC-1000S10D5, TFC-1000S40D3, TFC-1000S40D5, TFC-1000MGB /TFC-1000MGA con módulo TEG-MGBS10D35/ TEG-MGBS40D35

Instalación del convertidor de fibra sobre un chasis

1. Destornille la tapa del compartimiento deseado del chasis.



2. Afloje el tornillo de ajuste manual y saque el convertidor de la caja de metal.



3. Inserte el convertidor de medios en una ranura disponible y apriete el tornillo de ajuste manual.



La instalación ha sido completada.

3. Indicadores LED y conmutadores Dip

Indicadores LED			
Indicadores LED	Color	Secuencia	Función
PWR (Corriente)	Verde	Sólido	Dispositivo encendido
		Apagado	Dispositivo apagado
LINK/ACT	Verde	Sólido	2000 Mbps (Full Dúplex) (por puerto)
	Verde	Intermitente	2000Mbps (Full Dúplex) (Transmisión y recepción de datos)(por puerto)
		Apagado	El enlace está desconectado

Conmutadores DIP		
Conmutador	Acción	Función
1	Encendido	TX Forced Mode (Modo forzoso)
	Apagado	TX Auto-Negotiation (Autonegociación)
2	Encendido	LLR Enable (Activado)
	Apagado	LLR Disable (Desactivado)

Nota:

1. Después de cambiar las configuraciones del conmutador DIP, reinicie el conversor de fibra.
2. LLR significa Link Loss Return. Cuando LLR está activado, el transmisor de puerto de fibra se apaga si su receptor no puede detectar un enlace válido. Si uno de los conductores ópticos es malo, la tarjeta con LLR activado devolverá una condición de no enlace a su enlace de socios LLR se utiliza para detectar problemas de enlace sólo en el puerto de fibra Si LLR no está activo en un convertidor de fibra, el convertidor de fibra opuesto debe tener LLR desactivado.

Declaration of Conformity



Company Information:

Company Name:
TRENDnet, Inc.

Company Address:
20675 Manhattan Place
Torrance, CA 90501
USA

Product Information:

Product Description:
1000Base-TX to 1000Base-SX/LX Fiber Converter



Model Number:
TFC-1000MSC, TFC-1000S20, TFC-1000S50, TFC-1000S70
TFC-1000MGB, TFC-1000MGA, TFC-1000S10D3,
TFC-1000S10D5 1000S40D3, TFC-1000S40D5

Brand name:
TRENDnet

Technical Standards:

EN 55022 : 2006 Class A
EN 61000-3-2 : 2006 Class A
EN 61000-3-3 : 1995 + A1 : 2001 + A2 : 2005
EN 55024 : 1998 + A1 : 2001 + A2 : 2003

Declaration:

The product is herewith confirmed to comply with the requirements of Directive 2004/108/EC of the Council (European Parliament) on the EMC directive and Energy-related products Directive 2009/125/EC.

I hereby declare that the products and devices mentioned above are consistent with the standards and provisions of the guidelines.

Sonny Su

Full Name

May 27, 2011

Date

Director of Technology

Position / Title

Signature

Limited Warranty

TRENDnet warrants its products against defects in material and workmanship, under normal use and service, for the following lengths of time from the date of purchase.

Fiber Converters– 3 Years Limited Warranty

AC/DC Power Adapter, Cooling Fan, and Power Supply carry a 1 year warranty.

If a product does not operate as warranted during the applicable warranty period, TRENDnet shall reserve the right, at its expense, to repair or replace the defective product or part and deliver an equivalent product or part to the customer. The repair/replacement unit's warranty continues from the original date of purchase. All products that are replaced become the property of TRENDnet. Replacement products may be new or reconditioned. TRENDnet does not issue refunds or credit. Please contact the point-of-purchase for their return policies.

TRENDnet shall not be responsible for any software, firmware, information, or memory data of customer contained in, stored on, or integrated with any products returned to TRENDnet pursuant to any warranty.

There are no user serviceable parts inside the product. Do not remove or attempt to service the product by any unauthorized service center. This warranty is voided if (i) the product has been modified or repaired by any unauthorized service center, (ii) the product was subject to accident, abuse, or improper use (iii) the product was subject to conditions more severe than those specified in the manual.

Warranty service may be obtained by contacting TRENDnet within the applicable warranty period and providing a copy of the dated proof of the purchase. Upon proper submission of required documentation a Return Material Authorization (RMA) number will be issued. An RMA number is required in order to initiate warranty service support for all TRENDnet products. Products that are sent to TRENDnet for RMA service must have the RMA number marked on the outside of return packages and sent to TRENDnet prepaid, insured and packaged appropriately for safe shipment. Customers shipping from outside of the USA and Canada are responsible for return shipping fees. Customers shipping from outside of the USA are responsible for custom charges, including but not limited to, duty, tax, and other fees.

WARRANTIES EXCLUSIVE: IF THE TRENDNET PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, THE CUSTOMER'S SOLE REMEDY SHALL BE, AT TRENDNET'S OPTION, REPAIR OR REPLACE. THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES,

EXPRESSED OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. TRENDNET NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION MAINTENANCE OR USE OF TRENDNET'S PRODUCTS.

TRENDNET SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THAT THE ALLEGED DEFECT IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY CUSTOMER'S OR ANY THIRD PERSON'S MISUSE, NEGLIGENCE, IMPROPER INSTALLATION OR TESTING, UNAUTHORIZED ATTEMPTS TO REPAIR OR MODIFY, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, OR OTHER HAZARD.

LIMITATION OF LIABILITY: TO THE FULL EXTENT ALLOWED BY LAW TRENDNET ALSO EXCLUDES FOR ITSELF AND ITS SUPPLIERS ANY LIABILITY, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF THE POSSIBILITY OF SUCH DAMAGES, AND LIMITS ITS LIABILITY TO REPAIR, REPLACEMENT, OR REFUND OF THE PURCHASE PRICE PAID, AT TRENDNET'S OPTION. THIS DISCLAIMER OF LIABILITY FOR DAMAGES WILL NOT BE AFFECTED IF ANY REMEDY PROVIDED HEREIN SHALL FAIL OF ITS ESSENTIAL PURPOSE.

Governing Law: This Limited Warranty shall be governed by the laws of the state of California. Some TRENDnet products include software code written by third party developers. These codes are subject to the GNU General Public License ("GPL") or GNU Lesser General Public License ("LGPL").

Go to <http://www.trendnet.com/gpl> or <http://www.trendnet.com> Download section and look for the desired TRENDnet product to access to the GPL Code or LGPL Code. These codes are distributed WITHOUT WARRANTY and are subject to the copyrights of the developers. TRENDnet does not provide technical support for these codes. Please go to <http://www.gnu.org/licenses/gpl.txt> or <http://www.gnu.org/licenses/lgpl.txt> for specific terms of each license.



Product Warranty Registration

Please take a moment to register your product online.
Go to TRENDnet's website at <http://www.trendnet.com/register>

Certifications

This equipment has been tested and found to comply with FCC and CE Rules.
Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received. Including interference that may cause undesired operation.



Waste electrical and electronic products must not be disposed of with household waste. Please recycle where facilities exist. Check with you Local Authority or Retailer for recycling advice.



NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

ADVERTENCIA

En todos nuestros equipos se mencionan claramente las características del adaptador de alimentación necesario para su funcionamiento. El uso de un adaptador distinto al mencionado puede producir daños físicos y/o daños al equipo conectado. El adaptador de alimentación debe operar con voltaje y frecuencia de la energía eléctrica domiciliar existente en el país o zona de instalación.

TRENDnet
20675 Manhattan Place
Torrance, CA 90501. USA