

TMR-61U2

**USB 2.0 Multi-Plus Memory Card Reader/Writer
Quick Installation Guide**

**Guide d'installation rapide de
Lecteur/enregistreur de carte mémoire USB 2.0 Multi-Plus**

**Kurzanleitung zur Installation des
USB 2.0 Multi-Plus Speicherkartenleser/-schreibers**

**Guía de instalación rápida del
Lector/escritor de Tarjeta de Memoria Multi-Plus USB 2.0**

Version 10.22.04



TRENDnet[®]
TRENDware, USA
What's Next in Networking

Table of Contents

English	1
1. Prepare for Installation	1
2. Product Detail	2
3. Hardware Installation	3
4. Driver Installation	4
5. Verify Installation	9
Troubleshooting	13

English QIG

1. Prepare for Installation

Thank you for purchasing TRENDnet's TMR-61U2 USB 2.0 Multi-Plus Memory Card Reader/Writer.

This guide will help you set up your USB 2.0 Multi-Plus Memory Card Reader/Writer

Following the installations should be quick and easy, but if you run into any problems, please refer to the Troubleshooting section. If you need further assistance, please visit www.TRENDNET.com or call technical support by phone.

Verify Package Contents

Please make sure you have everything in the box:




Minimum System Requirements

1. Pentium 233Mhz or faster, or MAC
2. 64 MB RAM or more
3. Computer with an available USB 2.0 slot
4. Windows XP, 2000, ME, 98SE or MAC 10.X

2. Product Detail

The USB 2.0 Multi-Plus Memory Card Reader/Writer has 4 slots to put in a CompactFlash, SmartMedia, Memory Stick, SecureDigital or MultiMedia Card.



Insert CompactFlash Card on the top slot. Insert Smart Media card on the bottom slot

Insert Memory Stick on the top slot. Insert MultiMedia card or SecureDigital Card on the bottom slot

3. Hardware Installation

1. Boot up your computer
2. Insert the USB 2.0 Multi-Plus Memory Card Reader/Writer firmly into an available USB slot.



4. Driver Installation

Windows XP/ME

After installing the hardware, Windows will automatically detect and install drivers for the TMR-61U2.

Your driver installation is now complete.


Note: If you would like to verify the TMR-61U2 has been installed properly for your windows, go to the Verify Installation section.

Windows 2000

After installing the hardware, Windows will automatically detect and install drivers for the TMR-61U2.

Note: If you would like to verify the installation, go to the Verify Installation section. If the Verify Installation section does not match what you see on your screen, manually install the drivers by following installation procedure below.

1. Insert the TMR-61U2 Driver CD-ROM into your computer's CD-ROM drive
2. Double-click the **“My Computer”** icon on your Windows desktop.
3. Double-click the **“CD-ROM”** drive and double-click the **“Driver”** folder.
4. Double-click the **“Windows 2000”** folder.
5. Double-click the **“Install”** icon.
6. Click on **“Yes”** to install the Drivers for Windows.



7. Click on “OK” to complete the installation.



8. Restart your computer.


Your driver installation is now complete.

Note: If you would like to verify the TMR-61U2 has been installed properly for your windows, go to the Verify Installation section.


Windows 98SE

After your computer reboots, the “Add New Hardware Wizard” will appear. Windows 98SE will automatically detect the TMR-61U2, and ask you to install the drivers for it.


1. Click **Next**.




2. Click **Next**.




3. Check the **“CD-ROM drive”** box and click **“Browse”**.




4. Click on the **CD-ROM** drive, click on **Driver** folder, click on **Windows 98** folder and Click **OK**.




5. Click **Next**.



6. Click Next.



7. Click Finish.



8. Restart your computer.


Your driver installation is now complete.

Note: If you would like to verify the TMR-61U2 has been installed properly for your windows, go to the Verify Installation section.


5. Verify Installation

Windows XP

1. Click **Start**, and then click **Control Panel**.
2. Double-click the **System** icon. On the **Hardware** tab, click the **Device Manager** button.
3. Expand the “Storage volumes” heading to verify that the 4 **Generic Volumes** have been installed.
4. Expand the “Universal Serial Bus controllers” heading to verify that the **USB Mass Storage Device** has been installed.




5. Go to your desktop and Double click the **My Computer** icon. Four removable disks should now appear.




Windows 2000

1. Click **Start**, highlight **Settings**, and click **Control Panel**.
2. Double-click the **System** icon. On the **Hardware** tab, click the **Device Manager** button.
3. Expand the “Storage volumes” heading to verify that the 4 **Generic Volumes** have been installed.
4. Expand the “Universal Serial Bus controllers” heading to verify that the **Genesys USB Mass Storage Device** has been installed.




5. Double click on **My Computer**. 4 Removable Disks should now appear.




Windows ME

1. Click **Start**, highlight **Settings**, and click on **Control Panel**.
2. Double-click the **System** icon, and click **Device Manager** tab.
3. Expand the “Storage device” heading to verify that the 4 **USB Disks** have been installed.
4. Expand the “Universal Serial Bus controllers” heading to verify that the **USB Mass Storage Device** has been installed.




5. Double click on **My Computer**. 4 Removable Disks should now appear.




Windows 98SE

1. Click **Start**, highlight **Settings**, and click on **Control Panel**.
2. Double-click the **System** icon, and click **Device Manager** tab.
3. Expand the “Universal Serial Bus Controllers” heading to verify that the **USB Card Reader** has been installed.



4. Double-click on **My Computer**. 4 Removable Disks should now appear.



Troubleshooting

Q1. Can I connect or disconnect the USB cable while the computer is on?

A1. Yes, you can connect or disconnect the USB or FireWire cable, or any external USB or FireWire device while the computer is on, because the USB and FireWire interfaces are Plug-and-Play and hot-pluggable.

Q2. I have a USB 1.1 cable. Can it work with USB 2.0 devices?

A2. Yes, it works but it may cause problems for connecting high-speed USB 2.0 external peripherals. Therefore it is recommended that you use a certified USB 2.0 cable.

Q3. After successful installation of the TMR-61U2 USB 2.0 6-in-1 Memory Card Reader/Writer, I insert my memory stick into the slot, but it is not working? What should I do?

A3. Make sure the memory stick is in the right slot. Reference the diagram at the beginning of the installation guide. Make sure it is inserted correctly with the front side up and make sure the light comes on.

If you have any questions regarding the TMR-61U2 USB 2.0 6-in-1 Memory Card Reader/Writer, please contact Trendware Technical Support Department.

Contact Technical Support

Telephone: +1-310-626-6252

Fax: +1-310-626-6267

Website: www.TRENDNET.com

E-mail: support@trendware.com

Technical Support Hours

7:00AM ~ 6:00PM, Monday through Friday

Pacific Standard Time (except holidays)

Certifications

This equipment has been tested and found to comply with FCC and CE Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received.
Including interference that may cause undesired operation.





Product Warranty Registration

Please take a moment to register your product online.
Go to TRENDware's website at <http://www.TRENDNET.com>

TRENDware International, Inc.
3135 Kashiwa Street
Torrance, CA 90505

<http://www.TRENDNET.com>