



Quick Installation Guide

TPE-082WS (V1)

Table of Contents

1 English

1. Before You Start
2. Hardware Installation and Configuration

1. Before You Start

Package Contents

- TPE-082WS
- Quick Installation Guide
- CD-ROM (Utility and User's Guide)
- Power adapter
- Rack mount kit


Minimum Requirements

- Computer with an Ethernet port and web browser
- Network cable


Optional Equipment

- EIA standard 19" rack
- SFP modules (e.g. TE100-MGBFX, TEG-MGBSX, TEG-MGBS10, TEG-MGBS40, TEG-MGBS80)

2. Hardware Installation and Configuration



3. Assign a Static IP address to your computer's network adapter in the subnet of 192.168.10.x (e.g. 192.168.10.25) and a subnet mask of 255.255.255.0.
4. Open your web browser, type the IP address of the switch in the address bar, and then press **Enter**. The default IP address is 192.168.10.200.



5. Enter the **User name** and **Password**, and then click **Login**. By default:

User Name: **admin**

Password: **admin**

Note: User Name and Password are case sensitive.



The login screen for the TPE-082WS device. It features a dark grey background with a light grey header area containing an ID card icon and the title "TPE-082WS LOGIN". Below the header, there are two input fields: "User Name:" and "Password:". The "User Name:" field contains the text "admin". The "Password:" field contains six dots. To the left of the "User Name:" field, there is a callout bubble containing the text "admin". To the left of the "Password:" field, there is another callout bubble containing the text "admin". At the bottom right of the form, there is a "LOGIN" button. A callout bubble points to this button with the text "LOGIN".

6. Click **System** and then click **IPv4 Setup**.

7. Configure the switch to match the requirements of your network. Then click **Apply** to save changes.




The configuration screen for the switch. It has a dark grey background. On the left, there is a sidebar with a "System" menu item highlighted by a callout bubble. Below it, there is an "IPv4 Setup" menu item, also highlighted by a callout bubble. The main area of the screen is divided into two sections: "Switch Info" and "IPv4 Setup". The "Switch Info" section lists various system settings: System Management, IPv4 Setup, IPv6 Setup, IPv6 Neighbor, DNS, IP Access List, Administration, Timeout, System Time, SSL, and DHCP Auto Configuration. The "IPv4 Setup" section contains a table with the following information:

IPv4 Setup	
System MAC Address:	00:01:02:03:04:05
System IP Address:	192 . 168 . 10 . 200
System Subnet Mask:	255 . 255 . 255 . 0
System Default Gateway:	0 . 0 . 0 . 0
System IP Mode:	Static ▼

At the bottom of the "IPv4 Setup" section, there is an "Apply" button. A callout bubble points to this button with the text "Apply".


8. Click **OK**.




A warning dialog box with a dark grey header and a light grey body. The header contains the word "WARNING" in bold. The body contains a warning icon (a triangle with an exclamation mark) and the text: "The management session will be disconnected. Use new IP address to connect to device." Below the text, there are two buttons: "OK" and "Cancel". A callout bubble points to the "OK" button with the text "OK".

9. In the left hand panel, click **Tools**, click on **Configuration**, and click **Save**.

10. Click **Save Settings to Flash** (button).



11. Click **OK**.



Note:

1. If you would like to easily discover all the Web Management Switches on the network, assign IP address, change password, then install the Web Smart Switch Management Utility. Follow the steps provided on the user's guide.
2. To download the latest version of the user's guide and the utility, please go to <http://www.trendnet.com/support> and select the TPE-082WS within the Products Download dropdown list.

Declaration of Conformity

TRENDnet®

Manufacturer's Name and Address

TRENDnet, Inc.
20675 Manhattan Place
Torrance, CA 90501 USA

Zwolsestraat 156 2587 WB
The Hague The Netherlands



Product Information:

Model Number: TPE-082WS
Product Name: 10-Port Gigabit Web Smart PoE+ Switch
Trade Name: TRENDnet

TRENDnet hereby declare that the product is in compliance with the essential requirements and other relevant provisions under our sole responsibility.

Safety

EN 60950-1:2006+A11:2009+A1:2010+A12:2011+A2:2013

EMC

EN 55032:2012+AC: 2013 (CISPR32:2012) (Class A)
EN 61000-3-2:2014
EN 61000-3-3:2013
EN 55024:2010
AS/NZS CISPR 32:2013

This product is herewith confirmed to comply with the Directives

Directives

EMC Directive 2014/30/EU
RoHS Directive 2011/65/EU
WEEE Directive 2012/19/EU
REACH Regulation (EC) No. 1907/2006
Low Voltage Directive 2014/35/EC

Person responsible for this declaration.

Place of Issue: Torrance, California, USA

Date: June 08, 2017

Name: Sonny Su

Title: Director of Technology

Signature:

A handwritten signature in black ink, appearing to read 'Sonny Su', is written over a horizontal line.





Certifications

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received.

Including interference that may cause undesired operation.



Waste electrical and electronic products must not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or Retailer for recycling advice.

Technical Support

If you have any questions regarding the product installation, please contact our Technical Support.

Toll free US/Canada: **1-866-845-3673**

Regional phone numbers available
at www.trendnet.com/support

TRENDnet

20675 Manhattan Place
Torrance, CA 90501
USA

Applies to PoE Products Only: This product is to be connected only to PoE networks without routing to the outside plant.

Note

The Manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Advertencia

En todos nuestros equipos se mencionan claramente las características del adaptador de alimentación necesario para su funcionamiento. El uso de un adaptador distinto al mencionado puede producir daños físicos y/o daños al equipo conectado. El adaptador de alimentación debe operar con voltaje y frecuencia de la energía eléctrica domiciliar existente en el país o zona de instalación.

Product Warranty Registration

Please take a moment to register your product online. Go to TRENDnet's website at:
www.trendnet.com/register